

### Configuration of IPDSLAM ADSL (D-Link) Modem

Connect Modem and PC by using UTP Patch chord.

Set PC IP address in the range of *192.168.1.100*

#### **Open Internet explorer**

At address bar type 192.168.1.1 press enter key

D-Link wind security screen will be displayed

USERNAME : **admin**

PASSWORD : **admin** press enter key

At left side you will find click on **ADVANCE SETUP**, Press **ADD** enter

VCI change **35 to 33**, Press Apply and Save.

Left Side Press LAN, it will be in the bottom.

**Press (default enabled) disable DHCP server**, press apply and save , enter

Left side press **WIRELESS**

Left **BASIC** right side **ENABLE** , Press Apply

Left side **MANAGEMENT** at bottom press **REBOOT** , press YES

The system will restart automatically and IP will be assigned.

#### **Go to the command prompt of the PC.**

Check the IP address configured (Type ipconfig/all , press enter)

Type **ipconfig/release**

Then type **ipconfig/renew**