

DFM Engineering, Inc.
1035 Delaware Avenue, Unit D
Longmont, Colorado 80501
Phone: 303-678-8143
Fax: 303-772-9411
Web: www.dfmengineering.com



TELESCOPE CONTROL SYSTEM

Upgrade to WinTCS

DFM OPERATIONS MANUAL

THE PERKIN ELMER 63 INCH APERTURE TELESCOPE

OBSERVATOIRE DU MONT-MEGANTIC

NOTRE-DAME DES BOIS, QUEBEC

CANADA JOB 2E0

By DFM ENGINEERING, INC. 2012

PO Number: BC00022709 (Universite de Montreal)

Customer: Dr. Robert LaMontagne 514 343 6111 ext 3195
Ship Date: 10 September 2012

WARRANTY

All DFM parts and labor specified in this contract are warranted by DFM Engineering, Inc. to be free from defects in materials and workmanship for a period of one year from the acceptance date. DFM will assign all manufacturer's warranties for parts that are not manufactured by DFM, but DFM gives no warranty and assumes no liability for those parts. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, SPECIFICALLY INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED.

Remedies for breach of this warranty are limited to repair or replacement of defects only, at the option and expense of DFM. In the event of any repair or replacement required by this warranty, such work shall be warranted for one year from completion under the terms of this warranty. DFM shall have no liability for any loss or damage arising from breach of this warranty, including incidental or consequential damages, except as expressly provided herein. DFM shall have no liability for defects or damages resulting from misuse, acts of God, war, vandalism, or theft. All maintenance during the warranty period shall be performed by or with the written consent from DFM, and any unauthorized maintenance shall relieve DFM from any liability under this warranty.

In the event DFM performs any work not covered by this warranty, the customer shall be fully responsible for all labor and material expenses incurred by DFM. The terms for such work shall be agreed to by the parties in writing prior to any work done by DFM.

ATTORNEY'S FEES

In the event DFM retains an attorney because of the customer's failure to pay any amounts under this contract, the customer shall be responsible for all reasonable attorney's fees incurred by DFM, in addition to any other damages.

SOFTWARE LICENSE AGREEMENT

The license agreement between customer and DFM ENGINEERING, INC. for rights in technical data and computer software is located in section 6.30 of this manual.

CONTENTS

1.0 GENERAL DESCRIPTION

1.1 MECHANICAL

1.2 ELECTRONIC

1.3 SOFTWARE

2.0 ADJUSTMENTS

2.1 BALANCE

2.2 LIMIT SWITCHES

2.3 ALIGNMENT

3.0 OPERATION

3.1 STARTING UP THE CONTROL SYSTEM

3.2 THE FRONT PANEL

3.3 THE DISPLAY

3.4 THE HAND PADDLE

3.5 THE MENU

3.5.1 File

3.5.1.1 Save Pointing Data

3.5.1.2 Exit

3.5.2 Telescope

3.5.2.1 Initialization

3.5.2.2 Movement

3.5.2.3 Rates

3.5.2.4 Misc.

3.5.3 View Status/Error Log

3.5.4 Options

- 3.5.4.1 Communication (external computer)
- 3.5.4.2 Night Colors
- 3.5.4.3 Defaults

- 3.5.5 Help

- 3.6 EXTERNAL COMPUTER INTERFACE

- 3.7 THE ASTRONOMICAL COMMAND LANGUAGE INTERFACE (ACL)

- 3.8 CONTROL SYSTEM SHUTDOWN AND RESTART

- 3.9 INSTRUMENT ROTATOR

4.0 MAINTENANCE

- 4.1 SOFTWARE BACKUPS

- 4.2 BELT TENSION

- 4.3 SERVO-MOTOR SETUP

- 4.4 POINTING MODEL

- 4.5 INITIALIZATION FILES

5.0 TROUBLE SHOOTING

- 5.1 MOTOR RUNAWAY

- 5.2 BAD POINTING

6.0 APPENDICES

- 6.1 TCP/IP & EXCOM DOCUMENT

- 6.2 SERVO TUNEUP DOCUMENT

- 6.3 COPY OF SOFTWARE LICENSE AGREEMENT

- 6.4 DRIVE DEMESHER ADJUSTMENT

1.0 GENERAL DESCRIPTION

1.1 MECHANICAL

The Perkin Elmer 63 inch aperture Telescope is an equatorial mounted Cassegrain telescope. After modification, the RA drive is one stage of worm gears driven by a stepping servomotor through two timing belt and pulley stages. The HA encoder is driven off the HA worm shaft. The DEC drive is one stage of worm gears driven by a stepping servomotor through two timing belt and pulley stages. The DEC encoder is driven off the DEC worm shaft. The focus motion is provided by a servo-motor driven secondary mirror and focus position is recorded with a Potentiometer. The existing instrument rotator has been modified to allow operation with two AC motors driving the brakes and a variable speed DC motor driving the rotation pinion. The instrument rotator position is encoded with a multiple turn potentiometer that provides feedback for the software control.

1.2 ELECTRONIC

The telescope is controlled with a PC computer. An interface card plugs into the PC and controls the motor driver unit. Cables connect the PC and the telescope to the motor driver unit. A hand paddle plugs into the motor driver chassis (MDC) and a second hand paddle may plug in at the pedestal. The MDC contains power supplies and control logic hardware for the motors. There is a mercury limit switch assembly mounted on the tube assembly. This final limit switch is a power interlock which cuts power to the motors at the horizon. The PC interface includes VIA's (versatile interface adapter) which the PC uses to control the telescope. Intel 8254 pulse rate generators are used to produce motion commands to the motors. LSI 7066 up-down counters are used to keep track of axes positions. An AD-574A (12 bit) analog to digital converter is used to read the focus position pot. The electronic chassis are housed in a 19 inch wide rack. Power for the chassis is 115 volts.

1.3 SOFTWARE

The software is written in Turbo-Pascal. The software is a multitasking 32 bit windows application. The control software is written for a general purpose equatorial research grade telescope operating in either hemisphere. Coordinate handling allows operation in any epoch. Corrections are performed for precession, nutation, aberration, refraction, mechanical and optical misalignments, and mechanical flexure. Small changes are required to

adapt the control system to site specific details including latitude, longitude, elevation, and dome type. These changes are made to the initialization file which is used to initialize system variables when the software is executed. The pointing model program may be used to modify the initialization file.

2.0 ADJUSTMENTS

2.1 BALANCE

It is important to balance the telescope to optimize performance, increase instrument life, and for safety. Balance of both axes of the telescope may be checked with the amp-meters on the front panel of the motor driver chassis. The meters read +3 and - 3 amps full scale. Use the hand paddle to see that the same current is required to slew in the two directions for each axis. Adjust counterweights until balance is achieved.

1. Balance the telescope with trim weights added to the North or South side of the primary mirror cell with the tube pointed at the zenith.
2. Balance the tube assembly top to bottom with the tube nearly horizontal.
3. Balance the Right Ascension axis (tube in any position).

2.2 LIMIT SWITCH

There is a mercury limit switch assembly on the tube assembly. These switches provide limits for the servo motors. The limits interrupt power to the motors if the tube assembly is nearly horizontal. If this limit is active a small green light on the motor driver chassis will go out. To recover from this final limit, the Halt Motors button on the motor driver chassis may be latched (it is latched in the IN position) and the telescope manually driven out of the limit. For worm drive telescopes a limit over-ride switch is provided so that the telescope can be driven out of the limit with the hand paddle. This keyed over-ride switch should be used only when the fault has been corrected. The focus axis has two sets of limits. The first set provides logic to the hand paddle input. The second set cuts power to the servo-motor if there is a servo failure. There is a momentary focus limit-over-ride switch which may be used to bypass the second set of limits.

2.3 ALIGNMENT

The following procedure is recommended for polar alignment:

Note: A star is drifting in the direction pushed on the hand paddle to re-center the star.

1. Orient cross hairs N-S, E-W in an illuminated retical eyepiece.
2. Track a star near the meridian and about 0 degrees declination.

If the star drifts south then the polar axle lies NE-SW.

If the star drifts north then the polar axle lies NW-SE.

Adjust in AZIMUTH to correct drift.

3. Track a star at about 6 hours east or west and about 45 degrees declination.

IF		E star drifts N		THEN
		or		
		W star drifts S		

ELEVATION OF POLAR AXLE IS TOO GREAT

IF		E star drifts S		THEN
		or		
		W star drifts N		

ELEVATION OF POLAR AXLE IS TOO SMALL

Adjust ELEVATION to correct drift.

3.0 OPERATION

3.1 STARTING UP

The control system is able to accommodate operation on either side of the pier. Choice of operation is selected from the initialization menu. The system defaults to West side operation at startup.

Turn on the switch on the power strip. Raise the door and press the start button on the control computer. After some disk access Windows will appear. Double Click the WinTCS shortcut on the desktop and the telescope control system will be loaded and will start. The control system automatically auto-initializes (Updates time, date, and assumes the telescope is pointing at the stow position. When auto-initialization is over, the top line in the Status group box will indicate INITIALIZED.

To move the telescope it is necessary to turn on the motor driver chassis and make sure the latching HALT MOTORS button is out. It is also necessary to place the front panel DRIVES switch in the ON position. This chassis also supplies power for the encoders. The latching HALT MOTORS button interrupts power to the servo-motors.

3.2 FRONT PANEL

The front panel is integrated into the Motor Driver Chassis. A cable labeled front panel plugs into the PC computer chassis. The TRACK / AUX track switch allows rapid selection of two preset track rates. The TRACK switch turns tracking on and off. The DRIVES switch is an input to the computer, and also turns off power to the motor driver chassis through a solid state

relay. The EXTERNAL COMPUTER switch is obsolete in WinTCS. The AUTODOME switch enables the dome control. This switch should be turned off until the dome has been properly initialized with command 3, "set dome". The DOME HOME/TRACK switch commands the dome to either track the telescope in azimuth, or to go to the preset home position. The home position is typically west; however, it may be set to any value. Prevailing weather patterns may dictate a preferred dome storage azimuth. Status of these switches is displayed in the TCS display.

3.3 THE DISPLAY

The WinTCS display is a window which appears on a pair of VGA monitors. The first group box of the display shows Telescope Position displayed in the first horizontal row in mean coordinates in the display epoch. The second row shows the next object coordinates in the next object epoch if a next object has been entered. The middle group box of the display shows Operating Modes which include Through-the-pole-operation, Target out of range, Approaching limits, and Limit reached. The Time/Date group box shows the UTdate, UT, ST, and Julian Date. The Rates group box shows Track rates, Track rate corrections, Guide and Set hand paddle rates, Cosine of the Declination and Trail parameters. The Status group box displays the status of Dome control, Tracking, Drive power, Dome destination (home or track), hand paddle or guider inputs (NSEW), Slew Enabled, Slewing, Setting, Trailing, HA-Demesh, and DEC-Demesh. The Misc. group box shows Telescope Azimuth, Dome Azimuth, focus position and instrument rotator position. In the lower right is Communications group box which shows if ExCom, MNCP, or TCP/IP are active. Menus are provided at the top line of the WinTCS display. If either the HA or DEC worm gear demesh switch is true TCS will make a warning sound.

3.4 USING THE HAND PADDLE

The Hand paddle is used to move the telescope under manual control. There are the four directions: N S E W, and three speeds: GUIDE, SET, and SLEW. The focus may be adjusted from the hand paddle using IN or OUT. Simultaneously pressing SET with IN or OUT gives a fast focus motion. SET and GUIDE speeds are adjustable from the menu. If the COSDEC feature is turned on, the guide and set speeds in Right Ascension will be proportional to $1/\cos(\delta)$ (cosine of the declination) up to a maximum of 1.5 degrees per second. SLEW is 1.5 degrees per sec. Automatic slews disable the hand paddle.

3.5 USING THE MENUS

3.5.1 File:

3.5.1.1 File: Save Point Data

Save point Data activates the pointing model data collection dialog box which lets the user collect, edit, and create a file of pointing data. The *Save point Data* dialog is non-modal and may be positioned on the display for convenience during pointing model tuneup.

3.5.1.2 File: Exit

Exit provides for ending your WinTCS session.

3.5.2 Telescope:

3.5.2.1 Telescope: Initialization ***

Date/Time (UPDATE): This command automatically executes when the TCS program starts. This auto-initialization uses the battery backed up clock in the PC and assumes the telescope is pointed at the zenith. This command calculates sidereal time based on input of the date and universal time. This command allows the user to manually enter the time and date for WinTCS. There is a button to tell WinTCS to get the time and date from the battery backed up clock in the PC. TCS time is kept in a hardware clock which runs at 200 Hz. Always check the UT and date after starting WinTCS. If the UT or the date are wrong then the PC time and date should be set using the control panel in Windows.

Telescope Position (ZERO POINT): This command sets the position of the telescope based on operator input. A button is available which will initialize the telescope position to the next object coordinates.

Other Positions: Set dome position (ZDOME): This command is used to initialize the dome position. North is zero azimuth, and azimuth increases clockwise looking down on the dome. A button tells WinTCS to set the dome azimuth based on the telescope position.

Move Rotator Position (ZROTATOR): This command is used to move the instrument rotator to position.

3.5.2.2 Telescope: Movement

The Movement dialog box is non-modal and may be positioned on the display for convenience. All of the motion commands may be canceled with the *Stop* button in the movement menu or on the main form. Approaching limits will also terminate automatic motion commands. All motion commands except TRAIL require the *Start slew* button to initiate motion after a slew has been ENABLED. This is a chance for the operator to double check that the area around the telescope is clear of people and obstructions. Horizon checks are performed before slews are ENABLED. If a destination is below the telescope horizon, a message will appear TARGET OUT OF RANGE. If a destination is above the telescope horizon it will be displayed in the NEXT OBJECT row of

the display and SLEW ENABLED will appear indicating that an automatic slew is pending. After an automatic slew is complete, the SLEW ENABLED message will disappear as well as the next object HA and AIRMASS.

Set slew position (RA,DEC): This command automatically slews the telescope to coordinates specified by the user. The commanded EPOCH will be the DISPLAY EPOCH if a zero is entered. If the telescope is not tracking, the slew may never terminate because the Earth's rotation is faster than the final automatic guide speed.

Set slew position (HA,DEC): This command automatically slews the telescope to coordinates specified by the user. The commanded EPOCH will be the DISPLAY EPOCH if a zero is entered. If the telescope is tracking, the slew may never terminate because the Earth's rotation is faster than the final automatic guide speed.

Set offset (OFFSET): This is a slew to coordinates relative to the present coordinates in the display epoch. Input is in seconds of arc. The speed of the offset is a function of the distance to be offset and not specified by the user.

Set zenith position (ZENITH): This command is used to slew the telescope to the Zenith. When Set Zenith Position is selected a prompt will appear that instructs the user to turn off tracking. Failure to turn off tracking may result in an un-terminated slew because the earth's rotation is faster than the automatic guide speed.

Set Stow position : This command is used to slew the telescope to the Stow position. When Set Stow Position is selected a prompt will appear that instructs the user to turn off tracking. Failure to turn off tracking may result in an un-terminated slew because the earth's rotation is faster than the automatic guide speed.

Set Flat Field position: This command is used to slew the telescope to the Flat field screen. When Set Flat Field is selected a prompt will appear that instructs the user to turn off tracking. Failure to turn off tracking may result in an un-terminated slew because the earth's rotation is faster than the automatic guide speed.

Select library object (OBJECT): This is a slew to a library of objects which are stored in the computer memory. All objects are stored in epoch 2000. The objects are the "Sommers-Bausch Observatory Catalog of Astronomical Objects". The catalog includes a set of ephemeris stars at one hour intervals which are useful for initializing the telescope position in the northern hemisphere. A library for southern hemisphere users as well as custom libraries are available. WinTCS displays the library in a spreadsheet format and allows sort and search capability.

Mark/Move Table (MOVE/MARK): This dialog allows the user to load, save Mark files as well as edit mark file entries, make entries of current telescope

position and slew to Marked positions. There are 500 entries possible for each file.

Start trail (TRAIL): This button turns the trail function on. The stop button is used to cancel trailing. Note: other commands are ignored while TRAIL is active.

Start slew (GO): This button starts automatic slews.

Stop (STOP): This button is used to cancel automatic motion commands from the menu.

3.5.2.3 Telescope: Rates

Track, guide, set, and trail rates may be set from the menu. Rates are arbitrary from zero to slew speed, allowing tracking of astronomical objects or satellites. All motion of the telescope is superimposed on the track rates specified. Slews to coordinates are optimized for astronomical objects with mean coordinates of the epoch specified. Slewing to coordinates with non-sidereal track rates may not be successful. The Auxiliary track rate feature allows a slew to position and then a rapid shift to non-sidereal rates with the front panel switch.

Track rate (TRACK RATE): This command allows modification of both RA and DEC track rates. There is an auxiliary track rate which is useful if moves are to be made between sidereal and non-sidereal objects. The auxiliary track rate is selected with a front panel switch. For external computer operation, the track rate may simply be changed with the track rate command for rapid changes.

Hand paddle rates (GUIDE RATE), (SET RATE): Guide is a traditional hand paddle function with rates superimposed on the track rate. Speeds between 3 and 10 arc seconds per second are recommended. Set is typically faster than guide and convenient values are 50 to 300 arc seconds per second.

Trail rates (TRAIL RATES): This command sets up the parameters for the trail function. Trail moves at a predetermined rate between two pre-calculated endpoints. This function is used to move an object back and forth along the slit in a spectrograph.

3.5.2.4 Telescope: Miscellaneous

Switches (COSDEC), (RATECOR), (DOME), (HOME):

(COSDEC): This command turns on a feature that divides commanded Right Ascension hand paddle rates by the cosine of the Declination so that the apparent motion of the object in the eyepiece is constant. (RATECOR): This command turns on the track rate correction feature of the control system. Rate corrections are calculated by differentiating the pointing model and these corrections may be automatically applied to the track rates. (DOME): This command is used to enable or disable dome function from the menu. (DOME HOME): This command is used to set the dome home/track bit from the menu. This can be convenient if the user is in the dome instead of in the

control room. The software command of the dome is only enabled if the front panel switch is in the Track position. If the switch is in the Home position, then the dome will go home and software command will be ignored.

Display epoch (EPOCH): The display epoch may be set to any value.

Set Side of Pier: The side of pier operation may be set to east or west.

Move focus position: This command allows the user to slew the telescope focus using the focus potentiometer for feedback.

3.5.3 View:

Status/Error Log... shows the last 100 entries.

3.5.4 Options:

3.5.4.1 Options: Communications

Communications events may be logged.

Excom: To use the standard DFM EXCOM interface. The external computer is user supplied and interfaces to the telescope controller through a serial port. Commands from the external computer are documented in the file EXCOM & TCP/IP.TXT which is an appendix to this document. This feature is designed to provide a telescope control system which can be slaved to a data acquisition computer or general observatory computer used to provide a customer supplied interface to the telescope control system.

MNCP: WinTCS supports Astronomical Command Language (ACL) as defined by Merlin Controls Corporation using a serial port and may be commanded from "The Sky" a planetarium program by Software Bisque in Golden Colorado. In brief: Double click on "The Sky" icon to start the planetarium software; click on TELESCOPE and pull down the menu to "establish link". Once the link is established, you may use "The Sky" to SYNC and SLEW THE TELESCOPE from the dialog box for a given object shown by "The Sky". As the telescope moves, "The Sky" will display a circle with a cross to show the telescope position. Telescope data setup for "The Sky" is: 9600 Baud, ACL Telescope.

TCP/IP: To use the DFM TCP/IP (ethernet) interface. The external computer is user supplied and interfaces to the telescope controller through an ethernet connection. Commands from the external computer are documented in the file EXCOM & TCP/IP.TXT which is an appendix to this document. This feature is designed to provide a telescope control system which can be slaved to a data acquisition computer or general observatory computer used to provide a customer supplied interface to the telescope control system.

The normal configuration for The 63 inch telescope will be:

Com1 = TheSky

Com2 = TheSky-MNCP

3.5.4.2 Options: Night Colors

This option uses dark colors to help the user maintain dark adaptation.

3.5.4.3 Options: Defaults

The user may save and retrieve WinTCS settings from these commands.

3.5.5 Help

WinTCS features on-line help.

3.6 EXTERNAL COMPUTER INTERFACE

To use the DFM EXCOM interface, turn on the EXCOM interface with Options/Communications/EXCOM. The external computer is user supplied and interfaces to the WINTCS telescope controller through a serial port. Commands from the external computer are documented in the file EXCOM.TXT which is an appendix to this document. This feature is designed to provide a telescope control system (WINTCS) which can be slaved to a data acquisition computer or general observatory computer used to provide a customer supplied interface to the telescope control system.

3.7 ASTRONOMICAL COMMAND LANGUAGE (ACL)

To use the ACL interface, turn on the MNCP interface with Options/Communications/MNCP. The TCS supports ACL as defined by Merlin Controls Corporation and may be commanded from "The Sky", a planetarium program by Software Bisque in Golden, Colorado. As with the DFM External Computer Interface, a second computer is required to run "The SKY". In brief: Double click on "The Sky" icon to start the planetarium software; click on TELESCOPE and pull down the menu to "establish link". Once the link is established, you may use "The Sky" to SYNC and SLEW THE TELESCOPE from the dialog box for a given object shown by "The Sky". As the telescope moves, "The Sky" will display a circle with a cross to show the telescope position. Telescope data setup for "The Sky" is: COM1, 9600 Baud, ACL telescope.

3.8 CONTROL SYSTEM SHUTDOWN AND RESTART

To stow the telescope for convenient restart:

(in the dome)

Move the telescope to a convenient position.
Cover the optics using covers provided.
Turn off tracking (command zero track speed).
Command the TCS to slew to the zenith.

(move to the control room).

Place dome home-track switch in the HOME position.
Wait for the dome to go home.
Wait for the telescope to go to the zenith.
Press the red HALT MOTORS button on the motor driver chassis to

interrupt power to the telescope motors.

Turn off dome with the front panel switch.

Turn off main power switch on the transformer enclosure.

Close the dome shutter.

To restart after shutdown

(This assumes the telescope was left at the zenith and the dome at the home position).

(in the dome)

Open the dome shutter.

Check that the telescope was left in the normal shutdown position (usually at the ZENITH).

(in the control room)

Power up the system with the main circuit breaker on the lower front panel.

Start TCS (type TCS <cr>).

Let TCS Auto-initialize.

Unlatch red HALT MOTORS button on the motor driver chassis.

Turn on tracking.

Turn on dome.

Place Dome Home-Track switch in the track position.

Remove covers from the optics.

Select and slew to an ephemeris star.

(move to the dome unless camera display is in the control room)

Center star in eyepiece.

Set telescope coordinates with "Set telescope position" in the initialization menu (entering "0's will set telescope position to the NEXT OBJECT coordinates).

3.9 INSTRUMENT ROTATOR

The motorized instrument rotator must be commanded from TCS. The command is in the Initialization menu and the input units are degrees. Travel is limited to +/- 120 degrees with North = 0. The position is displayed below the telescope focus on the TCS display. Control electronics for the instrument rotator are in the Mirror Support Chassis.

4.0 MAINTENANCE

4.1 MAKING SOFTWARE BACKUP COPIES

Since it is only a question of time before the system hard disk has a failure, it is a good idea to keep a copy of WinTCS so that the system hard disk can be rebuilt. Windows was supplied with your computer and can be reinstalled if necessary. Use Windows utilities to make backups of your WinTCS files.

4.2 BELT TENSION

There are timing belts between the motor and primary gearing in both Declination and Right Ascension. Check the timing belts for wear and tension, they should be snug, but not tight.

4.3 SERVO-MOTOR SETUP

The servomotors can only be setup by a qualified technician using an oscilloscope, and the document Servo.doc which is an appendix to this manual.

4.4 POINTING MODEL

The pointing model program is used to determine the values of correction constants used by the TCS to point the telescope. The constants are changed in the initialization file on disc. This file is read by TCS when the program is executed. This file is name ASU.DAT.

The Data required is:

TR	TELESCOPE RA
TD	TELESCOPE DEC
SR	ACTUAL PUBLISHED RA
SD	ACTUAL PUBLISHED DEC
TH	TELESCOPE HA

Data may be recorded with TCS. Initialize the telescope coordinates on a star near the zenith and record this first star. Take a set of data from stars which lie near the meridian (near zero Hour Angle), this is called the DEC sweep. Take a second set of data near the equator (near zero DEC), this is called the RA sweep. Stars should be about 10 or 15 degrees apart, and can be found easily in the Bright Star Catalog of "The Astronomical Almanac". These two sweeps across the sky are important because they isolate the pointing model terms. About 20 stars is sufficient for analysis. TCS includes commands which allow these data to be taken and stored on the hard disk for subsequent analysis. Commands in the Initialization menu OPEN and CLOSE a file. The command "Write data to file" in the Movement menu will record the data for a star position each time it is used.

***** **NOTE!!** *****

The first star in the data must be a star recently used to initialize the telescope position for valid error calculations. For this star the Published and Telescope values for RA and DEC are very nearly the same.

After pointing data is stored on disk, exit TCS with the RESET button and run the program PNTM. To do this type in: PNTM filename.PAT <cr>.

The program PNTM requests values for the constants and then calculates the pointing errors. The program repeats allowing new constants to be tried in an iterative manner until the user is satisfied. In addition to the pointing model coefficients, other initialization values (for example site Latitude) may be changed using PNTM. During the process of exiting PNTM, the initialization file may be updated.

Analysis of the graphs is done to determine the values of the coefficients.

DEC VS. DEC This graph shows the DEC scale factor in its slope. The asymmetric terms are refraction and tube flexure.

RA vs HA This graph shows the HA scale factor in its slope. The asymmetric term is refraction.

DEC vs HA This graph shows the elevation and azimuth misalignment of the polar axle. The elevation is curvature, and the azimuth is slope.

HA vs DEC This graph shows the collimation and non-perpendicularity of the DEC and Polar axes. Collimation is curvature and non-perpendicularity is slope.

It is desirable for the physical misalignments to be small before the computer model is calibrated because the interaction of terms will then be small. The drift test for azimuth and elevation should be at the level of a few arc seconds of drift in one half hour or better. Large collimation errors should be corrected by adjusting the tip-tilt of the primary mirror. Refraction can be adjusted in software to compensate for the altitude and temperature of the site. The tube flexure, and non-perpendicularity terms are mechanical characteristics of the mount, and are not site dependent.

The terms have units as follows:

SCLRA	ARCSEC/DEG	ra scale factor
SCLDEC	ARCSEC/DEG	dec scale factor
ME	ARCSEC	elevation misalignment (+ = above pole)
MA	ARCSEC	azimuth misalignment (+ = NW--SE)
CH	SEC	optical collimation
NP	SEC	non-perpendicularity of RA & DEC axis
TFLX	ARCSEC	tube flexure
TBAR	NONE	temp & pressure coefficient

This is a physical model and each term has real significance which is directly related to some aspect of the telescope mount. The determination of constants should be done in a methodical way which isolates individual terms by working on the shapes of the graphs. Attempts to minimize the overall error with any single term will result in poor pointing. Each term should be adjusted to remove the corresponding slope or curvature.

Before you get started on a new installation make sure all the terms in the TCS pointing model are zero, the site latitude and longitude are correct and that the scale factors are about theoretical. TBAR should be a number between 1.0 for sea level and .75 for 7000 feet above sea level. At higher altitudes, TBAR should be smaller.

PNTM will run with or without a printer. If there is no printer, do not request a printout, and do not request a copy of the graphs. If there is a printer, a printout must be made before the graphs will print. If the program hangs up, it is because the printer is missing; to recover press reset and start the program over.

For setting up a new telescope:

1. Adjust the elevation with a bubble level protractor. Adjust the azimuth by sighting the north star (eyeball method).
2. Use the drift test to do the rough alignment using a reticle eyepiece or CCD camera.
3. Take pointing data (the DEC and RA sweeps).
4. Run the pointing model programs and determine the coefficients.
5. If the residual misalignments for azimuth or elevation are larger than 60 arc seconds, dial off the error mechanically using a magnetic base and dial indicator. Additional drift alignment should be performed to determine the sense (direction) of the residual errors.
6. Take a second set of data, and determine the coefficients.
7. Take more data to confirm the pointing performance.

In a pointing tune-up of an established telescope there may be no need to correct the azimuth or elevation alignment if the mount has not been moved. There should never be a need to adjust the ratios for the encoder drives unless the friction drive surfaces have been reground. The non-perpendicularity will be a constant for the life of the mount unless the DEC bearing housings are shimmed or machined. A common problem is the need to change the collimation term after primary mirror movement due to collimation or cleaning.

4.5 INITIALIZATION FILES

The TCS initialization file is named WinTCS.DAT. This file contains the pointing model data and other data required by TCS. The files are ASCII data files and they may be modified with a text editor. The program PNTM can be used to modify WinTCS.DAT or the file may simply be edited. The following list shows the contents of WinTCS.DAT with a description for each entry.

LATITUDE:= 39.25	site latitude degrees
LONGITUDE:= 76.709	site longitude degrees
TBAR:= 0.95	site temperature and pressure coefficient
ME:= 60.0	polar elevation misalignment
MA:= 0.0	polar azimuth misalignment
CH:= 0.0	optical collimation misalignment
NP:= 0.0	non-perpendicularity of RA and DEC axes
TWIST:= 0.0	polar axle twist
TWSTOF:= 0.0	polar axle twist offset
TFLX:= 0.0	tube flexure
ECCDEC:= 0.0	DEC encoder eccentricity
PHADEC:= 0.0	DEC eccentricity phase angle
HOME:= 268.	dome home position
ZDMAX:= 75.0	maximum zenith distance for automatic slew
XMTR:= 0.0920100	RA axis motor step size arcsec/step
YMTR:= 0.0927	DEC axis motor step size arcsec/step
DOMERATIO:= 3.08E-6	dome encoder ratio radians/encoder unit
HARATIO:= 1.163663	RA axis position encoder ratio arcsec/eu
DECRATIO:= 1.0125	DEC axis position encoder ratio arcsec/eu
UTRATIO:= 3.59137036E5	universal time clock scalar interrupts/hour
GAP:= 15.0	dome gap (telescope-dome aperture)/2 inches
RDOME:= 120.0	dome radius inches
WINDOW:= 2.5	dome control algorithm target window degrees
COAST:= 2.5	dome coast distance degrees
FOCRATIO:= 0.2633	focus encoder ratio
FIDHA:= 0.25	HA fiducial real hours
FIDDEC:= 31.0	DEC fiducial real degrees

5.0 TROUBLE SHOOTING

5.1 MOTOR RUNAWAY

If the servomotors run out of control when the motor driver chassis is turned on and the HALT MOTORS button is enabled, the most likely problem is that the servo control system is not getting motor encoder feedback. Check the motor encoder cables on the motor driver chassis and at the axis drive cover for dislodged pins or other failure. Inside the drive cover, check the connector on the encoder on the back of the motor. If all connectors are OK then there is a failure in the encoder 5 volt power, component failure on the servo control card, or failure of the encoder on the motor shaft. Repair of non connector failure modes should be made by an experienced technician or a representative of DFM Engineering Inc.

5.2 BAD POINTING

Check the Universal time (UT) and the date on the TCS display. Verify the setup star. Check for mechanical problems with the optics. Follow instructions for tuning up the pointing model.

6.0 APPENDICES

6.1 EXCOM DOCUMENT

6 March 2002

DFM ENGINEERING, INC.
BY MARK S. KELLEY

This document is a supplement to the Operations Manual and it describes the DFM external computer interfaces TCP/IP & EXCOM). This is not the Astronomical Command Language (ACL) interface. The ACL interface, TCP/IP and the EXCOM interfaces are resident in WinTCS.

EXTERNAL COMPUTER

To use the standard DFM External Computer Interface (EXCOM) or the TCP/IP interface they must be activated using the communications menu in WinTCS. The external computer is user supplied and interfaces to the telescope controller through a serial port (EXCOM) or the ethernet network card (TCP/IP). This feature is designed to provide a telescope control system which can be slaved to a data acquisition computer or general observatory computer used to provide a customer provided interface to the telescope control system. The program PCEXCOM.XPL is an example of an external computer user interface.

The commands used by the external computer are the same as those used by WinTCS. The commands are given here in numerical order with the input and output shown for the excom users information. All I/O is character I/O. The WinTCS serial port is selectable. The port setup is 9600 Baud, 8 data bits, 1 stop bit, no parity. Transmit, receive and ground are required. The external computer (user supplied) may have special requirements for serial port control lines. For example, DOS machines typically require jumpers between pins 4 & 5 and that 6, 8 and 20 be jumpered together. Command numbers are all integers. Interrogation of the status integers will reveal command status. TCS does not store up commands. Commands will be ignored if a previous command is still in progress. The TCP/IP connection uses standard ethernet technology. Ports must be set in WinTCS as well as in the client. The TCP/IP commands are packetized and begin with "#", subsequent numbers are separated with "," and packets are terminated with ";". For an example a SLEW command sent over the TCP/IP interface looks like: #6,18.3457,35.3456,2002.5; To summarize, the TCP/IP commands are like EXCOM commands except send a "#" first, use "," instead of the <cr> to separate values, and end with a ";". WinTCS will return the same strings to the external computer running TCP/IP as it does to the external computer running EXCOM except the characters will be packetized with a leading "#", number separators will be "," and the last character will be a ";".

FOR ALL OF THESE DESCRIPTIONS <CR> DENOTES THE CARRIAGE RETURN CHARACTER HEXADECIMAL \$0D.

UPDATE COMMAND 1 INITIALIZE / UPDATE TIME AND DATE

THIS PROCEDURE INITIALIZES THE FOCUS ENCODER, SETS THE CLOCKS AND WILL INITIALIZE COORDINATES TO THE ZENITH IF THE SYSTEM IS NOT YET UPDATED. INITIALIZES DATE AND TIME IF SYSTEM IS INITIALIZED.

EXCOM SENDS	CHARACTERS	COMMENTS
	1 <CR>	COMMAND #
	1994.0 <CR>	YEAR
	11. <CR>	MONTH
	22. <CR>	DAY
	17.123456 <CR>	UNIVERSAL TIME (REAL HOURS)
TCS RESPONDS	NO RESPONSE	INITIALIZES FOCUS ENCODER INITIALIZES TELESCOPE TO ZENITH SETS TIME & DATE. AFTER FIRST INITIALIZATION, SETS TIME & DATE ONLY.

*** Initialization ***

Set date and time (UPDATE): This command calculates sidereal time based on input of the date and universal time. TCS Time is kept in a hardware clock which runs at 200 Hz. The PC Computer has a battery backed up clock which is reset along with the date when the update command is executed. If zero is entered for the year in the update command the program gets the time and date from the battery backed up clock in the PC.

The clocks are updated and the telescope will be assumed to be at the zenith (UPDATE). After initialization, the status INITIALIZED will appear on the display screen.

ZDOME COMMAND 2

INITIALIZE THE DOME ENCODER

EXCOM SENDS	CHARACTERS	COMMENTS
	2 <CR>	COMMAND #
	270. <CR>	POSITION (0.-->360.)
TCS RESPONDS	NO RESPONSE	SETS DOME UP DOWN COUNTER

Set dome position (ZDOME): This command is used to initialize the dome position. North is zero azimuth, and azimuth increases clockwise looking down on the dome. If zero is entered as the dome azimuth, TCS will set the dome azimuth based on the telescope position.

ZPOINT COMMAND 3

INITIALIZE THE RA AND DEC POSITION ENCODERS
ENTER ZEROS FOR NEXT OBJECT

EXCOM SENDS	CHARACTERS	COMMENTS
	3 <CR> 12.012345 <CR> 12.345678 <CR> 1950. <CR>	COMMAND # RA (HOURS) DEC (DEGREES) EPOCH
TCS RESPONDS	NO RESPONSE	SETS TELESCOPE POSITION TO RA, DEC DOES NOT MOVE TELESCOPE

Set telescope position (ZERO POINT): This command sets the position of the telescope.
Three ZERO's will set the telescope position display to the next object coordinates.

ZROTATOR COMMAND 4

SET THE POSITION OF THE INSTRUMENT ROTATOR

EXCOM SENDS	CHARACTERS	COMMENTS
	4 <CR> 45.0 <CR>	COMMAND # POSITION (+/- 120. Degrees)
TCS RESPONDS	NO RESPONSE	

ZFOCUS COMMAND 5

INITIALIZE THE FOCUS POSITION

EXCOM SENDS	CHARACTERS	COMMENTS
	5 <CR> 2000.1 <CR>	COMMAND # POSITION (0.-->4096.0)
TCS RESPONDS	NO RESPONSE	SETS FOCUS UP DOWN COUNTER

Set focus position (ZFOCUS): This command is used to initialize the focus position display.
The focus is an absolute pot. This command offsets the focus display to the input value.

SLEW COMMAND 6

SETS UP AUTOMATIC SLEW
CHECKS DESTINATION COORDINATES FOR HORIZON
SETS NEXT OBJECT COORDINATES
CONVERTS FROM NEXT OBJECT EPOCH TO DISPLAY EPOCH IF REQUIRED
CONVERTS FROM APPARENT COORDS (EPOCH = -1) TO MEAN COORDS IN
DISPLAY EPOCH IF REQUIRED

EXCOM SENDS	CHARACTERS	COMMENTS
	6 <CR>	COMMAND #
	12.012345 <CR>	RA (HOURS)
	12.345678 <CR>	DEC (DEGREES)
	1950. <CR>	EPOCH
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO RA, DEC

Set slew position (SLEW): This command prepares TCS to automatically slew the telescope to the coordinates specified. The EPOCH will be the display epoch if a ZERO is received. If the telescope is not tracking, the slew may never terminate because the Earth's rotation is faster than the final automatic guide speed. After the slew is ENABLED (status bit set) by COMMAND 6, a COMMAND 12 (GO) is required to initiate the slew. If the coordinates are below the telescope horizon, the TARGET OUT OF RANGE status bit will be set.

OFFSET COMMAND 7

OFFSETS ARE MOTIONS IN ARC SECONDS FROM THE TELESCOPE MEAN COORDINATES IN THE DISPLAY EPOCH.

EXCOM SENDS	CHARACTERS	COMMENTS
	7 <CR>	COMMAND #
	100. <CR>	OFFSET RA (ARC SECONDS + = EAST)
	150. <CR>	OFFSET DEC (ARC SECONDS + = NORTH)
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO OFFSET

Set offset (OFFSET): This is a slew to coordinates relative to the present coordinates in the display epoch. Input is in seconds of arc. The speed of the offset is a function of the distance to be offset and not specified by the user. Status bits for ENABLED and TARGET OUT OF RANGE apply. COMMAND 12 must be sent to move telescope.

OBJECT COMMAND 8 SLEW TO OBJ WITH LOOKUP

SLEW TO LIBRARY OF OBJECTS

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	8 <CR> 13 <CR>	COMMAND # LIBRARY #
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO LIBRARY OBJECT

Select library object (OBJECT): This is a slew to a library of objects which are stored in the computer memory. All objects are stored in epoch 2000. The objects are the Sommers-Bausch Observatory Catalog of Astronomical Objects and a printout of the catalog is supplied with the telescope. The catalog includes a set of ephemeris stars at one hour intervals which are useful for initializing the telescope position in the northern hemisphere. A library for southern hemisphere users as well as custom libraries are available. Check the status bits for ENABLED and TARGET OUT OF RANGE. A COMMAND 12 must be sent to move the telescope.

TMOVE COMMAND 9

PROCEDURE SLEWS TO AN OBJECT PREVIOUSLY STORED WITH THE MARK COMMAND

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	9 <CR> 32 <CR>	COMMAND # TABLE #
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO TABLE ENTRY

Select table entry (MOVE): This command is the partner of the Set table entry (MARK) command in the Miscellaneous submenu. Select table entry is used to slew to locations previously stored in memory with the Set table entry command. There are 500 entries possible. Check the status bits for ENABLED and TARGET OUT OF RANGE. A COMMAND 12 must be sent to move the telescope.

ZENITH COMMAND 10

SLEWS THE TELESCOPE TO THE ZENITH

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	10 <CR>	COMMAND #
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO ZENITH

Set zenith position (ZENITH): This command is used to slew the telescope to the Zenith. Use TRACK, COMMAND 14 to set the track rates to zero before the zenith command is used. Failure to set track speed to zero may result in an un-terminated slew to zenith because the earth's rotation is faster than the automatic guide speed. Recover from an un-terminated slew with STOP COMMAND 13. Status bits for ENABLED and TARGET OUT OF RANGE apply. COMMAND 12 must be sent to move telescope.

TRAIL COMMAND 11

START TRAIL

EXCOM SENDS	CHARACTERS	COMMENTS

	11 <CR>	COMMAND #
TCS RESPONDS	NO RESPONSE	BEGINS TRAILING

Start trail (TRAIL): This command turns the trail function ON. STOP COMMAND 13 or the CANCEL button on the front panel are used to end trailing. Guide while trailing is allowed, so it may be a good idea to stop any autoguider inputs while trailing.

GO COMMAND 12 INITIATE MOTION COMMANDS

EXCOM SENDS	CHARACTERS	COMMENTS

	12 <CR>	COMMAND #
TCS RESPONDS	NO RESPONSE	BEGINS AUTOMATIC MOTION

Start slew (GO): This command starts automatic slews.

STOP COMMAND 13 CANCELS AUTO SLEW IN PROGRESS CANCELS SLEW ENABLED IF MOTION NOT BEGUN THIS COMMAND CANCELS AUTOMATIC MOTIONS AND COMMANDS

EXCOM SENDS	CHARACTERS	COMMENTS

	13 <CR>	COMMAND #
TCS RESPONDS	NO RESPONSE	STOPS AUTOMATIC COMMAND

Stop (STOP): This command is used to cancel automatic motion commands.

TRACK COMMAND 14
CHANGE TRACK RATE RA & DEC

EXCOM SENDS	CHARACTERS	COMMENTS
	14 <CR>	COMMAND #
	15.002. <CR>	RA RATE (ARC SECONDS/SECOND)
	.05 <CR>	DEC RATE (ARC SECONDS/SECOND)
	14.545 <CR>	AUX RA RATE (ARC SECONDS/SECOND)
	0. <CR>	AUX DEC RATE (ARC SECONDS/SECOND)
TCS RESPONDS	NO RESPONSE	CHANGES TRACK RATES

Set track rate (TRACK RATE): This command allows modification of both RA and DEC track rates. There is provision for an auxiliary track rate which is useful if comparisons are to be made between sidereal and non- sidereal objects. The auxiliary track rate is selected with a front panel switch. For external computer operation, the track rate may simply be changed with the track rate command for rapid changes. Positive DEC rate is north.

GUIDE COMMAND 15
CHANGE THE GUIDE RATE RA & DEC

EXCOM SENDS	CHARACTERS	COMMENTS
	15 <CR>	COMMAND #
	7. <CR>	RATE (ARC SECONDS/SECOND)
TCS RESPONDS	NO RESPONSE	CHANGES GUIDE RATE

Set hand paddle GUIDE rates: Guide is a traditional hand paddle function with rates superimposed on the track rate. Speeds between 3 and 10 arc seconds per second are recommended. The response of TCS to guide inputs may be adjusted with the GUIDE command. An autoguider may require specific rates.

SET COMMAND 16
CHANGE THE SET RATE FOR RA & DEC

EXCOM SENDS	CHARACTERS	COMMENTS
	16 <CR>	COMMAND #
	200.0 <CR>	RATE (ARC SECONDS/SECOND)
TCS RESPONDS	NO RESPONSE	CHANGES SET RATE

Set hand paddle SET rates: SET is similar to GUIDE and convenient values are 50 to 300 arc seconds per second.

TRAIL COMMAND 17

SET TRAIL RATE, LENGTH, & ANGLE

EXCOM SENDS	CHARACTERS	COMMENTS
	17 <CR>	COMMAND #
	200.0 <CR>	RATE (ARC SECONDS/SECOND)
	50. <CR>	LENGTH (ARC SECONDS)
	0. <CR>	POSITION ANGLE (NORTH) (90. EAST)
TCS RESPONDS	NO RESPONSE	CHANGES TRAIL RATES

Set trail rates (TRAIL RATES): This command sets up the parameters for the trail function. Trail moves at a predetermined rate between two pre-calculated endpoints. This function is used to move an object back and forth along the slit in a spectrograph. Hand paddle guide while trailing is supported.

COSDEC COMMAND 18

TURN ON FUNCTION WHICH DIVIDES THE COMMANDED RA HAND PADDLE RATE BY THE COSINE OF THE DECLINATION. SPEED CLIPS AT SLEW SPEED

EXCOM SENDS	CHARACTERS	COMMENTS
	18 <CR>	COMMAND #
	0 <CR>	STATUS (OFF) (1 ON)
TCS RESPONDS	NO RESPONSE	CHANGES COSDEC STATUS BIT

(COSDEC): This command turns on a feature that divides commanded Right Ascension hand paddle rates by the cosine of the Declination so that the motion of the object in the eyepiece is constant.

RATECOR COMMAND 19

TURN ON TRACK RATE CORRECTION FUNCTION

EXCOM SENDS	CHARACTERS	COMMENTS
	19 <CR>	COMMAND #
	0 <CR>	STATUS (OFF) (1 ON)
TCS RESPONDS	NO RESPONSE	CHANGES CORRECTION STATUS BIT

(RATECOR): This command turns on the track rate correction feature of the control system. Rate corrections are calculated by differentiating the pointing model and these corrections may be automatically applied to the track rates.

DOME COMMAND 20

THE DOME ON-OFF FLAG INTERACTS WITH THE FRONT PANEL SWITCH.
IF THE SWITCH IS ON, THE COMMAND CAN TURN THE DOME ON OR OFF,
IF THE SWITCH IS OFF, THE DOME IS OFF AND THIS COMMAND IS IGNORED

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	20 <CR>	COMMAND #
	0 <CR>	STATUS (OFF)
		(1 ON)
TCS RESPONDS	NO RESPONSE	CHANGES DOME STATUS BIT

(DOME): This command is used to enable or disable dome function from the EXCOM.

GUIDER COMMAND 21

THIS IS A CONVENIENCE FOR SETTING THE DISPLAY ONLY.
THE GUIDER IS HARDWARE OR'D WITH THE HAND PADDLE.

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	21 <CR>	COMMAND #
	0 <CR>	STATUS (OFF)
		(1 ON)
TCS RESPONDS	NO RESPONSE	SETS DISPLAY MESSAGE

(GUIDER): This command is a convenience to the user to set the dome HOME/TRACK switch in the desired position from the EXCOM. A 1 will send the dome home; a 0 command the dome to track the telescope azimuth.

DOEPOCH COMMAND 22

SET THE DISPLAY EPOCH

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	22 <CR>	COMMAND #
	2000.0 <CR>	EPOCH
TCS RESPONDS	NO RESPONSE	CHANGES DISPLAY EPOCH

Set display epoch (EPOCH): The display epoch may be set to any value by the menu.

MARK COMMAND 23

STORE R.A., DEC. & EPOCH INTO THE MARK TABLE AT INDICATED POSITION

EXCOM SENDS	CHARACTERS	COMMENTS
	23 <CR>	COMMAND #
	1. <CR>	TABLE #
	21.000000 <CR>	RA
	12.000000 <CR>	DEC
	2000.0 <CR>	EPOCH
TCS RESPONDS	NO RESPONSE	MAKES ENTRY IN TABLE

Set table entries (MARK): The Set table entries command is used to set up a list of coordinates which may be slew destinations using the Select table entry (MOVE) command. An entry number and three ZERO's are sufficient to mark the present telescope location. There are 500 entries possible. The table is initialized to zeros.

COEFFICIENTS COMMAND 24

CHANGE TELESCOPE AND POINTING MODEL PARAMETERS FROM EXCOM

EXCOM SENDS	CHARACTERS	COMMENTS	UNITS
	24 <CR>	COMMAND #	
	120. <CR>	ME	(ARC SECONDS)
	35. <CR>	MA	(ARC SECONDS)
	10. <CR>	CH	(SECONDS OF TIME)
	3. <CR>	NP	(SECONDS OF TIME)
	.8 <CR>	TBAR	(NO UNITS 0-1)
	10. <CR>	TFLX	(ARC SECONDS)
	.000019673 <CR>	HARATIO	(HOURS / ENC. UNIT)
	.00027743 <CR>	DECRATIO	(DEG. / ENC. UNIT)
TCS RESPONDS	NO RESPONSE	TCS CHANGES THE VARIABLES	

Set model coefficients (COEFFICIENTS): This command is used for testing, or for updating the coefficients from the external computer.

COORDS COMMAND 25

RETURN TELESCOPE COORDINATES, TIME AND DATE TO THE EXCOM

EXCOM SENDS	CHARACTERS	COMMENTS	UNITS
<hr/>			
	25 <CR>	COMMAND #	
TCS RESPONDS		EIGHT REAL NUMBERS FOLLOWED BY CARRIAGE RETURNS	
	2.034567 <CR>	HA	
	20.234567 <CR>	RA	
	33.345674 <CR>	DEC	
	1994.5 <CR>	EPOCH	
	1.3456 <CR>	AIRMASS	
	22.034523 <CR>	SIDEREAL TIME	
	5.234153 <CR>	UNIVERSAL TIME	
	1994.82345 <CR>	YEAR	
	2054.1 <CR>	TELESCOPE FOCUS	
	167.2 <CR>	DOME POSITION	
	10.0 <CR>	INSTRUMENT ROTATOR POSITION	

COORDS: TCS sends the telescope coordinates out over the serial port to the external computer.

STAT COMMAND 26

EXCOM SENDS	CHARACTERS	COMMENTS	
<hr/>			
	26 <CR>	COMMAND #	
TCS RESPONDS	2345 <CR>	STATL	THREE STATUS INTEGERS
	0023 <CR>	STATH	
	1034 <CR>	STATLH	

STATUS: This command is like COORDS except it sends the three status bytes out over the serial port to the external computer.

Status Byte Assignments:

BYTE	BIT	DESCRIPTION
STATL	0	INITIALIZED
	1	GUIDE ON/OFF
	2	TRACK ON/OFF
	3	SLEW ENABLED
	4	DOME ON/OFF
	5	APPROACHING LIMIT
	6	FINAL LIMIT
	7	SLEWING
STATH	0	SETTING
	1	TRAILING
	2	EXCOM ON/OFF

	3	DOME OK
	4	TARGET OUT OF RANGE
	5	COSDEC ON/OFF
	6	RATE COR ON/OFF
	7	DRIVES ON/OFF
STATLH	0	SLEW COMPUTING
	1	DOME TRACK / FREE
	2	"N"
	3	"S"
	4	"E"
	5	"W"
	6	NEXT OBJECT ACTIVE
	7	AUX. TRACK RATE

AFOCUS COMMAND 27
SLEW TO FOCUS

EXCOM SENDS	CHARACTERS	COMMENTS
	27 <CR> 2000.0 <CR>	COMMAND # DESIRED FOCUS
TCS RESPONDS	NO RESPONSE	TCS SLEWS TO FOCUS

Move to Focus (AFOCUS): This command slews the focus ram to an encoded focus position.
(legal values are 1780 to 5270). The command may be terminated with Cancel: command 13.

POINT COMMAND 28
RETURN POINTING MODEL POSITION DATA TO THE EXCOM

EXCOM SENDS	CHARACTERS	COMMENTS
	28 <CR>	COMMAND #
TCS RESPONDS		FIVE REAL NUMBERS SEPARATED BY CARRIAGE RETURNS
	2.345678 <CR> 25.012345 <CR> 3.000000 <CR> 25.000000 <CR> 2.000000 <CR>	NEXT OBJECT RA NEXT OBJECT DEC TELESCOPE RA TELESCOPE DEC TELESCOPE HA

POINT: This command is intended for use by the external computer only. It returns the position of the telescope in the format used by the pointing model programs: NORA, NODEC, RA, DEC, HA.

ExitToWin **COMMAND 30**
EXIT TO WINDOWS

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	30 <CR>	COMMAND #
TCS RESPONDS		SHUTS DOWN TCS

POINT: This command is intended for use by the external computer only.

ESTOUEST **COMMAND 31**
SET EAST/WEST FLAG

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	31 <CR>	COMMAND #
TCS RESPONDS		IGNORED

POINT: This command can only be invoked manually with the TCS menus.

SPEED **COMMAND 32**
SET THE TELESCOPE SPEED

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	32 <CR>	COMMAND #
	1.25 <CR>	DESIRED SPEED BETWEEN 1.0 and 1.5
deg/sec		
TCS RESPONDS	NO RESPONSE	TCS SLEWS TO FOCUS

This command sets the telescope speed.

GET SPEED COMMAND 33

RETURN TELESCOPE SPEED

EXCOM SENDS	CHARACTERS	COMMENTS	UNITS
<hr/>			
	33 <CR>	COMMAND #	
TCS RESPONDS		1 REAL NUMBERS FOLLOWED BY CARRIAGE RETURN	
	1.25 <CR>	SPEED	

GET SPEED: TCS sends the telescope speed out over the serial port to the external computer.

HA DEC SLEW COMMAND 36

SETS UP AUTOMATIC SLEW TO HA,DEC
CHECKS DESTINATION COORDINATES FOR HORIZON
SETS NEXT OBJECT COORDINATES

TURN OFF TRACKING OR THIS COMMAND MAY NOT TERMINATE

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	36 <CR>	COMMAND #
	4 <CR> HA (HOURS)	
	10 <CR> DEC (DEGREES)	
TCS RESPONDS	NO RESPONSE	ENABLES SLEW TO RA, DEC

Set slew position (SLEW): This command prepares TCS to automatically slew the telescope to the coordinates specified. The EPOCH will be the display epoch if a ZERO is received. If the telescope is not tracking, the slew may never terminate because the Earth's rotation is faster than the final automatic guide speed. After the HA,DEC slew is ENABLED (status bit set) by COMMAND 36, a COMMAND 12 (GO) is required to initiate the slew. If the coordinates are below the telescope horizon, the TARGET OUT OF RANGE status bit will be set.

DOME OFFSET COMMAND 37

SETS UP DOME OFFSET

This command sends the dome home with an offset allowing the user to position the dome for flat fields or other purposes

EXCOM SENDS	CHARACTERS	COMMENTS
<hr/>		
	37 <CR>	COMMAND #
	45 <CR>	DOMES AZIMUTH
TCS RESPONDS	NO RESPONSE	SENDS DOME TO OFFSET POSITION

THE DOME MUST BE ON AND COMMANDED TO HOME FOR THIS COMMAND TO WORK.

Send Command Number COMMAND 38
RETURN TELESCOPE SPEED

EXCOM SENDS	CHARACTERS	COMMENTS	UNITS

	38 <CR>	COMMAND #	
TCS RESPONDS		1 REAL NUMBERS FOLLOWED BY CARRIAGE RETURN	
	0 <CR>	COMMAND Number	

Send Command Number: TCS returns the telescope command number out over the serial port to the external computer.

6.2 SERVO TUNEUP DOCUMENT

The servo motor controller board 073-16C has four trimpots at the top of the board. The silkscreen labels are B D G I. These are for Balance, Damping, Gain, and Integrator respectively. There is a large pushbutton switch near the center of the board which is the RESET button for the GALIL controller chip on the board.

The MDC motherboard has the eurocard connectors labeled RA and DEC for identification of the boards for an axis.

NOTE: It is important to not let the telescope run away while the servo-adjust procedure is being performed. It is probably a good idea to remove the motor timing belt at least for the initial setup. After the initial setup, replace the belt to add the inertia and damping of the entire structure to the servo-loop.

Attach an oscilloscope probe to the position error test point located at the top of the board beside the LED. Attach the ground lead to the GND test point. Set the scope at 2V/div. and 1ms/div. Switch ON the MDC and release the latching red HALT MOTORS button (STOP button on older systems).

First adjust the balance. With the RESET button depressed, observe the voltage on the test point and use the balance pot to get a zero offset. The motor shaft should remain in a fixed position. Additional adjustment of the balance pot may be required to achieve zero shaft rotation. Release the RESET button.

Next adjust the response of the servo loop. This is done by commanding a change in position with the servo test programs. The servo test programs are used to adjust the servo amplifier circuits. The servo test programs are run independently of TCS. The servo-test program commands a burst of motor steps at high frequency (to simulate a step position error) waits a few milliseconds, and commands an identical burst of motor steps in the opposite direction. The motion of the motor shaft resulting from the servo test program is an oscillation which allows a technician to observe the response of the servo with an oscilloscope.


The servo test program is named ServoTune.EXE and is in the TCS sub-directory. To run the test program double click the icon.

The program has buttons for the HA or DEC axes. The number of steps as well as the delay between steps may be changed dynamically.

The four figures show representative oscilloscope traces of a step forward and then back. Figure 1 shows the servo with low gain and damping. The response to the step input is slow and the overshoot is large. The system continues to ring until the step in the opposite direction occurs. Figure 2 shows the servo setup with too much gain and damping. There is no low frequency ringing and the response to the step input is very fast. Figure 3 shows a DC offset which may be removed with the integrator pot. The integrator pot should be increased. Figure 4 shows a normal servo with minimum gain and a reasonable amount of ringing with no offset.

Set the Oscilloscope to 1V/div. and 10ms/div.. Observe the trace and adjust the GAIN and DAMPING pots to achieve the best response with minimum GAIN. Too much GAIN will make the motors noisy (like stepper motors). If the GAIN is too low the motors may not respond; or run away. As the GAIN is increased, the magnitude of the response should equal about 1V. Increasing the DAMPING will reduce overshoot and stabilize the system response. After this is accomplished, adjust the INTEGRATOR pot to remove offsets.

After the HA axis is adjusted, select the DEC axis. Repeat the tuneup for the DEC axis.



Servo.doc




figure 1
GAIN too low
DAMPING too high
overflow LED
may come on




figure 2
GAIN too high
DAMPING too high
drives noisy




Figure 3
Adjust INTEGRATOR
to remove DC offset




Figure 4
Normal servo response
for a telescope

6.3 SOFTWARE LICENSE AGREEMENT

LICENSE AGREEMENT BETWEEN CUSTOMER AND DFM ENGINEERING, INC. FOR RIGHTS IN TECHNICAL DATA AND COMPUTER SOFTWARE

(A) DEFINITIONS

1. COMPUTER, as used in this agreement means a data processing device capable of accepting data, performing prescribed operations on the data, supplying the results of these operations, and/or performing control functions based upon commands supplied, or logical decisions made using input data or commands. For example, a 486 PC (Personal Computer) may be used for controlling a telescope.

2. COMPUTER DATA BASE, as used in this agreement means a collection of data in a form capable of being processed and operated on by a computer.

3. COMPUTER PROGRAM, as used in this agreement means a series of instructions, statements, procedures, etc. in a form acceptable to a computer, designed to cause the computer to execute an operation or operations. Computer programs include operating systems, assemblers, compilers, interpreters, data management systems, utility programs, sort-merge programs, real time control programs, etc. Computer programs may be either machine-dependent or machine-independent, and may be general purpose in nature or be designed to satisfy the requirements of a particular user.

4. COMPUTER SOFTWARE, as used in this agreement means computer programs, software, and/or computer data bases. This includes source code, binary code, memory images, or any intermediate form of the programs.

5. COMPUTER SOFTWARE DOCUMENTATION, as used in this agreement includes technical data, including computer listings and printouts, in human-readable or machine readable form which (a) documents the design or details of computer software, (b) explains the capabilities of the software, or (c) provides operating instructions for using the software to obtain desired results from the control system or computer.

6. TECHNICAL DATA, as used in this agreement means recorded information, regardless of form or method of recording.

7. DETAILED DESIGN DATA as used in this agreement means technical information or data that describes the physical or electrical configuration and performance characteristics of an item or component in sufficient detail to allow understanding of its function or to allow duplication of the item or component. Examples include, but are not limited to, drawings, CAD files, schematics, software listings, flow charts, etc.

8. LIMITED RIGHTS as used in this agreement means rights to use, duplicate, or disclose technical data, in whole or in part, by the customer or any of the customer's employees or staff with the express limitation that such technical data shall not, without written permission of DFM Engineering, Inc. , be: (i) released or disclosed to a third party, or (ii) used for any purpose except in conjunction with a DFM Engineering, Inc. product. Detailed design data (examples include, but are not limited to, mechanical and electrical drawings or schematics) shall not be used for manufacture or preparation of the same or similar devices.

9. RESTRICTED RIGHTS as used in this agreement means rights to use, duplicate, or disclose technical data in whole or in part by the customer without written permission of DFM Engineering, Inc. This data may be used, duplicated, or disclosed to a third party subject to the following express limitations: The data may be used, duplicated, or disclosed in whole or in part only in a human-readable form and at no cost to the third party.

(B) LICENSE TO CUSTOMER

The customer is granted LIMITED RIGHTS to the technical data and computer software. The software may be copied for safekeeping (archives) or backup purposes only. The software may be used with a backup computer only when the computer it was supplied for is non functional. The software may only be used at the original site that it was supplied for and may not be transported to another site even if the computer which it was supplied for is transported to another site. The software may not be used in whole or in part as a portion of another computer program. The detailed design data may not be used for manufacture or preparation of the same or a similar device.

The customer is granted RESTRICTED RIGHTS TO the computer data base containing the data for the library of objects as supplied by DFM Engineering, Inc. The customer may add to, change, or subtract from this data base as they deem necessary for efficient operation.

Acceptance of the technical data acknowledges the acceptance of this agreement in totality and customer agrees to pay all costs involved in prosecution required to enforce this agreement and to pay all damages to DFM Engineering Inc. for unauthorized use of the technical data. This agreement shall remain in effect until the year 2020 AD.

6.4 U Montreal 1.5M drive de-mesher adjustment.

The HA and Dec drives on this 1.5M B&C telescope have a “demesh” feature. The main drive mounting plate in each axis is able to move in response to increased torque loads between the primary worm and worm gear. When slew speed is commanded the main drive mounting plate automatically retracts slightly to allow more backlash between the primary worm and worm gear to lower the required motor torque. The main HA and Dec drive plates are actuated by a counterweighted lever arm with an oil damper on the outboard end.

To check the HA axis de-mesh:

- Make sure five or six 10-lb. counterweights are attached to the east end of the main HA drive plate.
- Attach a magnetic base and 0-1” dial indicator to the pier weldment. Set the indicator perpendicular to the main drive plate to measure the motion of the end of the drive plate, furthest from the drive plate main pivot.
- Climb inside the pier and become familiar with the counterweight lever arm, counterweight, and oil damper.
- Make sure there is oil in the damper.
- Gently pull the counterweight arm towards the oil damper to demesh the HA worm. Release the counterweight arm and, when the HA plate settles, have an assistant set the indicator dial to read zero. Repeat this step a few times to verify how repeatable the indicator zero position is.
- Move the counterweight as needed to exert the minimum force required to settle the HA plate at zero reliably. Excessive counterweight force will drastically increase the motor torque required for tracking. Too little counterweight force will not mesh the HA worm and gear completely.
- Have an assistant use the dynamometer to push down on the main drive plate directly below the center of the worm housing, perpendicular to the drive plate.
- Adjust the position of the counterweight to exert the minimum force required to settle the drive plate back to zero on the indicator after pulling on the counterweight lever arm. When everything is adjusted correctly the dial indicator should show the HA worm demeshing from the gear when about 20 lbs of force is applied, when the force is removed the indicator should return to within .001” of zero. The range of motion should be about .030”, when set up as noted above.

The Dec drive is adjusted similar to HA except the force required to demesh the worm is approximately 35 lbs.

Note: This test was performed at an ambient temperature of 55 deg F.