

LE STRUM QUICK REF V1.1

Preset Patch (Hold MODE Button)	Command (Hold MODE Button)	Toggle <i>Setting</i> (Hold MODE Button) Single blink OFF , Double blink ON
------------------------------------	-------------------------------	--

	C	C#	D	D#	E	F	F#	G	G#	A	A#	B
MAJ	Basic Strum Mode		Guitar Strum Mode		Guitar Sustain Mode	Organ Buttons Mode		Organ Buttons with Adds		Organ Buttons with Adds/Retrig		Load User Patch From EEPROM
MIN	Play Note On Contact Make	Play Note On Contact Break	Guitar Open Chord Voicing	Added Notes (Sus4/6/9)	Sustain Chord Until Next Chord	Chromatic Scale On Pads				Enable Organ Buttons On MIDI Ch 2	Sustain O/B Until Next Chord	Save User Patch To EEPROM
DOM7	Damp Note On Contact Make	Damp Note On Contact Break	Repeat Guitar Chord At +1 Octave	Map Guitar Chord Bass Notes	Common Notes Sustain On Change	Diatonic Scale On Pads	Pentatonic Scale On Pads				Common Notes Sustain On O/B	MIDI Panic (All Notes Off)
	C	C#	D	D#	E	F	F#	G	G#	A	A#	B

Special Chord Button Combinations

- MAJ + DOM7 = **Major Seventh Chord**
- MIN + DOM7 = **Minor Seventh Chord**
- MAJ + MIN = **Diminished Triad**
- MAJ + MIN + DOM7 = **Augmented Triad**

Added Notes (When enabled by Mode)

- Hold chord and press top row button to right = **Sus 4**
- Hold chord and press middle row button to right = **Add 6**
- Hold chord and press bottom row button to right = **Add 2/9**

- Hold MODE and touch a pad with the stylus to set **MIDI velocity**
- Hold MODE at startup to view **firmware version**. LED flashes major version digit, short blink, minor version digit, short blink
- Strum output on MIDI channel 1 at controllable velocity
- Organ button output on MIDI channel 2 at full velocity

LE STRUM QUICK REF V1.1

Preset Patch (Hold MODE Button)	Command (Hold MODE Button)	Toggle <i>Setting</i> (Hold MODE Button) Single blink OFF , Double blink ON
------------------------------------	-------------------------------	--

	C	C#	D	D#	E	F	F#	G	G#	A	A#	B
MAJ	Basic Strum Mode		Guitar Strum Mode		Guitar Sustain Mode	Organ Buttons Mode		Organ Buttons with Adds		Organ Buttons with Adds/Retrig		Load User Patch From EEPROM
MIN	Play Note On Contact Make	Play Note On Contact Break	Guitar Open Chord Voicing	Added Notes (Sus4/6/9)	Sustain Chord Until Next Chord	Chromatic Scale On Pads				Enable Organ Buttons On MIDI Ch 2	Sustain O/B Until Next Chord	Save User Patch To EEPROM
DOM7	Damp Note On Contact Make	Damp Note On Contact Break	Repeat Guitar Chord At +1 Octave	Map Guitar Chord Bass Notes	Common Notes Sustain On Change	Diatonic Scale On Pads	Pentatonic Scale On Pads				Common Notes Sustain On O/B	MIDI Panic (All Notes Off)
	C	C#	D	D#	E	F	F#	G	G#	A	A#	B

Special Chord Button Combinations

- MAJ + DOM7 = **Major Seventh Chord**
- MIN + DOM7 = **Minor Seventh Chord**
- MAJ + MIN = **Diminished Triad**
- MAJ + MIN + DOM7 = **Augmented Triad**

Added Notes (When enabled by Mode)

- Hold chord and press top row button to right = **Sus 4**
- Hold chord and press middle row button to right = **Add 6**
- Hold chord and press bottom row button to right = **Add 2/9**

- Hold MODE and touch a pad with the stylus to set **MIDI velocity**
- Hold MODE at startup to view **firmware version**. LED flashes major version digit, short blink, minor version digit, short blink
- Strum output on MIDI channel 1 at controllable velocity
- Organ button output on MIDI channel 2 at full velocity