

## LE STRUM QUICK REF V1.2

**Preset Patch**  
(Hold MODE Button)

**Command**  
(Hold MODE Button)

Toggle *Setting* (Hold MODE Button)  
Single blink **OFF**, Double blink **ON**

	C	C#	D	D#	E	F	F#	G	G#	A	A#	B
<b>MAJ</b>	Basic Strum Mode		Guitar Strum Mode		Guitar Sustain Mode	Organ Buttons Mode		Organ Buttons with Adds		Organ Buttons with Adds/Retrig	Toggle Strum Direction	Load User Patch From EEPROM
<b>MIN</b>	Play Note On Contact Make	Play Note On Contact Break	Guitar Open Chord Voicing	Added Notes (Sus4/6/9)	Sustain Chord Until Next Chord	Chromatic Scale On Pads				Enable Organ Buttons On MIDI Ch 2	Sustain O/B Until Next Chord	Save User Patch To EEPROM
<b>DOM7</b>	Damp Note On Contact Make	Damp Note On Contact Break	Repeat Guitar Chord At +1 Octave	Map Guitar Chord Bass Notes	Common Notes Sustain On Change	Diatonic Scale On Pads	Pentatonic Scale On Pads				Common Notes Sustain On O/B	MIDI Panic (All Notes Off)
	C	C#	D	D#	E	F	F#	G	G#	A	A#	B

### Special Chord Button Combinations

- MAJ + DOM7 = **Major Seventh** Chord
- MIN + DOM7 = **Minor Seventh** Chord
- MAJ + MIN = **Diminished** Triad
- MAJ + MIN + DOM7 = **Augmented** Triad

### Added Notes (When enabled by Mode)

- Hold chord and press top row button to right = **Sus 4**
- Hold chord and press middle row button to right = **Add 6**
- Hold chord and press bottom row button to right = **Add 2/9**

- Hold MODE and touch a pad with the stylus to set **MIDI velocity**
- Hold MODE at startup to view **firmware version**. LED flashes major version digit, short blink, minor version digit, short blink
- Strum output on MIDI channel 1 at controllable velocity
- Organ button output on MIDI channel 2 at full velocity

## LE STRUM QUICK REF V1.2

**Preset Patch**  
(Hold MODE Button)

**Command**  
(Hold MODE Button)

Toggle *Setting* (Hold MODE Button)  
Single blink **OFF**, Double blink **ON**

	C	C#	D	D#	E	F	F#	G	G#	A	A#	B
<b>MAJ</b>	Basic Strum Mode		Guitar Strum Mode		Guitar Sustain Mode	Organ Buttons Mode		Organ Buttons with Adds		Organ Buttons with Adds/Retrig	Toggle Strum Direction	Load User Patch From EEPROM
<b>MIN</b>	Play Note On Contact Make	Play Note On Contact Break	Guitar Open Chord Voicing	Added Notes (Sus4/6/9)	Sustain Chord Until Next Chord	Chromatic Scale On Pads				Enable Organ Buttons On MIDI Ch 2	Sustain O/B Until Next Chord	Save User Patch To EEPROM
<b>DOM7</b>	Damp Note On Contact Make	Damp Note On Contact Break	Repeat Guitar Chord At +1 Octave	Map Guitar Chord Bass Notes	Common Notes Sustain On Change	Diatonic Scale On Pads	Pentatonic Scale On Pads				Common Notes Sustain On O/B	MIDI Panic (All Notes Off)
	C	C#	D	D#	E	F	F#	G	G#	A	A#	B

### Special Chord Button Combinations

- MAJ + DOM7 = **Major Seventh** Chord
- MIN + DOM7 = **Minor Seventh** Chord
- MAJ + MIN = **Diminished** Triad
- MAJ + MIN + DOM7 = **Augmented** Triad

### Added Notes (When enabled by Mode)

- Hold chord and press top row button to right = **Sus 4**
- Hold chord and press middle row button to right = **Add 6**
- Hold chord and press bottom row button to right = **Add 2/9**

- Hold MODE and touch a pad with the stylus to set **MIDI velocity**
- Hold MODE at startup to view **firmware version**. LED flashes major version digit, short blink, minor version digit, short blink
- Strum output on MIDI channel 1 at controllable velocity
- Organ button output on MIDI channel 2 at full velocity