

Group 26

User instructions:

1. Enter an angle value in degrees in the serial monitor, between 15 and -15 degrees, at which you want the pendulum to stabilize.
2. Move the pendulum within ± 45 degrees of the selected value.
3. See the pendulum settles on the selected value.