

## 1. Module Interface Details


TarangMini module has 18-pin (3 X 6) 2mm pitch **Castellated Pads / Through- Hole Pins** distributed in three rows at the module edges. This connector / pads are used for interfacing the module with a microcontroller / RS232 level converter / USB to serial base board



Top View



Bottom View




## 2. Pin Definition


Pin	Name	Type	Function
1	VCC	P	Module Power Supply (3.3V to 3.6V)
2	DOUT	O	Serial data output from TarangMini
3	DIN	I	Serial data input to TarangMini
4	BOOT	I	H- Firmware update; L- Normal operation
5	RESET	I	Reset module (Active Low)
6	GND		Ground
7	NC		Reserved
8	NC		Reserved
9	NC		Reserved
10	NC		Reserved
11	NC		Reserved
12	NC		Reserved
13	NC		Reserved
14	NC		Reserved
15	NC		Reserved
16	NC		Reserved
17	NC		Reserved
18	NC		Reserved

## 3. Technical specification

Specification	TarangMini Module
Supply Voltage	3.3 to 3.6V
Operating Frequency	865 – 867 MHz
Current Draw, Receive	< 25 mA
Current Draw, Transmit	< 130 mA @ 19 dBm
Deep Sleep Current	Less than 10 uA
Maximum RF Output Power	+19 dBm
Serial Baud Rate (UART)	1200 - 115200
Operating Temperature	-10 to 70 degree c
Antenna Options	Spring / External
PCB Dimension (mm)	25 (L) x 22.5 (W) x 2.5 (H)







TarangMini Demo Board

## 10. Testing and Configuration

TarangMini SM20LR03 modules can be configured, tested and programmed using any standard serial port terminal software and a Tarang Interface board.

### a. Software pre-requisites

Download the TMFT software for Windows, available from <http://melangesystems.com/tmft/tmft.rar>

Download the Docklight Software from Windows, available from <http://docklight.de/downloads/>

Download the FTDI Driver for Windows

### b. Bringing module to configuration mode

The TarangMini SM20LR03 can be configured using AT commands via the TMFT terminal interface or any terminal program.

- Download and install TMFT / any other terminal software
- Connect the Tarang Interface board with the module to the PC
- Start TMFT software. Available COM ports must be listed in the “COM Port Setup” pane. Select the interfaced COM port
- If the module is a standard non customized one, the parameters will default to Baud Rate-9600, Data bits-8, Parity-None, Stop bits-1, Hand shake-None
- Go to Tools Window tab- Click on Terminal
- Type “+++” ( Without LF and CR)
- A functional module must respond with “OK” within 2seconds
- Now the module is ready to be configured and accepts further commands

## 11. AT Commands

AT Command	Description	Parameter and Range	Default	Example
<b>ATGRD</b>	Restore Defaults: Module is Configured to Factory settings	-		-
<b>ATGWR</b>	Write: Stores the set parameters to memory	-		-
<b>ATGEX</b>	Exit from AT command mode	-		Provides "EXIT" as response
<b>ATNMY</b>	8-bit Source Address: Set/Read the RF module 8-bit source address.	0 – 0xFFFF	0X1000	ATNMY1001
<b>ATNDA</b>	8-bit Destination Address: Set/Read the RF module 8-bit destination address.	0 – 0xFFFF	0X1000	ATNDA2000
<b>ATNPI</b>	8-bit PAN ID: Set/Read the PAN (Personal Area Network) ID	0 – 0xFFFF	0X1000	ATNPI3000
<b>ATSBD</b>	Interface data rate: Read / Set the serial interface data rate for communications between the RF module serial port and host.	[0-7] 0 - 1200 1 - 2400 2 – 4800 . . 7 - 115200	3 - 9600	ATSBD01
<b>ATNCH</b>	Set/Read the frequency channel	[0-9] 0. 865.1Mhz 1. 865.3Mhz . . 9. 866.9Mhz	0	ATNCH00
<b>ATVFW</b>	Read firmware version	-	-	-