

V40 项目

uboot 调试说明书 V1.0

文档履历

[illegible]

目 录

V40 项目	1
uboot 调试说明书 V1.0	1
目 录	2
1. 概述	3
1.1. 编写目的	3
1.2. 适用范围	3
1.3. 相关人员	3
2. Uboot FDT 命令说明	4
2.1. FDT	4
3. 查询配置	6
3.1. 第一步：在根目录下查找	6
3.2. 第二步：在 soc 目录下找	7
3.3. 使用路径别名查找	8
4. 修改配置	10
4.1. 修改整数配置	10
4.2. 修改字符串配置	10
5. GPIO 或者 PIN 配置特殊说明	12
5.1. port 接口对应的数字编号说明	12
5.2. Sysconfig 中描述 gpio 的形式	12
5.3. Pin 配置说明：	12
5.3.1. 查看 PIN 配置	12
5.3.2. 修改 PIN 配置	13
5.4. GPIO 配置说明	13
5.4.1. Device tree 和 sysconfig.fex 中 GPIO 对应关系	14
5.4.2. 修改 GPIO 配置	14
6. 保存配置	15
Declaration	16

1. 概述

1.1. 编写目的

介绍 uboot 中，在控制台修改 device tree 配置的方法，为 uboot 和内核的使用者提供参考。

1.2. 适用范围

适用于 allwinnertech V40 平台。

1.3. 相关人员

uboot 开发/维护人员，内核开发人员。（需要对 device tree 有一定的了解）

2. Uboot FDT 命令说明

2. 1. FDT

FDT : flattened device tree 的缩写

在 UBOOT 控制台停下后，输入 fdt，可以查看 fdt 命令帮助

```
sunxi#fdt
```

```
fdt - flattened device tree utility commands
```

```
Usage:
```

```
fdt addr [-c] <addr> [<length>] - Set the [control] fdt location to <addr>
```

```
fdt move <fdt> <newaddr> <length> - Copy the fdt to <addr> and make it active
```

```
fdt resize - Resize fdt to size + padding to 4k addr
```

```
fdt print <path> [<prop>] - Recursive print starting at <path>
```

```
fdt list <path> [<prop>] - Print one level starting at <path>
```

```
fdt get value <var> <path> <prop> - Get <property> and store in <var>
```

```
fdt get name <var> <path> <index> - Get name of node <index> and store in <var>
```

```
fdt get addr <var> <path> <prop> - Get start address of <property> and store in <var>
```

```
fdt get size <var> <path> [<prop>] - Get size of [<property>] or num nodes and store in <var>
```

```
fdt set <path> <prop> [<val>] - Set <property> [to <val>]
```

```
fdt mknode <path> <node> - Create a new node after <path>
```

```
fdt rm <path> [<prop>] - Delete the node or <property>
```

```
fdt header - Display header info
```

```
fdt bootcpu <id> - Set boot cpuid
```

```
fdt memory <addr> <size> - Add/Update memory node
```

```
fdt rsvmem print - Show current mem reserves
```

```
fdt rsvmem add <addr> <size> - Add a mem reserve
```

```
fdt rsvmem delete <index> - Delete a mem reserves
```

```
fdt chosen [<start> <end>] - Add/update the /chosen branch in the tree
```

```
<start>/<end> - initrd start/end addr
```

```
fdt save - write fdt to flash
```

NOTE: Dereference aliases by omitting the leading '/', e.g. fdt print ethernet0.

```
sunxi#
```

注：

其中常用的命令就是 fdt list 和 fdt set

Fdt list 用来查询节点配置

Fdt set 用来修改节点配置

3. 查询配置

首先确定要查询的字段在 device tree 的路径，如果不知道路径，则需要用 fdt 命令查询：

3.1. 第一步：在根目录下查找

```
sunxi#fdt list /
/ {
    model = "sun8iw11p1";
    compatible = "arm,sun8iw11p1", "arm,sun8iw11p1";
    interrupt-parent = <0x00000001>;
    #address-cells = <0x00000002>;
    #size-cells = <0x00000002>;
    .....
    cpuscfg {
    };
    ion {
    };
    dram {
    };
    memory@40000000 {
    };
    interrupt-controller@1c81000 {
    };
    sunxi-chipid@1c14200 {
    };
    timer {
    };
    pmu {
    };
    dvfs_table {
    };
    dramfreq {
    };
    gpu@0x01c40000 {
    };
    wlan {
```

```

};

bt {

};

btlpm {

};

};

```

如果找到需要的配置，比如 wlan 的配置，运行如下命令即可

```
sunxi#fdt list /wlan //注意路径中的 /
```

```

wlan {

    compatible = "allwinner,sunxi-wlan";
    clocks = <0x00000096>;
    wlan_power = "vcc-wifi";
    wlan_io_regulator = "vcc-wifi-io";
    wlan_busnum = <0x00000001>;
    status = "okay";
    device_type = "wlan";
    wlan_regon = <0x00000077 0x0000000b 0x00000002 0x00000001 0xffffffff 0xffffffff
0x00000000>;
    wlan_hostwake = <0x00000077 0x0000000b 0x00000003 0x00000006 0xffffffff 0xffffffff
0x00000000>;
};

```

3.2. 第二步： 在 soc 目录下找

如果在第一步中没有发现要找的配置，比如 nand0 的配置，则该配置可能在 soc 目录下

```
sunxi#fdt list /soc
```

```

soc@01c00000 {

    compatible = "simple-bus";
    #address-cells = <0x00000002>;
    #size-cells = <0x00000002>;
    ranges;
    device_type = "soc";
    .....
    hdmi@01ee0000 {
    };
    tr@01000000 {
    };
    pwm@01c21400 {

```



```

};
nand0@01c03000 {
};
thermal_sensor {
};
cpu_budget_cool {
};
.....
};

```

然后用如下命令显示即可:

```
sunxi#fdt list /soc/nand0
```

```

nand0@01c03000 {
    compatible = "allwinner,sun50i-nand";
    device_type = "nand0";
    reg = <0x00000000 0x01c03000 0x00000000 0x00001000>;
    interrupts = <0x00000000 0x00000046 0x00000004>;
    clocks = <0x00000004 0x0000007e>;
    pinctrl-names = "default", "sleep";
    pinctrl-1 = <0x00000081>;
    nand0_regulator1 = "vcc-nand";
    nand0_regulator2 = "none";
    nand0_cache_level = <0x55aaaa55>;
    nand0_flush_cache_num = <0x55aaaa55>;
    nand0_capacity_level = <0x55aaaa55>;
    nand0_id_number_ctl = <0x55aaaa55>;
    nand0_print_level = <0x55aaaa55>;
    nand0_p0 = <0x55aaaa55>;
    nand0_p1 = <0x55aaaa55>;
    nand0_p2 = <0x55aaaa55>;
    nand0_p3 = <0x55aaaa55>;
    status = "disabled";
    nand0_support_2ch = <0x00000000>;
    pinctrl-0 = <0x000000a9 0x000000aa>;
};

```

3. 3. 使用路径别名查找

别名是 device tree 中完整路径的一个简写, 有一个专门的节点(/aliases)来表示别名的相关信息,用如下命令可以查看系统中别名的配置情况:

```
sunxi#fdt list /aliases
```

```
aliases {
    serial0 = "/soc@01c00000/uart@01c28000";
    .....
    mmc0 = "/soc@01c00000/sdmmc@01c0f000";
    mmc2 = "/soc@01c00000/sdmmc@01c11000";
    nand0 = "/soc@01c00000/nand0@01c03000";
    disp = "/soc@01c00000/disp@01000000";
    lcd0 = "/soc@01c00000/lcd0@01c0c000";
    hdmi = "/soc@01c00000/hdmi@01ee0000";
    pwm = "/soc@01c00000/pwm@01c21400";
    boot_disp = "/soc@01c00000/boot_disp";
};
```

```
sunxi#
```

由于配置了 nand0 节点的路径别名, 因此可以用如下命令来显示 nand0 的配置信息

```
sunxi#fdt list nand0
```

```
nand0@01c03000 {
    compatible = "allwinner,sun50i-nand";
    device_type = "nand0";
    reg = <0x00000000 0x01c03000 0x00000000 0x00001000>;
    .....
    pinctrl-names = "default", "sleep";
    pinctrl-1 = <0x00000081>;
};
```

注: 在 fdt 的所有命令中, 别名可用 path 字段

```
fdt list    <path> [<prop>]          - Print one level starting at <path>
```

```
fdt set    <path> <prop> [<val>]    - Set <property> [to <val>]
```

4. 修改配置

4.1. 修改整数配置

命令格式: `fdt set path prop <xxx>`

示例: `fdt set /wlan wlan_busnum <0x2>`

`sunxi#fdt list /wlan`

```
wlan {
    compatible = "allwinner,sunxi-wlan";
    clocks = <0x00000096>;
    wlan_power = "vcc-wifi";
    wlan_io_regulator = "vcc-wifi-io";
    wlan_busnum = <0x00000001>;
    status = "disable";
    device_type = "wlan";
};
```

`sunxi#fdt set /wlan wlan_busnum <0x2>`

`sunxi#fdt list /wlan`

```
wlan {
    compatible = "allwinner,sunxi-wlan";
    clocks = <0x00000096>;
    wlan_power = "vcc-wifi";
    wlan_io_regulator = "vcc-wifi-io";
    wlan_busnum = <0x00000002>;    //修改后
    status = "disable";
    device_type = "wlan";
};
```

注：修改整数时，根据需要也可配置为数组形式，需要用空格来分隔

命令格式: `fdt set path prop <0x1 0x2 0x3>`

4.2. 修改字符串配置

命令格式: `fdt set path prop "xxxxxx"`

示例: `fdt set /wlan status "disable"`

`sunxi#fdt list /wlan`

```
wlan {
    compatible = "allwinner,sunxi-wlan";
    clocks = <0x00000096>;
    wlan_power = "vcc-wifi";
    wlan_io_regulator = "vcc-wifi-io";
    wlan_busnum = <0x00000001>;
    status = "okay";
    device_type = "wlan";
};
```

```
};  
sunxi#fdt set /wlan status "disable"  
sunxi#fdt list /wlan  
wlan {  
    compatible = "allwinner,sunxi-wlan";  
    clocks = <0x00000096>;  
    wlan_power = "vcc-wifi";  
    wlan_io_regulator = "vcc-wifi-io";  
    wlan_busnum = <0x00000001>;  
    status = "disable";           //修改后  
    device_type = "wlan";  
};  
sunxi#
```

注：修改字符串时，根据需要也可配置为数组形式，需要用空格来分隔

命令格式：fdt set path prop "string1" "string2"

5. GPIO 或者 PIN 配置特殊说明

5.1. port 接口对应的数字编号说明

```
#define PA 0
#define PB 1
#define PC 2
#define PD 3
#define PE 4
#define PF 5
#define PG 6
#define PH 7
#define PI 8
#define PJ 9
#define PK 10
#define PL 11
#define PM 12
#define PN 13
#define PO 14
#define PP 15
#define default 0xffffffff
```

5.2. Sysconfig 中描述 gpio 的形式

Sysconfig 中描述 gpio 的形式:

Port:端口+组内序号<功能分配><内部电阻状态><驱动能力><输出电平状态>

5.3. Pin 配置说明:

Pinctrl 节点为 cpux, 对应的节点路径如下:

Cpux : /soc/pinctrl@01c20800

5.3.1. 查看 PIN 配置

5.3.1.1. PIN 配置属性字段说明

<allwinner,function>对应于 sysconfig 中的主键名

<allwinner,pins>对应于 sysconfig 中每个 gpio 配置中的端口名.

<allwinner,pname>对应于 sysconfig 中主键下面子键名字

<allwinner,muxsel>, <allwinner,pull>, <allwinner,drive>, <allwinner,data>这些属性分别表示<功能分配><内部电阻状态><驱动能力><输出电平状态>, 其中值为 0xffffffff 表示使用默认值。

5.3.1.2. 查看 cpux 的 PIN 配置

```
sunxi#fdt list /soc/pinctrl@01c20800/lcd0
lcd0@0 {
    linux,phandle = <0x000000ab>;
    phandle = <0x000000ab>;
    allwinner,pins = "PD12", "PD13", "PD14", "PD15", "PD16", "PD17", "PD18", "PD19", "PD20",
"PD21";
    allwinner,function = "lcd0";
    allwinner,pname = "lcdd0", "lcdd1", "lcdd2", "lcdd3", "lcdd4", "lcdd5", "lcdd6", "lcdd7", "lcdd8",
"lcdd9";
    allwinner,muxsel = <0x00000003>;
    allwinner,pull = <0x00000000>;
    allwinner,drive = <0xffffffff>;
    allwinner,data = <0xffffffff>;
};
sunxi#
```

5.3.2. 修改 PIN 配置

使用 fdt set 命令可以修改 PIN 中相关属性字段

```
sunxi#fdt set /soc/pinctrl@01c20800/lcd0 allwinner,drive <0x1>
```

```
sunxi#fdt list /soc/pinctrl@01c20800/lcd0
```

```
lcd0@0 {
    linux,phandle = <0x000000ab>;
    phandle = <0x000000ab>;
    allwinner,pins = "PD12", "PD13", "PD14", "PD15", "PD16", "PD17", "PD18", "PD19", "PD20",
"PD21";
    allwinner,function = "lcd0";
    allwinner,pname = "lcdd0", "lcdd1", "lcdd2", "lcdd3", "lcdd4", "lcdd5", "lcdd6", "lcdd7", "lcdd8",
"lcdd9";
    allwinner,muxsel = <0x00000003>;
    allwinner,pull = <0x00000000>;
    allwinner,drive = <0x00000001>;
    allwinner,data = <0xffffffff>;
};
```

注意：示例中该处修改会影响 allwinner,pins 表示的所有端口的驱动能力配置，修改 muxsel pull data 的值也会产生类似效果。

5. 4. GPIO 配置说明

5.4.1. Device tree 和 sysconfig.fex 中 GPIO 对应关系

以 usb 中 usb_id_gpio 为例

```
sunxi#fdt list /soc/usb0
```

```
usb0@0 {
```

```
    test = <0x00000002 0x00000003 0x12345678>;
```

```
    device_type = "usb0";
```

```
    compatible = "allwinner,sun50i-otg-manager";
```

```
    .....
```

```
    usb_serial_unique = <0x00000000>;
```

```
    usb_serial_number = "20080411";
```

```
    rndis_wceis = <0x00000001>;
```

```
    status = "okay";
```

```
    usb_id_gpio = <0x00000030 0x00000007 0x00000009 0x00000000 0x00000001 0xffffffff
0xffffffff>;
};
```

```
usb_id_gpio = port:PH09<0><1><default><default>
```

对应于 device tree 中

```
usb_id_gpio = <0x00000030 0x00000007 0x00000009 0x00000000 0x00000001 0xffffffff 0xffffffff>
```

由 5.1 节描述，端口 PH 组内序号 功能分配 内部电阻状态 驱动能力 输出电平
其中首个 0x00000030 是 device tree 内部一个节点相关信息，这里可以略过。

5.4.2. 修改 GPIO 配置

如果需要修改 usb_id_gpio 的配置，可按如下方式（示例修改了驱动能力，输出电平两项）：

```
sunxi#fdt set /soc/usb0 usb_id_gpio <0x00000030 0x00000007 0x00000009 0x00000000 0x00000001 0x2
0x1>
```

```
sunxi#fdt list
```

```
usb0@0 {
```

```
    test = <0x00000002 0x00000003 0x12345678>;
```

```
    device_type = "usb0";
```

```
    compatible = "allwinner,sun50i-otg-manager";
```

```
    .....
```

```
    usb_serial_unique = <0x00000000>;
```

```
    usb_serial_number = "20080411";
```

```
    rndis_wceis = <0x00000001>;
```

```
    status = "okay";
```

```
    usb_id_gpio = <0x00000030 0x00000007 0x00000009 0x00000000 0x00000001 0x00000002
0x00000001>; //修改 ok
```

```
};
```

```
sunxi#
```

6. 保存配置

命令格式: `fdt save`

作用: 保存配置到存储介质上, 掉电不会丢失。

运行该命令后, 可以接着运行 `reset` 命令重启系统, 然后用 `fdt` 查询命令看所修改的内容是否已永久生效。

说明: 如果修改的内容只需要当次启动有效, 则不需要运行该命令保存配置

Declaration

This document is the original work and copyrighted property of Allwinner Technology (“Allwinner”). Reproduction in whole or in part must obtain the written approval of Allwinner and give clear acknowledgement to the copyright owner.

The information furnished by Allwinner is believed to be accurate and reliable. Allwinner reserves the right to make changes in circuit design and/or specifications at any time without notice. Allwinner does not assume any responsibility and liability for its use. Nor for any infringements of patents or other rights of the third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of Allwinner. This datasheet neither states nor implies warranty of any kind, including fitness for any particular application.