

BCN3D

+

Dual extruder

user manual

INDEX

1. PRIOR INFORMATION	3
Specifications	3
FFF Technology	4
Compliance	5
Safety	6
2. SETTING UP	8
Unboxing	8
Tools and accessories	9
BCN3D+ Paste Extruder diagram	10
3. STARTUP PROCESS	12
Hotbed height calibration	12
Calibrating relative distance	13
Loading filament	17
Working with your BCN3D+	18
4. LCD CONTROL	18
Home screen	18
Home menu	20
5. STL FILES	22
Obtaining STL files	22
Editing and repairing an STL file	23
Netfabb interface	24
Repairment	25
Orientation and move home	26
G-CODE generation	26
Slic3r configuration	27
Slic3r first steps	27
Slic3r use with a Dual extruder	30
Notes and usage tips	30
Cura use with a Dual extruder	30
6. PRINTING FROM USB AND SD CARDS	32
Printing with one extruder	33
What configuration to use?	33
Available printing surface	33
7. FILAMENTS	34
PLA, ABS y Nylon	34
HIPS, PVA, Laybrick, Laywood y Filaflex	35
8. FIRMWARE	36
What is it and when to update it?	36
When it is necessary to update the firmware?	36
Downloading Arduino's IDE	36
9. TROUBLESHOOTING	38
10. PRINT QUALITY DIAGNOSTICS	41
11. MAINTENANCE	44
12. TIPS AND TRICKS	47
13. TECHNICAL SUPPORT AND CUSTOMER SERVICE	48
14. GLOSARY	48
15. WARRANTY, REFUNDS AND REPLACEMENT POLICY	50
16. TERMS OF SERVICE	50

1. PRIOR INFORMATION


Specifications

Print Technology: Physical Dimensions: Weight:	Extrusion Fused Filament Fabrication (FFF) 480mm x 480mm x 455mm 13 kg (without spool)
Printing Volume:	Length: 252mm Width: 200mm Height: 200mm
Number of extruders:	2
Layer height:	0,1-0,35mm (with standard 0,4mm nozzle) 0,2-0,5mm (with 0,6mm nozzle)
Positioning resolution:	X axis: 0,05mm Y axis: 0,05mm Z axis: 0,1mm
Working temperature: Max. Hot bed temperature: Max. extruder temperature: Filament diameter:	15-35°C 80°C (measured on the perimeter) 260°C 3mm/1,75mm
Compatible materials:	PLA
Electronics:	Arduino Mega 2560 + RAMPS 1.4
Connectivity:	SD Card (autonomous operation) USB Cable (controlled through Repetier Host)
Firmware: Compatible files: Code converter software: AC Input: Power requirements	BCN3D+ specific (based on Marlin) STL Slic3r, Cura AC 100-240 V, ~4 amps, 50-60 Hz 200W

FFF Technology

BCN3D+ is a 3D printer based on fused filament fabrication additive manufacturing technology, consisting of the deposition of melted material layer by layer based on a previously divided digital model.

The head makes the necessary movements to deposit a layer of material, then a slight vertical movement to continue with the next layer. The process is repeated until the full object is completed.



The printer is ready to accept any add-on produced by RepRapBCN through an easy and step-by-step process. One of its main features is interchangeable extruder heads, either for using multiple heads at the same time or extruders designed for several other textures and materials.

Compliance

Fundació Privada Centre Cim hereby states that BCN3D+ complies with the essential requirements and other relevant provisions of the following Directives:



Low Tension Directive 2006/95/CE
Directive on machinery 2006/42/CE
Directive RoHS2011/65/UE

Safety

To avoid possible residual risks for the user , please read carefully the following safety measures.

REPRAPBCN IS EXEMPTED OF ANY LIABILITY IF THE USER DOES NOT FOLLOW THE FOLLOWING HANDLING INSTRUCTIONS:

- Very important. Like with any other appliance, do not touch the terminals of the cables connected to the main. The voltage is 230V and there is a risk of electrocution. Other cables from the machine working at 12V and present no risk.
- This machine produces and emits radio frequencies during use. It is important to install and use the equipment according to the instructions in this manual to avoid harmful interference to domestic appliances such as television or radio. If the machine causes interference, increase the separation between it and other appliances.
- Print materials are not innocuous and may emit toxic fumes. Always print in open or vented spaces.
- Do not breathe closer to 25cm from the extruder head or heads when printing.
- Do not place any object or body part between the moving parts of the machine when functioning.
- Do not touch its hot parts (hotbed and hotend) when the machine is turned on, or within 15 minutes of operation.
- Do not connect or disconnect any device and/or electrical connector when the machine is on.
- Oversee proper function of the machine during operation.
- In case of an emergency, stop the machine using the STOP button and unplug.

Safety warnings

The following signs have been arranged on the printer to warn users about areas of potential risk arising from its use or possible actions that are not recommended.



Hot surface danger



Moving parts, danger of crushing.



Hot Surface, allow it to cool down before handling.



Moving parts, danger of crushing, disconnect before handling



2. SETTING UP YOUR BCN3D+ DUAL EXTRUDER

Unboxing

The BCN3D+ is delivered inside a properly secured cardboard box, measuring 600mm long, 570mm wide and 590mm high. To properly unbox BCN3D+ the following steps must be followed:

1. Remove the packing tape and open the box.
2. Remove the upper cardbox cover. The assembled printer and an accessories box are fixed to the corrugated board inside.
3. Cut the cables ties fixing the accessories box and remove.
4. Carefully remove the protective cardboard from the sides.
5. Grab the upper frame and lift the printer out of the box.
6. Cut the zip ties attaching the lower cover to the machine.
7. Once out of the box, cut the zip ties holding the axes in place:
 - Ties holding the extruder carriage
 - Ties holding the hotbed
 - Ties holding the Z axis in its upper position
8. Open the accessories box, comprising:



▪ Hotbed glass	▪ SD Card
▪ Power cable	▪ 1 Kg Spool
▪ 3DLAC	▪ Frog + Calibration cube
▪ Tools	▪ USB containing full documentation
9. Unwrap the hotbed glass and use the included clamps to fix it onto the hotbed.
10. Plug the printer in using the included power cable
11. Remove the toolkit and the fixing spray and leave them close to the machine, as they will be needed.
12. Fit the supplied spool onto the holder mounted on top of the printer
13. The machine is ready to load the spool filament and the necessary files to print.




Tools and accessories

The BCN3D+ comes with a kit containing with every tool necessary to build the printer from scratch included. It also includes a fixing spray specially designed for 3d printing.

Kit consists in





BCN3D+ Paste Extruder Diagram

Perspective

- 1. LCD Screen
- 2. SD Card Slot
- 3. USB Connector
- 4. Hotbed
- 5. Hotend (Extruder)
- 6. X axis guides
- 7. Threaded rod and Z axis guides

- 8. Y axis linear guides
- 9. Mechanical endstops
- 10. Stepper motors
- 11. Outlet
- 12. ON/OFF button
- 13. Power supply
- 14. Spool holder


Left view*Front view*

Extruder (Hotend)


- 1. Heatsink
- 2. Heat break
- 3. Heatblock
- 4. Nozzle

Head

- 5. Idler
- 6. Tightening screws
- 7. Layer fan
- 8. Hotend fan
- 9. X axis carriage

**Electronics**

- 10. Pololus
- 11. Arduino + RAMPS




3. STARTUP PROCESS

Hotbed height calibration

For proper use, the nozzle movement must be parallel to the Hotbed Surface.


To achieve this, there are three screws available to calibrate its orientation.




There is a risk of the nozzle hitting the hotbed glass or the first layer not sticking to its surface when decalibrated. The following steps must be followed:

1. Click Autohome (Prepare/Autohome) so the printer axes move to their initial position. The first time, caution should be exercised because the nozzle can collide with the base plate. If it is anticipated that this will happen, manually press the Z axis end stopper.
2. Adjust the screw triggering the endstop so the nozzle almost touches the glass when clicking Auto-home.
3. Tighten or loosen the three black screws leveling the base plate. The distance between the nozzle and the glass should be 0,2 mm. (Tip: use a folded piece of paper to check)
4. Position the extruder on the left side using your hand (in case any resistance is felt, disable the stepper motors using Prepare > DisableSteppers). Level the base plate once again using the same procedure.
5. Move the base plate to the front to level the rear end of the plate.
6. Repeat the process until its four corners are leveled.

2.



3.



Calibrating the relative distance

The Dual Extruder kit requires calibration of the relative distance between nozzles to ensure they are in sync at the junction between the two printed materials. The fully assembled version comes fully calibrated.


It is necessary to calibrate whenever any of the BCNozzles are disassembled. The assembling procedure affects the nozzle positions.

To obtain the relative distance values (offset values) two files are needed, available at our downloads section of the website or in the Calibration folder on the SD (for customers purchasing the fully assembled model with the Dual Extruder upgrade included.)

The files are named "Dual_PLA_Slic3r.ini" (configuration) and "Calib.amf" (calibration tool)

Open Slic3r (available at our site, see chapter 5 of this manual) and load the configuration Dual_PLA_Slic3r.ini and the object Calib.amf.

When opening a configuration with multiple extruders the following warning message is shown:



Slic3r only loads the Filament Settings for the first extruder. Therefore, sub configurations for every kind of plastic that will be used must be created. Click on OK and proceed to load the second extruder configuration.

1. Go to Filament Settings.
2. Make the appropriate parameter adjustments for the second extruder plastic.

These are the guiding parameters for the most common plastics:

ABS

- Temp Extruder: 250°C
- Temp Bed: 70°C
- Enable Auto cooling
- Min Fan Speed: 35
- Max Fan Speed: 50
- Bridges Fan Speed: 50
- Disabled Fan for the 2 first layers
- Enable fan if layer print is below 60 seconds
- Slow down if layer print is below 30 seconds
- Min Print Speed: 10 mm/s

PLA

- Temp Extruder: 220°C
- Temp Bed: 45°C
- Keep Fan always on
- Enable Auto cooling
- Min Fan Speed: 35
- Max Fan Speed: 100
- Bridges Fan Speed: 100
- Disabled Fan for the 1 first layers
- Enable fan if layer print is below 60 seconds
- Slow down if layer print is below 30 seconds
- Min Print Speed: 10 mm/s


PVA

- Temp Extruder: 190°C
- Temp Bed: 55°C
- Enable Auto cooling
- Keep Fan always on
- Min Fan Speed: 35
- Max Fan Speed: 100
- Bridges Fan Speed: 100
- Disabled Fan for the 1 first layers
- Enable fan if layer print is below 60 seconds
- Slow down if layer print is below 30 seconds
- Min Print Speed: 10 mm/s


NYLON

- Temp Extruder: 230°C
- Temp Bed: 0°C
- Disable Auto cooling


3. Click on the save icon (save current filament settings). Save with the desired name.




4. In the Plater tab, go to Filament Settings and choose the desired sub configuration for each of the extruders.




5. Depending on the outcome of the print, adjust extruder 2 offset: Printer Settings > Extruder 2 > Extruder Offset. Generally, the offset error will be no bigger than 1 mm. The adjustments to fix the misalignment are described below with some examples:




Reduce X axis offset
and increase Y axis
offset




Increase Y axis offset




Reduce Y axis offset
and increase X axis
offset




Increase X axis offset



Reduce offset in the Y
axis




Reduce offset in the X
axis



Correct calibration,
no need to modify
settings

6. Export the setup with the new offset values: File > Export Config. Exportar G-Code and reprint the object.




7. Go back to step 5 until an optimal result is achieved. Be strict with the results. The appearance of future printed objects will depend on proper calibration

Loading filament

One of the more common operations in our BCN3D+ will be, for several reasons, loading and unloading filament: a change of color, a change of material, using a fresh spool, cleaning, maintenance...


The following steps must be followed:

1. Heat the extruder. Warm the hotend up to printing temperature.
It is not necessary to click on Preheat, although it is advisable when wanting to print immediately after loading the spool. If that is not the case, click *Menú>Control>Temperatura>Nozzle>220°C*.
2. Click on *Prepare>Move axis> 1mm>Extruder*, and rotate the wheel slightly clockwise (positive values) to extrude a few millimeters of material. This procedure will help prevent jams.
3. Click on *Prepare>Move axis> 1mm>Extruder*, and rotate the wheel anticlockwise (negative values) moving the gear a few steps back until the filament is free.
4. Once the old thread is out, load the new one. Click on *Prepare>Move axis> 1mm>Extruder* so the screws hold it tight. Move the wire slowly until the material exits through the hotend.
5. For a proper filament feeding, the idler screws must be tightened enough, offering a slight resistance when assisted with fingers.
6. Once the extruder starts pulling the filament, tighten the screws until enough pressure is reached.
7. Once these steps have been followed, the filament will be loaded and ready to print.



Working with your BCN3D+


The BCN3D+ operation diagram from beginning to end is show below. As shown, two alternative operating paths are possible:



4. LCD CONTROL

The BCN3D+ can be operated from its LCD menu, a single button combining two movements:


- Turn to move through the menu.
- Press down to select desired option.



Next to the control button there is an emergency red button to stop the machine in case of malfunction. It stops the printer but keeps the screen and fans on. Once pressed, the printer resets itself to resume use.

Home Screen

The main screen reports on the status of the printer at the time of the printing currently in progress.



- | | |
|----------------------------------|---------------------------------------------|
| 1. Target/Current temperature | 5. Percentage of printing program read (SD) |
| 2. Fan speed | 6. Status bar and time elapsed |
| 3. Printing speed (Fr) | 7. Notifications |
| 4. Printing height indicator (Z) | |

Actual and target temperature

In the upper left corner four different temperature values can be seen, indicating target temperature (top), actual temperatures measured by the thermistors (bottom), hotend temperature (left) and hotbed temperature (right).

Fan speed

In the upper right corner, the display shows the percentage of power provided to the layer fan. A 0 % value indicates it is OFF, 100% means FULL POWER.

Printing Speed (Fr)

The center left value indicates printing speed. By default a 100% value is shown, meaning it is printing at the specified speed in the executed printing program.

This value is modifiable at any time, even when not printing simply by turning the control button. Thus, with a 150% value it will print 1.5 times faster than stipulated in the printing program.

NOTE: Varying the printing speed modifies the speed of the motor proportionally and directly to the printing velocity, affecting only axes X, Y, Z and the extruder but not the temperature, therefore, printing problems can appear when increasing or decreasing speed to a large degree. It is not recommended to modify this value by more than 50%.

Printing height indicator (Z)

The center right value indicates the printing head height.

NOTE: This value might be incorrect when measured just after switching the printer on, Z=0 actually being the point at which the printer stopped last time it was used.

Percentage of printing program read (SD)

In the lower part of the screen the percentage of program read is shown. Notice that this value states the percentage of Gcode lines performed, not the percentage of the object being printed.

Status bar and time elapsed

In the lower right corner, a status bar shows the same information as before.

Above it, time elapsed since printing process started is shown.

Notifications


The last line shows different messages displaying the processes being carried out by the machine.

Home menu

To enter the menu, click the wheel from the Home Screen.

Three options are found: Prepare, Control, Print from SD/No SD (according to whether the SD has been inserted into the slot or not).

<http://www.reprap-electronics.de/>



Prepare menu

Prepare allows you to operate the machine without it actually printing . The following options can be found:


- DisableSteppers: Turns the motors off, easing the manual movement of the hotbed and printing head.
- Autohome: Positions the printing head in its home position.

NOTE: Before selecting this option, make sure nothing obstructs the movement of any of the axes. Likewise, it is necessary to perform the calibration process before selecting this option.

- Preheat: Unfolds a list of several materials. Selecting one of them makes the printer preheat to the proper working temperature for said material.
- Cooldown: Turns off the power of the heating parts.

NOTE: The machine cools down naturally, so be aware that parts can remain hot.


- Move Axis: It controls axes movement. Select the distance and the axis. To move the axis, turn the control button. Rotate clockwise to move in the positive direction, anticlockwise for the negative one.



NOTE: before clicking on this option, make sure nothing obstructs the movement of all the axes. E axis will not move unless the extruder is hotter than 150°C

Control menu


Allows you to modify the printer parameters before and during the printing process. They are much more specific parameters, requiring a much deeper knowledge of the internal operations of the machine.




Print from SD /No SD

Allows you to access the SD card and select a stored file to print. If the SD card is not inserted, a No SD message is shown. In that case, the BCN3D+ can be connected to a PC through a USB cable (see printing section).


Print from SD



Print from USB



Just for reference, the full menu diagram is shown below:



5. 'STL' FILES

The backbone of BCN3D+ printing are the 3D model files.


The most commonly found file type is the *.STL format. An STL file describes a raw unstructured triangulated surface. The smaller the triangles are, the bigger the resolution and the detail of the 3D model.

Obtaining STL files

There are three different methods:

- 1) Own design: The users create their own objects with Computer-aided design software best suited for people with previous knowledge in modeling.

A wide range of available programs exist, some of them free (OpenSCAD, FreeCAD, Blender), while others require a software license (SolidWorks, Rhinoceros, Inventor, etc.). In general terms, all of them allow the user to import/export STL files.



2) Download: Nowadays there are lots of online repositories where people share their own models with the rest of the community. As an example, the following ones are mentioned:

- **www.grabcad.com** – Repository specialized in engineering, design and architecture models. Not always in STL format but in the original format used by the creator.
- **www.thingiverse.com** – Repository marketed by MakerBot, contains a great deal of STL models and customization tools.

3) Digitalization: Parallel to the development of 3d printing, home scanning technology is evolving at high speed. In this regard, it's worth visiting Autodesk's own www.123dapp/catch. In there, free tools to obtain digital models from pictures taken with a photographic camera are provided.

Other existing methods are: specialized softwares that combines the use of projectors and cameras or 3D scanners.

Editing and repairing a .STL file

As it has been mentioned before, a file in STL format is not always in the best condition. Some of the most common errors are:

- Holes. The model must be closed, with no holes present.
- Face orientation: An STL model is composed of flat faces. Their orientation must be the same and outwards. In other words, it cannot be that some sides point in one direction and some another, they must all be facing outwards. This usually happens by accident when working with modeling software.

Several repairing and editing softwares are available. RepRapBCN recommends Netfabb, which, in its BASIC free version, allows you to perform the most basic editing (scale, rotate, cut, combine, etc.), repairing and measurement operations.

<http://www.netfabb.com/downloadcenter.php?basic=1>

The essential information for editing STL files is detailed below. For more detailed information, it is advisable to visit the official site.

Netfabb interface


After installing Netfabb, it is advisable to become familiar with its interface. First of all, enable printing volume visualization for our BCN3D+. For this, click on View/Show Platform.

Then, redefine volume dimensions. Click on Settings/Settings/General/Default PlatformSize, introducing the values corresponding to the BCN3D+: 252 x 200 x 200. Lastly, click on Save.

In the upper tool bar several icons are found, below are the most important:

- 1) 7 basic views
- 2) Zoom tools
- 3) Tool to orientate the face of the object to the printing surface
- 4) Move, Rotate and Escale tools
- 5) Repairment tools

In the right part of the screen the model's basic info and the cutting tool are available.



Repairment



In case the model needs to be repaired before printing, a warning sign will appear in the lower right corner. To repair it, select the model and click on the tool *Repair*.

Next, in the right side window, click on Automatic Repair and select

Default Repair in the pop-up window. Click on Execute and then click on Apply Repair in the right side window to finish the process.

In the new pop-up window, select Remove old part to erase the faulty original file. If the file is successfully repaired, the warning sign will be gone.

- In case the model faces are inverted, the model will be shown in red. In this instance, the model can be repaired clicking on Part/InvertPart.




Orientation and move home

First of all, we need to correctly orientate the model, usually on a flat surface. The easiest method is selecting the tool *align to bottom* plane and double click the side in contact with the printer's surface.

Then, the object must be moved to its origin selecting it (represented by the green object) and using the Move tool. In the pop-up window, click on "To origin" and then "Translate" to finish.

Additional editing options available are cutting and scaling.

Once the model is repaired and edited it's time to save it. Click Part/ExportPart/as STL and save with the desired name.



G-CODE generation

At this point, we've got a 3D model ready to print. However, one last step is required. The STL file must be converted to a file type the printer can read in order to fabricate the model. In other words, the G-Code file must be generated.

Gcode is a programming language used to control CNC machines, including the majority of 3d printers. It consists of a set of instructions that tell the machine the positions and speed at which each of the axes must move and also the hotend and hotbed temperatures.

There are several tools to generate a Gcode file from a STL file. RepRapBCN recommends using Slic3r, an open source software that is constantly updated, with new functionalities added.

<http://slic3r.org/download>

Like other GCodes generators, Slic3r sections the 3D model in layers that will be later deposited to create the 3D model. In every layer, a distinction is made between the perimeters and the filling of the part. Also, the operational sequence, printing speed, number of perimeters, etc can be chosen. Since there are many parameters, some of them difficult to understand, specific configurations have been prepared to ease up the process for the novice user.

Slic3r configuration

The following printing profiles have been prepared for the BCN3D+ with a 0,4mm nozzle in mind, taking into account the kind of object and later use.

These must be taken as a reference point and can be improved to go faster, achieve a better finish, etc.

ST: Standard configuration with a layer height of 0,2mm for most builds

HQ: High quality standard configuration with a layer height of 0,1mm

HS: Setting targeted at jobs needing a fast print without losing much quality

SV: Special configuration for container-like pieces. There is no infill present and the object is manufactured helically with a single surface, improving the surface finish.

WALL: Special setting for models with exotic geometries like the ones generated with the Voronoi algorithm (the designer Dizingof being its best representative). There's no filler present and the temperature and speed are lowered to improve overhang construction.

STR: Special setting for parts suffering from significant mechanical stress. The filling is made in a honeycomb fashion and the layer height is decreased to 0.15mm to improve adhesion between the layers.

Slic3r FIRST STEPS


We will now explore the key points needed to use Slic3R. To gain a deeper knowledge please visit the official website of the Project and download the manual:

<http://manual.slic3r.org/>

Printer definition


A setup wizard will appear the first time Slic3r is executed. The following information must be entered:

- 1) Firmware Type: RepRap (Marlin/Sprinter)
- 2) BedSize: x: 252 y: 200 mm
- 3) NozzleDiameter: 0.4mm
- 4) FilamentDiameter: 2.9 mm
- 5) ExtrusionTemperature: 220°C
- 6) BedTemperature: 55°C



Loading a profile


Once configured, we can load the best suited printing profile to the kind of object we are about to print. To do that, we must go to File/Load Config... and select the preferred configuration.



Adding files


Next, add the previously edited and repaired STL. The file can be directly dragged over the platform or be added by clicking on it. You can add as many files as you like.

Also, more than one copy can be printed. You only have to select the outline of the object or select it from the list on the right to duplicate, and click the “+” button as many times as needed.



Exporting Gcode

Once the object has been deployed over the platform and the configuration adjusted, it is time to export the GCode. Click on Export G-Code and specify the saving location and file name, creating a file with the *gcode extension.



Slic3r use with a Dual extruder

Slic3r is capable of generating G-Codes for printers with multiple extruders. The basic instructions needed to operate Slic3r with the Dual Extruder are explained below:

Creating .amf files

Slic3r uses .amf (Additive Manufacturing File Format) for prints with multiple extruders. Unlike the STL format, it can save information on the materials used. The process for creating an .amf file is as follows:

1. File > Combine multi-material STL files
2. Select the first STL (for extruder 1)
3. Select the second STL (for extruder 2)
4. Click on Cancel
5. Pick name and location to save the *.amf file

Load the *.amf file (like an *.stl file) to begin printing

Notes and usage tips

One of the main problems of dual extruders is the dripping that occurs in the extruder that is idle. Not only does it stain the piece being printed, but also empties the reservoir of molten plastic. This means that, to reprint after a period of inactivity, some time is needed before returning to extrude continuously.

To minimize this issue, the Dual.ini configuration incorporates a skirt the same height of the piece. This skirt functions both as a barrier against leakage and for purging the extruder. However, skirting is done with only one extruder (the left one). Therefore, when creating the *.amf file it is advisable to study which of the two extruders is working less. That should always be the extruder no. 1.

Cura use with a Dual extruder

Cura can also generate G-Codes for printers with up to 4 extruders. While it is true that Slic3r allows control over more parameters, Cura is easier to use. Most importantly, however, is that it solves many of the problems arising from the use of the Dual Extruder that Slic3r fails to solve.

It includes a skirting functionality around the object (called an Ooze shield), with the addition that it is done alternating both extruders.

It also has the Wipe & Prime Tower option to purge the idler extruder before reprinting, thus achieving better surface finishes.

You can download the program and Dual Extruder Cura configuration from our website.


1. Configuring the printer with Cura

During first time installation, a setup wizard allows configuring our printer parameters.

If Cura is already installed, additional printer profiles can be added.

Go to Machine --> Machine Settings --> Add New Machine.

Note that this menu also lets the user configure the second extruder offset.





2. Printing with Cura

Cura does not need working with *.amf.files, just add the two *.stl files.

Then click on one of the models and select the Dual Extrusion Merge.

The yellow model will be printed using extruder no. 1 and the red on with extruder no. 2.



Transferring our G-CODE to the BCN3D+

Finally, we just have to transfer the GCode to the printer to start the print. To do that, two different procedures are available.

- 1) Using the LCD. Insert an SD containing the Gcode file you want to print in the lateral slot card of the screen and press the control button and choose Print from SD to select the object.
- 2) PC connection. Use a software to connect the printer via USB. RepRapBCN recommends RepetierHost

<http://www.repetier.com/download/>

It's a free open source program that allows you to visualize STL files, automatically generate the GCode from preconfigured profiles and monitor the printing progress.

A simpler alternative to RepetierHost is Printron

<https://github.com/kliment/Printron>

6. PRINTING FROM USB AND SD CARDS

After selecting the piece to be printed, and having calibrated the machine and checked that everything works correctly, proceed as follows:

- Make sure PLA is loaded in the machine
- Preheat the printer using the following commands in the LCD:

Home Menu > Prepare > Preheat PLA

- Once working temperature is reached, clean out excess material:

Home Menu > Prepare > Move axis > 1mm > Extruder

Turn the wheel clockwise until the material flows continuously through the nozzle. Then clean out the extruded material.

- Insert the SD card into the left side slot of the display screen, paying attention to the position of the card.
- Start printing by selecting the desired file:

Home Menu > Print from SD > Fila_name

The print process will start. Attention should be paid to the manufacturing process, especially during the first uses.

Printing with one extruder

Dual Extruder assembly allows the use of a single extruder.

For that purpose, a conventional single extruder configuration must be loaded. By default, the one performing the task will be extruder no. 1 (left). In case printing with extruder no. 2 is desired, open the generated G-Code (using Notepad, for instance) and add T1 in the first code lines as described below:

```
G21 ; set units to millimeters
M190 S55 ; wait for bed temperature to be reached
M104 S210 T1 ; set temperature
G28 ; home all axes
M109 S210 T1 ; wait for temperature to be reached
G90 ; use absolute coordinates
G92 E0
M82 ; use absolute distances for extrusion
T1
G1 F2100.000 E-3.00000 .....
```

What configuration to use?

Two preset configurations for Slic3r and Cura are available on our website for PLA and ABS, the most commonly used plastics. As every plastic requires specific temperatures and several other specific values, these configurations are targeted at achieving an optimal surface finish.

When combining several materials in one print, use the configuration for the predominant one as a baseline. If considered appropriate, modify the parameters until achieving a compromise.

Available printing surface

With the Dual Extruder assembled, BCN3D+ printing volume is 175 x 190 x 200 mm.

Printing with a single extruder, the volume is 200 x 190 x 200 mm.

7. FILAMENTS

BCN3D+ achieves its best printing results with PLA, ABS and Nylon, while accepting many other plastic materials in 3 mm filament format. A brief description of the materials currently accepted follows:

PLA

PLA (polylactic acid) is the quintessential material for 3d printing, thanks to its ease of use through deposition. It is advisable to begin in this type of manufacturing technology with this material. A great variety of colors exists and complex geometries can be achieved without great difficulty. The finish is slightly glossy or semi-matte.

Printing is carried out at temperatures ranging between 195° and 220° C, depending on the supplier of the material and printing speed. A layer fan is required to build overhangs. It easily attaches to the glass, and if you work at a hotbed temperature ranging 45° C-55° C, no product is required to ensure this adherence.

The mechanical properties are average, but presents a certain fragility in parts requiring deformation, from a temperature of about 50° C. It dissolves in caustic soda.

ABS

ABS (Acrylonitrile Butadiene Styrene) is one of the most widely used materials in 3d printing, and makes up for some of the weaknesses of the PLA. Printing with ABS is more complex and requires some attention. ABS is not recommended for inexperienced users. The variety of colors is also very high and the finish is semi-matte or matte.

The ABS is printed at temperatures between 210° C and 240° C depending on the supplier of the material and printing speed. The ABS performs better with overhangs, and needs less air into the fan layer (excess air can be harmful). Adherence to the platform is weaker than with the PLA, due to material shrinkage on cooling, and often requires adhesive coating despite working with a hotbed temperature of 70 ° C. If the geometry of the piece to be printed has a too large base, it further promotes adherence problems due to the large lift effect that occurs at the opposite ends of the workpiece (known as warping. See section 11 Print quality diagnosis).

Nylon

Nylon polyamide is an easily printable polyamide, but presents major problems regarding adhesion to the base. It is a slightly translucent material with some flexibility. The color is white, while accepting tinting. Its use is recommended to prevent wear on parts that suffer friction in regular use.

It prints at a similar temperature to that of PLA, and often requires the use of alternative techniques to ensure adherence to the base. The use of special bases (Garolite, tufnol) or alternatively, the lining of the glass base with masking tape helps solve part of the warping. Parts with a too bigger base do not accept the use of nylon. It has better mechanical properties than ABS.

Materials in experimental phase

HIPS

HIPS is a material with properties similar to those of ABS but that reacts to different solvents. It is frequently used as support material for ABS printing.

PVA

PVA (Polyvinyl alcohol) is targeted at making support structures for overhang printing. It is soluble in water, making it easy and safe to get rid off afterwards.

Laybrick

The laybrick is a plastic-based material that imitates the finishing of stone. It's extruded like PLA, having similar characteristics, but has a tendency to clog the nozzles. Recommended only to expert users.

Laywood

The laybrick is another plastic-based material that imitates wood finishing. Not to be extruded with standard 0.4 nozzles due to the size of its particles, causing a clog. Recommended only to expert users.

Filaflex

Filaflex is a flexible material that comes in different colors. Extrusion is simple but requires the use of a 0.6 mm nozzle.

8. FIRMWARE

What is a firmware and when to update it?

The firmware is a software needed to control a hardware. Namely, it is the internal program that controls the BCN3D +. The BCN3D + is delivered and installed with the latest firmware version published on the web.

Its basic functions are:

On the one hand, converting .gcode files to useful instructions for printing, managing the motor drivers and target temperatures.

On the other hand, it is also responsible for managing machine peripherals such as the screen, allowing you to interact with it without actually connecting the printer to a computer, or the endstops necessary for proper functioning of your printer.

Usually the firmware of a device is integrated in it and you can not change or replace it unless approved and provided by the manufacturer.

The advantage of our RepRap printer is that it follows the Open Source philosophy so we can change or modify the firmware to adapt our machine to new features and accessories or improve its behavior.

The ability to modify the firmware is the responsibility of each user. RepRapBCN will always develop firmwares oriented to printing with their products and will freely disseminate them.

When it is necessary to update the firmware?

It will be always necessary when adding new functionalities that imply a change in its control system such as new extruder head, Dual extruder heads or a Paste extruder. Changing other parameters such as pulleys or axes length, printing speed and endstops will also need a firmware update.

When RepRapBCN publishes a new update, it will be announced through its web site and social networks, highlighting improvements and new features.

Downloading Arduino's IDE

This section describes the steps to update / modify the controller firmware. The first step is to install the Arduino IDE on a computer. This is a program that enables us to interact with BCN3D + Arduino card.




1. Download Arduino's software package from <http://www.reprapbcn.com> or execute from the provided USB dongle.

2. Install the program.
3. Once installed, plug the BCN3D+ to the computer through a USB cable, thus the connection with the Arduino board being established.



If the board drivers are not installed automatically, please follow the steps below:

<http://arduino.cc/en/guide/windows#toc3>

4. Open the Arduino manager
5. From File>Open, select the saved new firmware file.
The file has the *.ino extensión and it is located in a folder with the same name.
6. Now the desired parameters can be modified if necessary.
7. Select the card model and port using **Herramientas>Tarjeta>Arduino Mega 2560** and **Herramientas>Puerto Serial>COM X**



- The card used by the BCN3D+ is an Arduino Mega 2560.
- Port means the connector through which the board is connected to the computer (COM port). It can be checked from Start> Computer> Right click> Properties> Device Manager> Ports COM and LPT (Windows)



8. Click on Load.

Loading starts, first compiling the program for errors, and then, properly speaking, loading the firmware on the memory board.

9. If the process is completed successfully the message Charge completed is displayed and the printer is ready to use.

9. TROUBLESHOOTING

Hysteresis correction and backlash

The hysteresis effect is purely mechanical and derived from the backlash from some of the components used in the BCN3D+ printers. It occurs when a change in the direction of the platform to follow a given drawing suffers from a delay. It is present in changes in the Y axis.

The result can be noticed especially when printing circles, where a lengthening of the shape of the circumference in the point the axis shifts is produced.

The solution implemented in the firmware allows to force an X and Y axes correction right at the moment it changes direction. The printing platform is forced to correct its position going up or down to compensate depending on the direction in which the change occurs, thus the hysteresis and the elongation above mentioned disappear.


To access the hysteresis menu:



Main menu > Control > Motion > Hysteresis

Inside it, we will find the following options:

- Circles: Sets a standard correcting values for circles
- Manual X: Allows you to manually set X axis correction
- Manual Y: Allows you to manually set X axis correction
- Disable: Disables hysteresis correction



This firmware updates comes with a default value preset to start printing right away.

Store & Load memory


Lets you save the parameters set in the Control menu. These settings remain stored after turning off the printer.

- To save a configuration

Menu > Control > Store Configuration

- To restore previously saved information

Menu > Control > Load Configuration



With this improvement we can decide the control configuration best suited to the mechanical characteristics of our printer and save it.

It is difficult to remove an object once its done

Once a print is finished, it's sometimes difficult to pull it out of the platform:


- Let the base cool down, the colder it is, the less adhesion.
- Carefully place a cutter below the part and use it to slowly remove the object.
- It is highly recommended to remove the cristal base by loosening the white screws. If you try to extract the printed part directly without removing the glass first, you could be forcing the screws and/or misaligning the platform.

Motors do not rotate correctly (adjusting the pololus)


From Home Menu/LCD Prepare/Move Axis, the proper movement of the motors can be cheked by moving the axes. We will proceed as follows:

1. Before we start, use your own hands to check nothing is hindering the motors movement.. If there's still no movement, adjust the pololus following this instructions:

2. If the motors do not move or do not move enough, They are lacking power. Turn off the machine and turn the potentiometer pololu clock 5 minutes clockwise.



3. If the motors move but, from time to time, make sudden movements, ie, lose steps, they have too much power. In that case, turn off the machine and turn the potentiometer clock pololu 5 minutes anticlockwise.



NOTE: before clicking on this option, make sure nothing obstructs the movement of all the axes. E axis will not move unless the extruder is hotter than 150°C.

Extrusion stops

It could happen for several reasons:

- The motor does not properly rotate:
 1. Adjust pololus power.
 2. Check that the large gear axle nuts are not too tightened up against the extruder, but against each other. Ensure that the actuating mechanism rotates easily by hand.
 3. Check for flaws in the electrical cables and that they are properly connected.
- The thread does not advance even when the motor is running:
 1. Make sure the temperature is correct according to the type of plastic.
 2. Remove the extruder and thoroughly clean any remaining plastic.
 3. Raise the machine temperature and, using your own hands, try to get rid of the clog jamming the extruder.

- The message “Mintemp” or “Maxtemp” appears on screen:
 1. Hotend temperatura has left its working range. Make sure connections are secure and wiring is not damaged.
 2. If the problem persists, remove the hotend from the machine and make sure the thermistor is not broken and the wires are not touching, which would cause a short circuit and a misreading of temperature.
- The thread has become tangled:
 1. Make sure the spool rotates correctly in the holder, and that the thread descends more or less straight down into the extruder. A tangled thread may cause it to break or fall off the coil bracket.
- The glass is too close to the nozzle:
 1. Tighten the screws on the base or adjust the Z axis endstop a little higher and start again.
 2. Recalibrate the base.
- The SD card has been removed from its slot:
 1. If the SD card is removed from the screen slot, the printing process stops and it's not possible to continue from where it stopped.

The screen does not responde or nothing is shown

1. Turn the printer off and back on.
2. Make sure that the cables that feed the display are properly connected. The two cables coming from the electronics must cross each other
3. Reload the firmware using a pc. If the firmware is incorrectly loaded a blank screen will appear (see section 8, Firmware)

X,Y or Z carriage does not move fluently se desplazan con fluidez

1. Clean the guides.
2. Loosen the screws holding the guides.

10. PRINT QUALITY DIAGNOSTICS

This sections shows a list of the most common printing quality problems and how to minimize them. Regardless, we recommend using our web configurations (www.reprapbcn.com) because they have been tested and work well with most objects.

The part becomes separated from the hotbed (WARPING)

Sometimes the parts do not properly adhere to the glass hotbed during printing. This especially happens printing with ABS, a material with great thermal contraction.



In this case, try the following steps:

1. Clean the glass to prevent dust or other substances interfere between the base and the piece.
2. Soak the glass surface with a layer of the included adhesive spray
3. Raise the base temperature five degrees celsius.
4. Calibrate the base as shown in section 11 Maintenance.
5. Print the first layer with the hotend closer to the base. To do this, loosen the three screws from the base an eighth of the way or loosen the screw that actuates the Z axis endstop a fifth of the way. The two actions will get the base and hotend 0.1mm closer so the first layer adheres better.
6. Make the first layer extrude more material (from Slic3r, **PrintSettings/Advanced/FirstLayer**).

First layer material is not extruded throughout its geometry

1. It might happen that the first layer does not adhere properly to the glass, or leaves a steady stream of plastic thread (little droplets forming a line) throughout the figure.

The problem is that the machine is not correctly calibrated; the extruder is too far from the base. Check the calibration section in chapter 11 (Maintenance) to see how to regulate the Z axis endstop.

2. The symptoms above are present in just part of the first layer.


The reason being that the printer is not correctly calibrated, the X axis is not parallel to the base and this causes the extruder to move away from or get too close to the base at some points. Check the calibration process section in chapter 11 (Maintenance) to know further about orienting the printer dock.

11 Maintenance, focusing on the orientation of the plane of the printer dock.

Cracks appear in the middle of the piece

This happens because the area of the piece closest to the extruder is hotter than the lower layers.

To avoid these cracks the extrusion temperature must be raised five degrees celsius, so that the layers adhere more strongly.



Fused

When working with fused material, gravity causes it to drip from the nozzle. Strategies to minimize this problem and achieve better surface finishes, even with complex geometries, should be seek.

Deposition

The thread of material being extruded has the outer diameter of the nozzle orifice. By depositing the fused thread layer by layer, the entire surface of the part is printed.

Note that the manufacturing process occurs sequentially, which allows differentiation between different aspects of each model (such as perimeters and filler) and choose among different print strategies (order, framework and filling rate, etc).



Strings of plastic appear around the piece


This happens when the extruder is moved from one point to another without depositing material.

To avoid this, set the retract option in Slic3r. It retracts part of the extruder motor wire, so that the pressure of the material inside the extruder is reduced and dripping is prevented during axes movement. If the retract increases, there is a decrease in string-shaped waste.

Modeling


The higher we print, the need for support structures becomes more obvious. Deposited material tends to detach itself in steep areas or hanging parts such as overhangs.

When this happens, it is recommended to make use of Slicr options regarding the creation of support columns.



One layer is displaced relative to the lower one

When there is a discrepancy between layers position, it is likely that one of the motors lost steps. Firstly, you must identify which axis is affected and then adjust that pololu, as explained in section **9 (Troubleshooting)**.



11. MAINTENANCE

Given the machine characteristics, it is very important to periodically check the different components so we do not lose print quality and to avoid errors.

Calibration

BCN3D+ is marketed fully assembled and calibrated, but it is possible that it might require recalibration of its axes over time.




The process is simple if the following steps are taken:

- X axis calibration
 - a) With the calibration tool, measure the X axis bars height from the aluminum sheet base
 - b) Adjust the height at both ends of its horizontal axis by manually rotating each threaded rod.

- Z axis calibration

In order to ensure the perpendicularity of the axis Z with the base, an iterative process must be performed consisting of the following steps::

- a) Place the Z axis in a vertical position (about 180 mm).
- b) Loosen the screws on the base of the Z shaft guides. This provides a range of motion that will allow us to position them correctly.
- c) Use the calibration tool as a sort of set-square or triangle and stand its short side on the base plate while the longer side rests in contact with the vertical Z axis guides.
- d) Orientate the tool so two 90° measurements can be taken and repeat in both Z guides.



e) During measurements, keep adjusting the perpendicularity relative to the guide using the tool and tighten the base screws to fix its position. As mentioned before, this process has to be repeated in both guides and then correct any imbalances.

Rods lubrication

It is recommended to grease the rods from time to time, especially when they suffer from difficulties moving or make more noise than usual. Place a few drops on the rods, and move the axes so that the same mechanism distributes them throughout.

The same process should be applied to the two Z threaded rods.

Filament maintenance

Filament spools should be stored in a cool, dry place, heat and humidity affecting this kind of plastic. If a coil is not to be used for a long period of time, store it in a sealed plastic bag.

Ensure that the filament is neatly coiled. A loose coil can cause it to curl wrong, and cause jerks affecting printing and the machine components.

Cleaning the printer dock

After several prints, the hotbed glass gets dirty, and layers of adhesive coating, plastic dust and debris accumulate. To clean the glass, it must be removed from the printer. The remains of coating and dust are easily removed by placing the glass under water with a little of soap.


Remaining stuck plastic can be removed with a cutter, being careful of not scratching the glass. Acetone can also be used as it acts as a solvent.

Hotend maintenance


Removing the hotend to change the nozzle or any other of its parts can be performed easily by following these steps:

- Disassembling the hotend
 1. Remove the wire inside the hotend following the procedure explained in section 3. (First time setup in Loading filament).
 2. Cool down the hotend for about 15 minutes using the Prepare> Cooldown option.
 3. Click Autohome and raise the Z axis to +150.00 mm
 4. Turn off the printer
 5. Remove the two Layer Fan ring M3 screws M3.
 6. Disconnect the fan and remove the Heat sink fan cooler support.
 7. Disconnect the Hotend wires connector and cut the zip ties to release the cables.


8. Unscrew the Heat break+ block + nozzle set using the Hotblock wrench, taking care that the cables do not become entangled or uncrimped. [View 3]
9. With the above mentioned set out of the way, unscrew the nozzle block with both the block wrench and the nozzle wrench, watching carefully that no wires are damaged in the process. [View 5]
10. Unscrew the Heat break using both wrenches [View 7]
11. Check all the componentes are clean, if not, clean following the procedure explained below.



View3




View5



View7

▪ Assembling the Hotend


1. It is composed by the block (ceramic resistor and thermistor already installed), nozzle and heat break.
2. Screw the nozzle by hand until it makes contact with the block.
3. Once screwed, loosen by a quarter of the way.
4. Once screwed, loosen by a quarter of the way.
5. Tighten the nozzle with the nozzle wrench, holding the block with the block wrench. [view 6]
6. Screw the whole set by hand to the printer.



View6

If the cables ended up in an awkward position, we should remove the extruder mechanism and unscrew three heatsink screws so we can rotate the hotend.

7. Using the break wrench, gently tighten the heatbrek and the set against the heatsink. [view 9]
8. Plug the hotend wires.
9. Heat the extruder to 220 ° C.
10. Now that it has warmed up, tighten the nozzle back, against the block using both wrenches. [view 10]




View9

11. Assemble the cooler fan to the heat sink and connect the wiring.
12. Assemble the Layer fan ring using the two provided M3 screws.
13. Tie the hotend and fan wiring with a zip tie.
14. Turn the printer on and check all connections are working properly.
15. Load filament and extrude it.

Necessary:

- Nozzle wrench / break wrench (8,2 mm/4,6 mm)
- Block wrench (20,5 mm)



Cleaning hotend parts

To clean plastic debris or other remaining material within parts of the hotend we can proceed in several ways:

1. If the plastic residue is ABS or PLA, soak it acetone and leave it overnight. Remove them with a pice of wire so they don't get scratched.
2. If the waste is between the heat block screw thread, we will will need to connect the wiring and heat the block to 150-220°C, taking extreme care not to get burned. Pliers and wrenches are heat resistant.

VIEWS 8 AND 9 ALLUDE TO THE ONLINE WEB MANUAL

12. TIPS AND TRICKS

There are certain things that we must take into account when using and maintaining the machine:

- Do not spill liquids on the hotbed or hotend as they could damage the other components. To clean them, first remove them from the machine. The only advised product for improved printing adhesión is the included coating spray.
- If we've got difficulties removing the printed parts, remove the glass first to avoid decalibration.
- Do not overheat the hotend. Although its maximun temperature is firmware limited, do not use other methods to heat it above the established range.
- Do not handle the electronic parts of the machine when it is on, it could cause damage to its components.
- Do not turn off the printer immediately after printing. Allow some time for the fans to cool the different compo-nents down.

13. REPRAPBCN TECH SUPPORT

If you do not find in this manual a solution to your problem, you can contact the REPRAPBCN team via the following channels:

Forum

Before taking any other action, you should have a look at our forum. It is very likely another user has suffered the same problem, and the forum is where most of them are solved.

<http://www.reprapbcn.com/es/forum>

E-mail

If the problem persists, you can contact us directly by email. An expert from RepRapBCN will answer you back with a solution as soon as possible.

info@reprapbcn.com

Customer Service

Call our customer service line:

+34 93 473 88 24 (TECH SUPPORT)
+34 93 348 70 25

Call this numbers to contact our team, for either directly getting your questions answered via phone or to make an appointment and have your printer checked in our facilities.

This information is also available in our website contact section:

<http://www.reprapbcn.com/es/contact>

In any case, it is very important to attach the printer serial number so we can keep track of it and know in advance the problems that might arise. A photograph could also help identify more easily what happened.

14. GLOSSARY

- **Arduino.** Free hardware platform based on a board with a microcontroller and a development environment. It is a very popular board, and constitutes the brain of the BCN3D + electronics. Requires loading a firmware to work.

<http://www.arduino.cc/>

- **Endstop.** The electro-mechanical component that makes contact with the axis carriages to indicate their total length.
-

- Filament: Coil of any valid printable material.
- Firmware: BCN3D + Internal Code which governs all electronic and allows printing. BCN3D + uses its own firmware, based on the popular Marlin.
- Power supply: Used to power the device, adapted to the printer needs
- Gcode: Files in G-Code format containing the printing instructions for a given figure. They're loaded in the SD card so that they can be read and printed.
- Hotbed: Heated base on which the models are printed
- Hotend or Extruder: Where heat is applied to melt and print the filament.
- SD Card: Card where the files are stored in Gcode format for printing.
- Netfabb: Recommended by RepRapBCN to edit and repair STL files.

<http://www.netfabb.com/downloadcenter.php?basic=1>

- Netfabb: Recommended by RepRapBCN to edit and repair STL files.
- Open Source. Freely developed and distributed software
- Pololu. An electronic component that controls the functioning of the printer motors.
- RepetierHost. Software that allows sending Gcode files directly from the PC to the machine via a USB cable. It has other features like print monitoring.

<http://www.repetier.com/>

- RAMPS 1.4. Stands for RepRapArduino Mega PololuShield. It's a microcontroller board designed specifically to complement the printer circuit. Contains a fuse to prevent the destruction of the Arduino board in case of an electric surge.
- Slicer: RepRapBCN recommended software to generate Gcode files from STL files.

<http://slic3r.org/>

- Thermistors. Temperature sensors. Found in the hotbed and hotend.
- Layer fan. Fan located just off where the fused material is ejected, cooling it to match the temperature of the already printed material.

15. WARRANTY, REFUNDS AND REPLACEMENT POLICY

RepRapBCN does not offer a long term warranty. Every component has a one year warranty. RepRapBCN accepts returns for any unaffected item within 14 calendar days from the date of receipt of merchandise. After such time, all sales are considered final. Unaffected means a device has never been assembled, powered up, programmed, or otherwise changed. RepRapBCN cannot accept returns on purchased items that have had electrical power applied to them, or been otherwise programmed, changed, or affected

However, we do offer spare parts and technical assistance for items proven to suffer from a manufacturing defect and we will work with you to get your printer back to work


16. TERMS OF SERVICE

All the information contained in this manual is subject to change at any time without notice and it is offer just for convenience. purposes only.

RepRapBCN reserves the right to modify or revise this manual at any time. You accept being subject to any modification and/or revision. . Please contact RepRapBCN support tem if you want to obtained the most updated information.

The design of this manual and all text, graphics, information, content, and other material displayed are protected by copyright, trademark and other laws

Certain trademarks, trade names, service marks and logos used or displayed on this Website are registered and unregistered trademarks, trade names and service marks of RepRapBCN and its affiliates. Nothing contained on this manual grants or should be construed as granting, by implication, estoppel, or otherwise, any license or right to use any trademarks, trade names, service marks or logos displayed on this manual without the written permission of RepRapBCN or such other owner. Any unauthorized use of the information, materials or trademarks included in this manual might incur in violation of copyright laws, trademark laws, privacy and publicity laws and other laws and regulations.



RepRapBCN

BCN3D+ Dual extruder
User manual

Fundació CIM-UPC

12, Llorenç i Artigas

08028 Barcelona

T. 934 017 171

F. 934 017 170

info@reprapbcn.com

www.reprapbcn.com

RepRapBCN 2014, All Rights Reserved