

Interference Report

Purpose : To check interference at the top level and child level by excluding specific materials and generate interference reports

Functions:

- The tool will exclude selected material from the interference report
- Users can check child interferences
- Users can check top-level interferences
- The tool will generate an interference report.

Constraint:

- The tool will only work on assembly files

Interference Report

User Interface Guide:

1. Open the desired assembly in Solid Edge and Activate the tool by clicking on it.
2. Assign interference excel to exclude material for interference.
3. Click on get interference excludes material to fetch material from excel.
4. Select material from the list to exclude from the interference report. Users can also search or filter material from the bottom search menu.
5. Click on To false interference occurrence properties to exclude selected material.
6. Click on Check child interference to check child interference and generate a report.
7. Click on **Check interference TopLevel** to check **child interference** and generate a report.
8. The Report will be stored in the assembly location

