

# Copy and Transfer

**Purpose:** To conveniently transfer the desired part to another level of assembly without losing the original position of the part

**Functions:**

- This tool assists the user in duplicating multiple parts within the same location.
- This tool aids the user in relocating multiple parts to a different assembly.

# Copy and Transfer

## User Interface Guide:

1. Open the desired assembly in Solid Edge and Activate the "Copy and Transfer" tool by clicking on it.
2. Select part or parts in the assembly tree and press "Copy Part Same Location". Parts will copy on the same location.
3. Select a part in the assembly tree and press Transfer Selected Document. The solid edge transfer menu will open and select desired destination assembly from the menu.
4. Click on Update All Open Documents if changes don't reflect in assembly.

