

Copy and Transfer

Purpose : To conveniently transfer the desired part to another level of assembly without losing the original position of part

Functions:

- Tool helps user copy multiple parts in the same location.
- Tool helps user transfer multiple parts to another assembly.

Copy and Transfer

User Interface Guide:

1. Open the desired assembly in Solid Edge and Activate the tool by clicking on it.
2. Select part or parts in the assembly tree and press Copy Part Same Location. Parts will copy on the same location.
3. Select a part in the assembly tree and press Transfer Selected Document. The solid edge transfer menu will open and select desired destination assembly from the menu.
4. Click on Update All Open Documents if changes don't reflect in assembly.

