

Occurrence Properties

Purpose : To conveniently assign occurrence property for reference model in assembly

Functions:

- Tool helps users to assign preset occurrence properties for reference models in assembly.
- Preset occurrence property options can be changed as per need.

Occurrence Properties

User Interface Guide:

1. Open the desired assembly in Solid Edge and Activate the tool by clicking on it.
2. Check desired preset setting and change it if required.
3. Clicking "Update Occurrence Property" will apply property on the selected part.

