

CAN A

CAN A

Processor 1 : Front Axle + ICE (+ Clutch command)

- Mechanical modules :**
- Front Axle/ICE/ICE (&)
 - Front Axle/Clutch (@)
 - Front Axle/gearbox + differential (\$)
 - Front Axle/FA_TQ_to_F_BRAKE (#)

- Shared variables :**
- FA_N_ICE (@ → &)
 - FA_ICE_TQ_SP (% → &)
 - FA_STARTER_REQUEST (% → &)
 - FA_ICE_STATE (% → &)
 - FA_TQ_STARTER (& → %)
 - FA_CLU_STUCK (@ → %)
 - FA_TQ_CLU (@ → \$)
 - FA_TQ_ICE (& → @)
 - FA_N_GBX (\$ → @)
 - FA_TQ_MAX_ICE (& → \$)
 - FA_TQ_MIN_ICE (& → \$)

- Command modules :**
- Front Axle/ICE/ICE control (%)

SYSE_SOC (2 → 3)
PLA_SPEED (2 → 3)
PLA_N (2 → 13)
SYSE_VOLTAGE_HV (2 → 3)
RA_TQ_MIN (2 → 3)
RA_TQ_MAX (2 → 3)
SYSE_TQ_MIN (2 → 3)
SYSE_TQ_MAX (2 → 3)

CMD_CLUTCH_SP (3 → 1)
DRI_GBX_SP (3 → 1)
PLA_N (2 → 1)
CM_FA_MECHANICAL_BRAKE (3 → 1)
CMD_FA_TQ_SP (3 → 1)
FA_START_ICE (3 → 1)

FA_GAS_CONSUMPTION (1 → 3)
FA_TQ (1 → 2)
FA_TQ_MIN (1 → 3)
FA_TQ_MAX (1 → 3)
FA_PLA_F_BRAKE (1 → 2)
FA_N_ICE (1 → 3)

Processor 2 → Rear Axle + EMA + Platform + Environment

- Mechanical modules :**
- Real Axle/Electrical machine/Power efficiency (&)
 - Rear Axle/Differential (@)
 - Rear Axle/RA_TQ_to_F_BRAKE (\$)
 - Electrical system/Lithium-ion battery management system (#)
 - Electrical system/Auxiliary network 12V (%)
 - Platform (*)
 - Environment (€)

- Shared variables :**
- RA_TQ_ME (€ → &@)
 - RA_N_EM (@ → &μ)
 - RA_EM_CURRENT (& → #)
 - SYSE_VOLTAGE_HV (# → & %μ)
 - RA_TQ_MIN_ME (€ → @)
 - RA_TQ_MAX_ME (€ → @)
 - PLA_N (* → @)
 - RA_PLA_F_BRAKE (\$ → *)
 - SYSE_AUX_CURRENT (% → #μ)
 - RA_TQ (@ → *)
 - ENV_VECT (£ → *)
 - SYSE_SOC (# → μ)

- Command modules :**
- Real Axle/Electrical machine/Engine representation (€)
 - Electrical system/Electrical system supervision (μ)

CMD_RA_MECHANICAL_BRAKE (3 → 2)
FA_TQ (1 → 2)
FA_PLA_F_FRAKE (1 → 2)
CMD_RA_TQ_SP (3 → 2)

PLA_SPEED (2 → 3)
FA_N_ICE (1 → 3)
PLA_N (2 → 3)
FA_GAS_CONSUMPTION (1 → 3)
SYSE_SOC (2 → 3)
SYSE_VOLTAGE_HV (2 → 3)
RA_TQ_MIN (2 → 3)
RA_TQ_MAX (2 → 3)
SYSE_TQ_MIN (2 → 3)
SYSE_TQ_MAX (2 → 3)
FA_TQ_MIN (1 → 3)
FA_TQ_MAX (1 → 3)

DRI_GBX_SP (3 → 1)
CMD_FA_TQ_SP (3 → 1)
CMD_RA_TQ_SP (3 → 2)
FA_START_ICE (3 → 1)
CMD_CLUTCH_SP (3 → 1)
CMD_FA_MECHANICAL_BRAKE (3 → 1)
CMD_RA_MECHANICAL_BRAKE (3 → 2)

Processor 3 → Supervision

- Mechanical modules :**
- Shared variables :**
- DRI_REF_GBX (& → @)
 - DRI_REF_SPEED (& → @)
 - CMD_ANTI_WINDUP (\$ → @)
 - DRI_GBX_SP (@ → \$)
 - DRI_TQ_SP (@ → \$)
 - DRI_CLUTCH_SP (@ → \$)
 - START (@ → \$)
 - DRI_CMD_BRAKE (@ → \$)

- Command modules :**
- Reference (NEDC) (&)
 - Driver1 (@)
 - Command (\$)

CAN B

CAN B