

## JTAG Adapters and Interposers

JTAG adapters and interposers fit on the end of personality modules or flex cables that runs from the emulator to a device under test (target). These products may be purchased separately and can be used with Arium JTAG debuggers (emulators) for ARM and Intel respectively.

### JTAG Test Access Ports, Adapters, & Reference Boards



#### HSS-ARM

High speed serial trace port adapter supporting ARM HSSTP and Marvell SETM 3 (2 lanes at 6.25 GHz).



#### HSS-MRV

High speed serial trace adapter for the HS-1000S supporting Marvell SETM 2 (2 lanes at 6.25 GHz).



#### ARM-TI-ADP

ARM to TI OMAP adapter



#### ITP-XDP-SSA

ITP to SSA Adapter



#### XDP-SFF-26

26->60-pin adapter to small ITP JTAG port. For boards with debug ports whose pins lie parallel to the board. For use with ECM-50/PBD-XDP, ECM-XDP, and ECM-XDP3.



#### XDP-SFF-24

24->60-pin adapter to small ITP JTAG port. For boards with debug ports whose pins lie parallel to the board. For use with ECM-50/PBD-XDP, ECM-XDP, and ECM-XDP3.



#### ITP-FLXXDP

28->60-pin adapter to small ITP JTAG port. For more information, see the Intel Debug Port Design Guide([www.arium.com](http://www.arium.com)) for UP/DP Systems. For boards with debug ports whose pins lie parallel to the board. For use with ECM-50/PBD-XDP, ECM-XDP, and ECM-XDP3.



#### ITP-FLX

25->28-pin adapter to small ITP JTAG port. For more information, see the Intel ITP700 Debug Port Design Guide ([www.arium.com](http://www.arium.com)). For boards with debug ports whose pins lie parallel to the board. For use with ECM-50/PBD-700/700M.



#### TAP-MB

Interposer board for Intel® Core™2 Duo processor (Socket P). For boards without debug ports. For use with ECM-50/PBD-XDP, ECM-XDP, and ECM-XDP3.



#### TAP-YM

Interposer board for Intel® Core™ Solo and Intel® Core™ Duo processors (Socket M). For boards without debug ports. For use with ECM-50/PBD-XDP, ECM-XDP, and ECM-XDP3.



#### **TAP-BN**

Interposer board for Intel® Pentium® M processors (478-pin PGA). For boards without debug ports. For use with ECM-50/PBD-700/700M.



#### **TAP-WT**

Interposer board for Intel Pentium 4 and Xeon® processors (423-pin PGA). For boards without debug ports. For use with ECM-50/PBD-700/700M.

#### **DISTRIBUTOR**



**FLASH TECHNOLOGY PTE LTD**  
**Website : [www.flashtech.com.sg](http://www.flashtech.com.sg)**  
**Email : [sales@flashtech.com.sg](mailto:sales@flashtech.com.sg)**  
**Tel : +65 6749 6168**