

# Instructions For Use

1. *Turn on PC.*
2. *Login*
3. *Turn on PLC*
4. *Turn on robot.*
5. *Turn on drive 1.*
6. *Turn on drive 2.*
7. *Open HMI from the windows desktop.*
8. *Reset errors.*
9. *Run.*