

## Device: Panasonic AW-RP120/AW-RP150



### Introduction

The Device Core for the Panasonic AW-RP120 and the AW-RP150 have few but very practical actions.


Among other things the Device Core can be used to get routing control on external hardware based on Group Select/Camera Select on the AW-RP120/150. For instance to perform routing on AJA KUMO, Blackmagic VideoHub or ATEM (AUX) for the PTZ operators engineering monitor.

Other applications includes recalling presets from a SKAARHOJ panel.


For inspiration using the Device Core for routing control check our the default config "Panasonic AW-RP1xx" on the ETH-GPI Link from [cores.skaarhoj.com](http://cores.skaarhoj.com).

## Setting up Controller


The Device Core "Panasonic AW-RP1xx" must be added to your controller



The Device Cores IP address must have the same IP address as the AW-RP1xx. Connection to the AW-RP1xx can be confirmed from the Serial Monitor with the command: *Connected to AW-RP1x0 @ 192.168.10.243*



If connection is lost the serial monitor will report: *Lost connection to AW-RP1x0 @ 192.168.10.243*



This is a overview of the actions implemented in the Device Core

Panasonic AW-RP1xx: Port Select  
✓ Panasonic AW-RP1xx: Group Select  
Panasonic AW-RP1xx: Recall Preset  
Panasonic AW-RP1xx: Standby Trace  
Panasonic AW-RP1xx: Start Trace  
Panasonic AW-RP1xx: Stop Trace