



EVR ATA CONFIGURATION MANUAL

Abisai Ngalande

Table of Contents

Features and Description.....	3
Connections.....	3
Configuration.....	4
Entering connection details.....	4
1Select Quick Setup.....	4
2Click on Network Service Tab.....	4
3Network Settings.....	4

Features and Description.

Feature	Description	Comment
Reset	If pressed briefly it will reboot the ATA. Press and hold it will reset the device to factory default	
Phone 1 Phone 2	Using an RJ-11 phone cable connect to either one or both ports, connect to an analog phone.	
Ethernet (Yellow)	Connect to computer, or the local network using Ethernet cable.	
Internet (Blue)	Connect to a broadband network, or a route network.	
DC 5V Power	Connect 5V power source using the right cable	



Connections

1. Connect an analog phone to port 1.
2. Connect computer to Ethernet port using Ethernet cable.
3. Connect another Ethernet to the internet port and to the network on the other side
4. Connect power cable.

Configuration

The computer will get an IP address from ATA, which will be 192.168.15.0 network.

1. Log in the ATA using 192.168.15.1 through browser, this is default IP address.
2. Enter username and password as admin

Entering connection details

1 Select Quick Setup

Line 1

1. Proxy = 192.168.84.3
2. Display Name = “*Village name*”
3. Password = Mtema01

Line 2

Enter the same details as line 1

2 Click on Network Service Tab

1. Click on a drop down menu and select “*BRIDGE*”
2. Click submit to save

3 Network Settings

1. Select static and enter
 - IP address 192.168.100.5
 - Netmask 255.255.255.0
 - Gateway 192.168.100.1
 - Host name “*village’s name*”
2. Submit

Done