

TANDY®

**Technician Series
Diagnostics Software**

VIDADAPT

**Video Adapter
Diagnostics**

01-0220 Computer Technical Services

IMPORTANT
READ THIS BEFORE USING THIS PRODUCT

This is a legal agreement between you, the end user, and Tandy Corporation. BY OPENING THIS SEALED PRODUCT, YOU ARE AGREEING TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNOPENED SEALED PRODUCT AND THE ACCOMPANYING ITEMS (including written materials and binders or other containers) TO THE PLACE YOU OBTAINED THEM FOR A FULL REFUND.

TANDY SOFTWARE LICENSE

1. **GRANT OF LICENSE.** Tandy grants to you the right to use one copy of the enclosed Tandy software program (the "SOFTWARE") on a single terminal connected to a single computer (i.e. with a single CPU). You may not network the SOFTWARE or otherwise use it on more than one computer or computer terminal at the same time.
2. **COPYRIGHT.** The SOFTWARE is owned by Tandy or its suppliers and is protected by United States copyright laws and international treaty provisions. Therefore, you must treat the SOFTWARE like any other copyrighted material (e.g. a book or musical recording) except that you may either (a) make one copy of the SOFTWARE solely for backup or archival purposes, or (b) transfer the SOFTWARE to a single hard disk provided you keep the original solely for backup or archival purposes. You may not copy the written materials accompanying the SOFTWARE.
3. **OTHER RESTRICTIONS.** You may not rent or lease the SOFTWARE, but you may transfer the SOFTWARE and accompanying written materials on a permanent basis provided you retain no copies and the recipient agrees to the terms of this Agreement. You may not reverse engineer, decompile or disassemble the SOFTWARE.
4. **DUAL MEDIA SOFTWARE.** If the SOFTWARE package contains both 3-1/2" and 5-1/4" disks, then you may use only the disks appropriate for your single-user computer. You may not use the other disks on another computer or loan, rent, lease, or transfer them to another user except as part of the permanent transfer (as provided above) of all SOFTWARE and written materials.

LIMITED WARRANTY

LIMITED WARRANTY. Tandy warrants that (a) the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt; and (b) any hardware accompanying the SOFTWARE will be free from defects in materials and workmanship under normal use and service for a period of one (1) year from the date of receipt. Any implied warranties on the SOFTWARE and hardware are limited to ninety (90) days and one (1) year, respectively. Some states do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

CUSTOMER REMEDIES. Tandy's entire liability and your exclusive remedy shall be, at Tandy's option, either (a) return of the price paid or (b) repair or replacement of the SOFTWARE or hardware that does not meet Tandy's Limited Warranty and which is returned to Tandy with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE or hardware has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

NO OTHER WARRANTIES. TANDY DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO THE SOFTWARE, THE ACCOMPANYING WRITTEN MATERIALS, AND ANY ACCOMPANYING HARDWARE. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE TO STATE.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES. IN NO EVENT SHALL TANDY OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THIS TANDY PRODUCT, EVEN IF TANDY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

U.S. GOVERNMENT RESTRICTED RIGHTS

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (II) of The Rights in Technical Data and Computer Software clause at 52.227-7013. Contractor/manufacturer is Tandy Corporation, Fort Worth, Texas 76102, U.S.A.

This Agreement is governed by the laws of the State of Texas.

Should you have any questions concerning this Agreement, or if you desire to contact Tandy for any reason, please write: Tandy Customer Sales and Service, One Tandy Center, Fort Worth, Texas 76102.

91-256WP

04-161k

VIDADAPT DIAGNOSTIC
© 1989, Tandy Corporation
All Rights Reserved.

Reproduction or use, without express written permission from Tandy Corporation, of any portion of this manual is prohibited. While reasonable efforts have been taken in the preparation of this manual to assure its accuracy, Tandy Corporation assumes no liability resulting from any errors or omissions in this manual, or from the use of the information obtained herein.

Please refer to the Software License on the first page of this manual for limitations on use and reproduction of this Software package.

Important Notice:

This diagnostic software and manual are written for Tandy™ computer owners who have a thorough understanding of electronics and computer circuitry. It is not written at a comprehension level for the beginner.

Radio Shack® will not be liable for any damage caused, or alleged to be caused, by the customer or any other person using this diagnostic software or manual to repair, modify, or alter any Tandy™ computer in any manner.

Many parts of the computer electronics are very sensitive and can be easily damaged by improper servicing. We strongly suggest that for proper servicing, the computer be returned to Radio Shack®.

While this diagnostic software and manual have been carefully prepared, Radio Shack® will not be responsible for any errors or omissions and will not be liable for damages resulting therefrom.

Opening the Tandy™ computer housing, breaking the housing seal, or altering or modifying the computer may void the warranties given at time of purchase.

TANDY COMPUTER PRODUCTS

VIDADAPT DIAGNOSTIC

TABLE OF CONTENTS

GENERAL DESCRIPTION	5
FEATURES	5
EQUIPMENT REQUIRED	5
LOADING VIDADAPT	5
OPERATING VIDADAPT	5
MAIN DISPLAY DESCRIPTION	6
Active Display Port	6
Color Display Port	6
Mono Display Port	6
Standard Modes	6
Special Modes	6
Options	6
COMMANDS	7
Select Standard Mode	7
Select Special Mode	7
Toggle Active Port	7
Change Adapter/Monitor	7
Exit	7
TEST DESCRIPTIONS	8
STANDARD MODE TESTS	8
Standard Mode Test Display Description	8
Character Set	9
Character Attributes	9
Video Screen Pages	10
Border / Background Color	10
Color Palettes / Rotating Bits	11
Color Bars	13
Purity or Full Screen	13
Dots / Crosshatch	14
Linearity & Focus	14
SPECIAL MODE TESTS	15
Text Modes	15
Graphic Modes	15
Memory Tests	16
Video Memory Test Display Description	17
EGA/VGA ROM Character Sets	18
VGA Split Screen	18
VGA Pixel Scroll & Pan	18
APPENDIX	19
VIDADAPT Supported Video Adapters	19
VIDADAPT Supported Monitors	20
Display Adapter and Monitor Compatibility	20
Video Adapter Standard Modes	21
Video Adapter Special Modes	21
Error Messages	23

GENERAL DESCRIPTION

The VIDADAPT (Video Adapter) diagnostic program allows simple verification of a video adapter display board's functions. By providing a menu driven method of selecting a specific mode, or stepping through all modes, the user is able to visually see if the adapter is functioning.

FEATURES

Wide range of video adapters and monitors supported.

The selection of the video adapter and monitor installed is simplified by allowing the selection of only those adapters compatible with the current video port (color/monochrome), as well as only those monitors compatible with the selected adapter.

Allows testing of all standard video modes as well as any special modes available for the specific video adapter selected.

Dual video system operation. Allows switching between a color and monochrome adapter.

EQUIPMENT REQUIRED

MS-DOS compatible computer.

Video Adapter Display board.

Compatible Video Monitor.

LOADING VIDADAPT

The VIDADAPT program can be loaded either by selecting the appropriate menu selection on a Diagnostic Diskette or at the DOS prompt by typing:

`vidadapt<ENTER>`

OPERATING VIDADAPT

Once loaded, VIDADAPT will display the current video port, color or monochrome, along with all of the supported adapters but highlighting only those compatible with that port. Following this it will prompt for the selection of the Primary video adapter. Once the Primary adapter is selected it redisplayes the adapters highlighting only those compatible with the other video port. The prompt then asks for the selection of the Secondary adapter.

With the video adapter, or adapters, selected, VIDADAPT displays all of the supported video monitors highlighting only those compatible with the Primary video adapter. If there was a Secondary adapter selected the monitors selection is redisplayed highlighting only those compatible with the Secondary adapter.

Once the adapters and monitors are selected the main screen is displayed.

MAIN DISPLAY DESCRIPTION

VIDADAPT main screen:

ACTIVE	Port: 03D4H	COLOR	Port: 03D4H	MONO	Port: 03B4H
DISPLAY	Adapter: VGA	DISPLAY	Adapter: VGA	DISPLAY	Adapter: None
PORT	Monitor: VGA-C	PORT	Monitor: VGA-C	PORT	Monitor: None

ADAPTER STANDARD MODES	ADAPTER SPECIAL MODES
40 x 25 Text Grey 40 x 25 Text Color 80 x 25 Text Grey 80 x 25 Text Color 320 x 200 x 4 Color 320 x 200 x 4 Grey 640 x 200 x 2 Color 80 x 25 Text Mono	320 x 200 x 16 Color 640 x 200 x 16 Color 640 x 350 Monochrome 640 x 350 x 16 Color 640 x 480 x 16 Color 320 x 200 x 256 Color Split Screen Pixel Scroll & Pan ROM Character Sets Memory Test

F1:Select Standard Mode
F2:Select Special Mode

F3:Toggle Active Port
F4:Change Adapter/Monitor

ESC:Exit
Selection: _

The VIDADAPT main screen can be divided into six (6) sections:

Active Display Port
Standard Modes

Color Display Port
Special Modes

Mono Display Port
Options

Active Display Port: Displays the current video port, adapter and monitor being tested.

Color Display Port: Displays the selected adapter and monitor for the color port.

Mono Display Port: Displays the selected adapter and monitor for the monochrome port.

Standard Modes: Displays the standard video modes which may be tested for the active video adapter, highlighting the modes available for the current port, color or monochrome.

Special Modes: Displays the special video modes which may be tested for the active video adapter, highlighting the modes available for the current port, color or monochrome.

Options: Displays the currently available commands along with their associated keyboard entries.

COMMANDS**SELECT STANDARD MODE:**

Pressing <F1>, Select Standard Mode, places the selection bar over the current mode within the Adapter Standard Mode section. By using the Up and Down arrow keys the selection bar will step between the modes available for testing. Pressing <ENTER> will select the video mode highlighted by the selection bar.

SELECT SPECIAL MODE:

Pressing <F2>, Select Special Mode, places the selection bar over the first compatible mode within the Adapter Special Mode section. By using the Up and Down arrow keys the selection bar will step between the modes available for testing. Pressing <ENTER> will select the video mode highlighted by the selection bar.

TOGGLE ACTIVE PORT:

Pressing <F3>, Toggle Active Port, changes the current active display port (color or monochrome) to the other port (monochrome or color). If a secondary adapter was not selected the following error message will appear;

Port Inactive, Secondary Adapter Was Not Specified.

Pressing any key will clear the error message.

CHANGE ADAPTER/MONITOR:

Pressing <F4>, Change Adapter/Monitor, returns to the initial adapter selection screen. This allows selecting a new adapter/monitor combination.

EXIT:

Pressing <ESC> will exit VIDADAPT and return to the Diagnostics Diskette menu or the DOS prompt depending on how VIDADAPT was loaded.

TANDY COMPUTER PRODUCTS

TEST DESCRIPTIONS

STANDARD MODE TESTS

STANDARD MODE TESTS DISPLAY DESCRIPTION:

When a mode is selected from within the Adapter Standard Modes section, the Standard Mode Tests screen is displayed.

STANDARD MODE TESTS	
Test Mode: 80 x 25 Text Color	
Adapter Tests:	1. Character Set 2. Character Attributes 3. Video Screen Pages 4. Border / Background Color
Video Maintenance Aids:	5. Color Palettes / Rotating Bits 6. Color Bars
Tests 5-9 default to Text mode.	7. Purity or Full Screen 8. Dots / Crosshatch 9. Linearity & Focus

1-9:Select Test

ESC:Main Menu

Selection:

The Standard Mode Tests screen can be divided into four (4) sections:

Test Mode	Adapter Tests	Video Maintenance Aids	Options
-----------	---------------	------------------------	---------

Test Mode: Displays the currently selected video mode.

Adapter Tests: Displays the standard mode tests available.

Video Maintenance Aids: Displays the functions available to aid with the alignment of the video monitor as well as troubleshooting the video output signals of the video adapter.

Options: Displays the currently available commands along with their associated keyboard entries.

CHARACTER SET:

This test fills the screen with the ASCII character set of the video adapter. It starts with the first display attribute and then repeats rotating through all available attributes.

Pressing <P> will pause the test leaving a full screen with the current attribute while <ESC> will exit and return to the Standard Mode Test screen.

CHARACTER ATTRIBUTES:

The Character Attributes test displays all of the available attribute combinations. Depending on the current video mode selected this test will respond in one of four ways:

Text 40 Column: In these modes the attribute combinations are displayed in three tables. Each table has the Background color listed across the top and the Foreground color down the left side. A sample of the resulting attribute is displayed where the Background (Column) and Foreground (Row) meet.

Text 80 Column: In these modes the attribute combinations are displayed in a table format. Across the top are the Background colors and down the left side are the Foreground colors. A sample of the resulting attribute is displayed where the Background (Column) and Foreground (Row) meet.

320 x 200 x 4: In the four color graphic modes the character attributes available are defined in two Palettes. A Palette consists of three Foreground colors and one Background color. While the Background color can be any of the standard sixteen colors the three Foreground colors are usually predefined. The Character Attributes test will display the first Palette and then cycle through all of the Background colors. It will then repeat the process for the second Palette.

640 x 200 x 2: In the two color graphic mode the attributes available consist of one Foreground color, one Background color, and on some display adapters a Border color is allowed. Normally the Foreground color can not be changed, however the Background and Border, if supported, can be any of the standard sixteen colors. The test will display a Background color, cycle through the Border colors and then repeat for the remainder of the Background colors. The one Foreground color is the color of the text on the screen.

NOTES: On the text attribute tables not all color combinations are visible. Black Foreground and Black Background, Blue Foreground and Blue Background are a few examples.

On the Grid 140XT, GDA, GMDA, and DGDA adapters in the 320 x 200 graphic modes the border characters will not be the standard double bar characters but some unrecognizable dot patterns. This is caused by the board's character set and should not be considered a problem.

On the 1000, 1400LT and GDA adapters in 320 x 200 gray mode the palette colors are not as listed and they do not change. The colors are always Cyan, Red, and White.

VIDEO SCREEN PAGES:

Standard text mode video memory consists of 16 Kilobytes. The amount of memory required to fill the entire screen is called a Page. The actual memory required for one Page will vary depending on the video mode. The Video Screen Pages test fills each page with the ASCII number representing that page. It will then display the first Page of memory which should fill the screen with the number 1. In the center of the screen will then be displayed how many Pages are available and which one is currently being displayed. Pressing any key will cause the next Page of memory to be displayed. The entire screen, except for the center description box, should be filled with the number of the current video Page.

BORDER / BACKGROUND COLOR:

The Border, or overscan, area of the screen is the area outside the normal display area. Some Display Adapters support the ability to change the normally black Border to any of the standard colors. The Border / Background Color test will display a Background color, cycle through the Border colors and then repeat for the remainder of the Background colors.

Because not all of the Display Adapters support a Border, and those that do may not support it in all video modes, there may be a special message displayed describing any limitations the current Display Adapter has within the current video mode.


NOTES: 640x200x2 Mode - The Border / Background test starts with a black background. With the Tandy 1000 in this mode the text color is the background color. There will therefore be a short delay once the test is started before anything visible appears on the screen. This is normal operation.

Color/Grey Modes - With most color display adapters there will not be any noticeable difference between the Color and Grey video modes. The Grey modes simply disable the color burst to composite monitors. RGB monitors are not effected by the color burst signal.

COLOR PALETTES / ROTATING BITS:

The different colors of text are created by a special Attribute byte. Each bit of the byte signifies a single color or function which when combined with the others delivers the desired character Attribute. The Color Palettes / Rotating Bits test is used to display which of the bits within this Attribute byte are used to create the displayed color. This information is intended to aid in determining which, if any, of the video output signals is not reaching the monitor. Depending on the Display Adapter selected this test may respond in one of three ways:

CGA/Monochrome: The CGA attribute byte consists of one bit each for Red, Green and Blue Foreground, one bit each for Red, Green and Blue Background, plus one bit for High Intensity and one bit for Blinking. With this attribute byte configuration it is possible to display 16 colors, 8 in low intensity and 8 in high intensity.



The Monochrome attribute byte uses the same bit arrangement with a different meaning:

BACKGND				FOREGND				RESULT
B	R	G	B	I	R	G	B	
0	0	0	0	0	0	0	0	= Black Character on Black
0	0	0	0	0	0	0	1	= Underline
0	0	0	0	0	1	1	1	= White Character on Black
0	0	0	0	1	1	1	1	= Bright White on Black
1	0	0	0	0	1	1	1	= Blinking White on Black
1	0	0	0	1	1	1	1	= Blinking Bright White on Black
0	1	1	1	0	0	0	0	= Black Character on White
1	1	1	1	0	0	0	0	= Blinking Black on White

NOTE: All other combinations are undefined and may vary between Display Adapters.

TANDY COMPUTER PRODUCTS

The right side of the display will fill with eight blocks with each block displaying a different attribute. On the left side will be displayed the RGB bit pattern including the Blink and Intensity bits. The arrow is pointing to the attribute block currently being displayed in binary and decimal format.

The Attribute blocks will start incrementing in value so as to display all the possible combinations, 0 through 255. Pressing <SPACE> will stop the rotation leaving the current attribute block's binary value displayed. Pressing <SPACE> again allows single stepping through the Attributes while pressing <ENTER> will start the auto stepping again. Pressing <ESC> will exit the test.

EGA: The EGA attribute byte consists of two bits each for Red, Green and Blue. With this attribute byte configuration it is possible to display 64 colors.

With the EGA Display Adapter this test first displays a block of the three possible combinations of the two Red, Green and Blue signals. The display should show three shades of Red, three of Green and three of Blue.

Pressing any key continues to the next phase of the test which displays the same three shades of each again only filling the screen one at a time. Pressing any key advances to the next color.

With the full screens finished the third and final phase of the test starts. This test is very similar to the CGA/Monochrome Rotating bits with the exception of the colors and bit patterns being displayed.

The Attribute blocks will start incrementing in value so as to display all the possible combinations, 0 through 64 (displayed in binary and hex). Pressing <SPACE> will stop the rotation leaving the current attribute block's binary value displayed. Pressing <SPACE> again allows single stepping through the Attributes while pressing <ENTER> will start the auto stepping again. Pressing <ESC> will exit the test.

VGA: The VGA Attribute consists of three bytes, one byte for the Red, Green and Blue colors. Each byte may contain a value from 0 to 63. As the value of a color increases the level of the color increases. As an example a value of 0 for the Red byte would result in no trace of Red color. A value of 30 would produce a medium shade of Red where a value of 63 would produce a

bright Red. With the three Attribute bytes in combination it is possible to display 256 colors.

With the VGA Display Adapter this test first displays four blocks, Red alone, Green alone, Blue alone and finally Red, Green and Blue combined (White). Each block will contain all the possible shades of the specified color.

Pressing any key continues to the next phase of the test. At this point the test allows the user to increase or decrease each of the three attribute bytes. As this is being done the Decimal and Binary values of each byte are displayed.

Pressing <1> increases the Red attribute value.
Pressing <2> decreases the Red attribute value.

Pressing <3> increases the Green attribute value.
Pressing <4> decreases the Green attribute value.

Pressing <5> increases the Blue attribute value.
Pressing <6> decreases the Blue attribute value.

Pressing <ESC> exits the test.

COLOR BARS:

The Color Bars test will display 16 vertical color bars on color adapters and 3 vertical bars on monochrome adapters, one for each of the standard colors on that type of adapter. Using the left or right arrow keys the bars may be rotated left or right respectively. This test is used to aid in the alignment of the video monitor.

PURITY OR FULL SCREEN:

This test is used to aid in the purity alignment of the video monitor. It will fill the screen with one color at a time. Pressing any key will step to the next color causing it to rotate through all of the standard colors. Pressing <ESC> will exit the test.

Correct purity is reached when all screens are only the color specified. There should not be any color changes around the edges of the screen.

NOTE: If you are using an EGA adapter see the 25-4037 note on the following page.

DOTS / CROSSHATCH:

This test is used to aid in the convergence alignment of the video monitor. It will fill the screen with several rows of white dots. Pressing any key will toggle the display of dots to a crosshatch display using lines. Pressing <ESC> will exit the test.

Correct convergence is accomplished when all of the dots and lines are white, or without any color visible around the edges.

NOTE: The right most column defined by the dots or lines is narrower than the other columns on the display. A message to this effect is displayed in that column.

If you are using an EGA adapter see the 25-4037 note on this page.

LINEARITY & FOCUS:

This test is used to aid in the linearity and focus adjustments of the video monitor. It will display a box in each corner and the center of the screen along with a group of 'H's between the boxes. Pressing any key will exit the test.

Correct linearity is accomplished when all of the boxes and characters are the same size vertically and horizontally. Correct focus is reached when all of the characters are clear and sharp.

25-3048 NOTE: With the 25-4037 EGA adapter and an EGM-1 monitor there is an additional option of switching the adapter between EGA and CGA mode within the Purity, Dots / Crosshatch and Linearity & Focus tests. This allows adjustment of the monitor in both modes while displaying the same screen. However to accomplish this the adapter must be jumpered as if it was attached to a CGA monitor. As noted on the screen in these tests, pressing <F1> will toggle between CGA and EGA modes.

SPECIAL MODE TESTS

TEXT MODES:

All of the special text modes perform basically the same way. Each will fill the screen with the ASCII character set using the specified number of rows and columns. Exiting the test will change depending on adapter type:

Monochrome and EGA: The Monochrome and EGA adapters will only display the text in white characters. Pressing any key will exit the test.

Color: The color modes will display the character set using a different attribute for each screen full. Pressing <P> will pause the test with a full screen using the current attribute while pressing <ESC> will exit.

GRAPHIC MODES:

All of the special graphic modes perform the same way. A horizontal bar is drawn across the top and a vertical bar down the left. Axis marks are placed on both bars 50 dot columns apart. In the center of the screen a color bar will be drawn. The number of colors within this bar will vary depending on the video mode. Pressing any key will exit the test unless the current video mode uses palettes. In this case pressing a key the first time will cause the display to switch palettes. Then pressing a key the second time will exit the test.

NOTE: VGA 640x480x16 - The axis mark message is normally displayed above the color bar. However, due to the memory arrangement of the VGA in the 640x480x16 mode this message will overlap the color bar slightly.

MEMORY TESTS:

When a memory test is selected the Video Memory Tests option screen is displayed:

VIDEO MEMORY TESTS		Adapter's Memory Size: 256K
Test Pattern: Checkerboard	Test Mode: Single	Errors: 00000
Test Options:	<ol style="list-style-type: none">1. Test Adapter Memory2. Toggle Test Pattern3. Toggle Test Mode	

1-3:Select Test

ESC:Main Menu

Selection:

Every display adapter has a memory test option. However, not all adapters have the memory they use located on the adapter's board. Those that don't have their own memory share the system's memory located on the main logic board. VIDADAPT knows how much memory each adapter uses and displays that amount as Adapter's Memory Size.

The default Test Pattern, Test Mode and the Error count of the last test are then displayed as well as the current options.

Test Adapter Memory: This option uses the current Test Pattern, Test Mode and Memory Size, displays the memory test screen and begins testing.

Toggle Test Pattern: There are two test patterns that can be used on each adapter. For CGA and Monochrome modes they are Checkerboard and All Bits On/Off. For EGA and VGA the patterns are Checkerboard and Modified Address. This option allows the selection of the desired pattern.

Toggle Test Mode: Testing can be done with a single pass or continuously. This option allows the selection of single or continuous testing.

Errors: Displays the error count from the previous test.

Exit: Pressing <ESC> exits the memory test and returns to the main menu.

MEMORY TEST DISPLAY DESCRIPTION:

TEST CONFIGURATION		TEST STATUS		
TEST PATTERN: Checkerboard		TESTING: Page 1, Plane 0		
TEST MODE: Single		PASS: 00001		
MEMORY SIZE: 256K		ERROR COUNT: 00000		

*** ERROR LOG ***				
SEGMENT : OFFSET	WRITTEN	READ	(MSB) BAD BIT (LSB)	PASS

P:Pause Test

ESC:Option Menu

The Memory Test screen can be divided into four (4) sections:

TEST CONFIGURATION**TEST STATUS****ERROR LOG****OPTIONS**

Test Configuration: This box displays the Test Pattern, Test Mode and Memory Size configuration currently being used.

Test Status: This area displays the current memory location being tested as well as the current pass and error count. The current location being tested is normally displayed in the Segment:Offset format. The three exceptions are the EGA, VGA and GMDA adapters.

The EGA and VGA adapters have 256K of memory however only 64K is mapped into the system at any one time. The current location is displayed as Page x, Plane x. The 256K of memory is arranged into 2 pages of 4 planes per page. Each plane consists of 32K, so with 8 planes the total memory comes to 256K. At any given time only two planes are addressed into the system memory, one plane for Page 0 and one for Page 1, for a total of 64K.

TANDY COMPUTER PRODUCTS

The GMDA display adapter has 128K of memory with only 64K mapped into the system at any one time. The current location is displayed as Segment:Offset Bank x. The 128K of memory is arranged into 2 Banks of 64K. The test will start at address A000:0000 and go to A000:FFFF testing Bank 0. It will then repeat the same address range but test Bank 1.

Error Log: When a memory error occurs this area displays the information relative to the error.

Location - Address of error occurred displayed in the format described above.
Written - Test pattern written to location displayed in hex.
Read - Pattern read back from location displayed in hex.
Bad Bit - Differences between pattern written and read displayed in binary. An 'X' indicates a bit that was different between the word read and written. The bits are read right to left (bit 0 is on the right).
Pass - Pass the error occurred.

Options: Displays the currently available commands.

EGA/VGA ROM CHARACTER SETS:

The EGA and VGA display adapters have two (2) character sets in ROM. The EGA's sets use an 8x8 and 8x14 matrix whereas the VGA uses a 8x8 and 8x16 matrix. This test displays both to confirm the ROM character sets are operational.

VGA SPLIT SCREEN:

The VGA display adapter contains internal registers which allow the division of the display buffer. This test confirms the operation of these registers by displaying the first half of the buffer and then moving the second half up and back down the first.

VGA PIXEL SCROLL & PAN:

The VGA display adapter contains internal registers which allow shifting, vertically and horizontally, the display buffer in one pixel increments. This test confirms the operation of these registers by shifting vertically (scroll) and horizontally (pan) a section of the display. If they are working correctly the effect should be a fairly smooth movement of the display.

APPENDIX

VIDADAPT SUPPORTED VIDEO ADAPTERS

CATALOG NUMBER	DESCRIPTION	ABBR.
25-3040	Monochrome Display Adapter	MDA
25-3043	Graphics Display Adapter	GDA
25-3044	Graphics Master Display Adapter	GMDA
25-3045, 25-3045A	Dual Display Graphics Adapter	DDGA
25-3046, 25-3046B 25-3046C	Deluxe Text Display Adapter	DTDA
25-3047	Deluxe Graphics Display Adapter	DGDA
25-3048, 25-4037	Enhanced Graphics Adapter	EGA
25-1000, 25-1050 25-1051, 25-1600 25-1053, 25-1401 25-1601	Tandy 1000 Series	1000
25-6000, 25-4043	Video Graphics Array Adapter	VGA
25-3500, 25-3501 25-3505	Tandy 1400LT	1400
25-3049	Monochrome Graphics Adapter w/Parallel	MGAP

TANDY COMPUTER PRODUCTS

VIDADAPT SUPPORTED MONITORS

CATALOG NUMBER	DESCRIPTION	ABBR.
26-5111	VM-1 400 Line Monochrome	VM-1
26-3211, 25-1020	VM-2, VM-4 Composite	COMP
25-3010, 25-3011 25-3012	VM-3, VM-5 Monochrome	MONO
26-5112	CM-1 400 Line Color	CM-1
26-3232, 25-1021 25-1023, 25-1023A 25-1023B 25-1023C 25-1022, 25-1024 25-1043, 25-1043A	CM-2, CM-4, CM-5, CM-10, CM-11 Color	COLOR
25-4035, 25-4035A	EGM-1 Enhanced Graphics	EGM-1
25-4040	VGM-100 Monochrome	VGA-M
25-4041, 25-4042	VGM-200, VGM-300 Color	VGA-C
25-3500, 25-3501 25-3505	Liquid Crystal Display	LCD

DISPLAY ADAPTER AND MONITOR COMPATIBILITY

MONITOR	MDA	GDA	GMDA	DDGA	DTDA	DGDA	EGA	1000	VGA	1400	MGAP
VM-1					X	X	X ¹				
Comp		X	X	X				X			
Mono	X	X	X	X			X	X			X
CM-1					X	X	X ¹				
Color		X	X	X			X	X		X	
EGM-1							X				
VGA-M									X		
VGA-C									X		
LCD										X	

1 - The VM-1 and CM-1 are only compatible with the 25-4037 EGA adapter.

TANDY COMPUTER PRODUCTS**VIDEO ADAPTER STANDARD MODES**

STANDARD MODE	MDA	GDA	GMDA	DDGA	DTDA	DGDA	EGA	1000	VGA	1400	MGAP
40 x 25 Text Grey		C	C	C		C/M	C/M	C	C	C	
40 x 25 Text Color		C	C	C		C/M	C/M	C	C	C	
80 x 25 Text Grey		C	C	C		C/M	C/M	C	C	C	
80 x 25 Text Color		C	C	C		C/M	C/M	C	C	C	
320 x 200 x 4 Color		C	C	C		C/M	C/M	C	C	C	
320 x 200 x 4 Grey		C	C	C		C/M	C/M	C	C	C	
640 x 200 x 2 Color		C	C	C		C/M	C/M	C	C	C	
80 x 25 Text Mono	M		M	M	M	C/M	M	M	M		M

C = Supported In Color Mode Only

C/M = Supported In Both Color & Mono

M = Supported In Monochrome Mode Only

Blank = Not Supported

VIDEO ADAPTER SPECIAL MODES

VIDEO ADAPTER	SPECIAL MODE	COLOR	MONO
MDA - Monochrome Display Adapter	Memory Test		X
GDA - Graphics Display Adapter	Memory Test	X	
GMDA - Graphics Master Display Adapter	40 x 16 Text Color	X	
	40 x 43 Text Mono		X
	80 x 16 Text Color	X	
	80 x 43 Text Mono		X
	320 x 200 x 16 Color	X	
	640 x 200 x 16 Color	X	
	640 x 704 Mono		X
	720 x 200 x 4 Color	X	
DDGA - Dual Display Graphics Adapter	720 x 704 Mono		X
	Memory Test	X	X
	132 x 25 Text Mono		X
	132 x 44 Text Mono		X
	320 x 200 x 16 Color	X	
	640 x 200 x 4 Color	X	
DTDA - Deluxe Text Display Adapter	640 x 200 x 16 Color	X	
	Memory Test	X	X
	Memory Test		X

TANDY COMPUTER PRODUCTS

VIDEO ADAPTER SPECIAL MODES (cont.)

VIDEO ADAPTER	SPECIAL MODE	COLOR	MONO
DGDA - Deluxe Graphics Display Adapter	80 x 50 Text Color	X	
	320 x 200 x 16 Color	X	
	320 x 400 x 16 Color	X	
	640 x 200 x 4 Color	X	
	640 x 400 x 2 Mono		X
	640 x 400 x 4 Color	X	
	Memory Test	X	X
EGA - Enhanced Graphics Adapter	80 x 43 Text Mono		X
	320 x 200 x 16 Color	X	
	640 x 200 x 16 Color	X	
	640 x 350 Monochrome		X
	640 x 350 x 16 Color	X	
	ROM Character Sets	X	X
	Memory Test	X	X
1000 - Tandy 1000 Series (Built In)	160 x 200 x 16 Color	X	
	320 x 200 x 16 Color	X	
	640 x 200 x 4 Color	X	
	Memory Test	X	X
VGA - Video Graphics Array Adapter	320 x 200 x 16 Color	X	
	640 x 200 x 16 Color	X	
	640 x 350 Monochrome		X
	640 x 350 x 16 Color	X	
	640 x 480 x 16 Color	X	
	320 x 200 x 256 Color	X	
	Split Screen	X	X
	Pixel Scroll & Pan	X	X
	ROM Character Sets	X	X
	Memory Test	X	X
1400 - Tandy 1400LT / Grid 140XT	Memory Test	X	
MGAP - Monochrome Graphics Adapter With Parallel Port	720 x 348 Monochrome		X
	Memory Test		X

ERROR MESSAGES:**Selected Adapter Is NOT Compatible With Video Port.**

This message appears during the display adapter selection if the adapter is not supported on the current video port.

Selected Monitor Is NOT Compatible With Selected Adapter.

This message appears during the monitor selection if the monitor is not supported with the current display adapter.

Port Inactive, Secondary Adapter Was Not Specified.

This message appears during the Toggle Active Port command if there was no secondary port selected.

This Mode Requires The Enhanced Graphics Monitor (EGM-1)

This message appears if an enhanced EGA mode is selected and the current monitor is not the EGM-1.

The Adapter Must Be In EGA Mode Using The CM-1 Or EGM-1

This message appears if an enhanced EGA mode is selected and the current monitor is not the CM-1 or EGM-1.

SERVICE POLICY

Radio Shack's nationwide network of service facilities provides quick, convenient, and reliable repair services for all of its computer products, in most instances. Warranty service will be performed in accordance with Radio Shack's Limited Warranty. Non-warranty service will be provided at reasonable parts and labor costs.

CUSTOM MANUFACTURED FOR RADIO SHACK A Division of Tandy Corporation

**U.S.A.: FORT WORTH, TEXAS 76102
CANADA: BARRIE, ONTARIO L4M 4W5**

TANDY CORPORATION

AUSTRALIA	BELGIUM	FRANCE	U. K.
91 Kurrajong Avenue Mount Druitt, N.S.W. 2770	Rue des Pieds d'Alouette, 39 5140 Naninne (Namur)	Centre Commercial des 3 Fontaines B.P. 147 95022 Cergy Pontoise Cedex	Bilston Road Wednesbury West Midlands WS10 7JN