

TANDY®

**Technician Series
Diagnostics Software**

CMOS

CMOS Memory Diagnostic

01-0220 Computer Technical Services

IMPORTANT
READ THIS BEFORE USING THIS PRODUCT

This is a legal agreement between you, the end user, and Tandy Corporation. BY OPENING THIS SEALED PRODUCT, YOU ARE AGREEING TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNOPENED SEALED PRODUCT AND THE ACCOMPANYING ITEMS (including written materials and binders or other containers) TO THE PLACE YOU OBTAINED THEM FOR A FULL REFUND.

TANDY SOFTWARE LICENSE

1. **GRANT OF LICENSE.** Tandy grants to you the right to use one copy of the enclosed Tandy software program (the "SOFTWARE") on a single terminal connected to a single computer (i.e. with a single CPU). You may not network the SOFTWARE or otherwise use it on more than one computer or computer terminal at the same time.
2. **COPYRIGHT.** The SOFTWARE is owned by Tandy or its suppliers and is protected by United States copyright laws and international treaty provisions. Therefore, you must treat the SOFTWARE like any other copyrighted material (e.g. a book or musical recording) except that you may either (a) make one copy of the SOFTWARE solely for backup or archival purposes, or (b) transfer the SOFTWARE to a single hard disk provided you keep the original solely for backup or archival purposes. You may not copy the written materials accompanying the SOFTWARE.
3. **OTHER RESTRICTIONS.** You may not rent or lease the SOFTWARE, but you may transfer the SOFTWARE and accompanying written materials on a permanent basis provided you retain no copies and the recipient agrees to the terms of this Agreement. You may not reverse engineer, decompile or disassemble the SOFTWARE.
4. **DUAL MEDIA SOFTWARE.** If the SOFTWARE package contains both 3-1/2" and 5-1/4" disks, then you may use only the disks appropriate for your single-user computer. You may not use the other disks on another computer or loan, rent, lease, or transfer them to another user except as part of the permanent transfer (as provided above) of all SOFTWARE and written materials.

LIMITED WARRANTY

LIMITED WARRANTY. Tandy warrants that (a) the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt; and (b) any hardware accompanying the SOFTWARE will be free from defects in materials and workmanship under normal use and service for a period of one (1) year from the date of receipt. Any implied warranties on the SOFTWARE and hardware are limited to ninety (90) days and one (1) year, respectively. Some states do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

CUSTOMER REMEDIES. Tandy's entire liability and your exclusive remedy shall be, at Tandy's option, either (a) return of the price paid or (b) repair or replacement of the SOFTWARE or hardware that does not meet Tandy's Limited Warranty and which is returned to Tandy with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE or hardware has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

NO OTHER WARRANTIES. TANDY DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO THE SOFTWARE, THE ACCOMPANYING WRITTEN MATERIALS, AND ANY ACCOMPANYING HARDWARE. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE TO STATE.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES. IN NO EVENT SHALL TANDY OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THIS TANDY PRODUCT, EVEN IF TANDY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

U.S. GOVERNMENT RESTRICTED RIGHTS

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013. Contractor/manufacturer is Tandy Corporation, Fort Worth, Texas 76102, U.S.A.

This Agreement is governed by the laws of the State of Texas.

Should you have any questions concerning this Agreement, or if you desire to contact Tandy for any reason, please write: Tandy Customer Sales and Service, One Tandy Center, Fort Worth, Texas 76102.

91-256WP

04-161k

CMOS

© 1989, Tandy Corporation
All Rights Reserved.

Reproduction or use, without express written permission from Tandy Corporation, of any portion of this manual is prohibited. While reasonable efforts have been taken in the preparation of this manual to assure its accuracy, Tandy Corporation assumes no liability resulting from any errors or omissions in this manual, or from the use of the information obtained herein.

Please refer to the Software License on the first page of this manual for limitations on use and reproduction of this Software package.

Important Notice:

This diagnostic software and manual are written for Tandy™ computer owners who have a thorough understanding of electronics and computer circuitry. It is not written at a comprehension level for the beginner.

Radio Shack® will not be liable for any damage caused, or alleged to be caused, by the customer or any other person using this diagnostic software or manual to repair, modify, or alter any Tandy™ computer in any manner.

Many parts of the computer electronics are very sensitive and can be easily damaged by improper servicing. We strongly suggest that for proper servicing, the computer be returned to Radio Shack®.

While this diagnostic software and manual have been carefully prepared, Radio Shack® will not be responsible for any errors or omissions and will not be liable for damages resulting therefrom.

Opening the Tandy™ computer housing, breaking the housing seal, or altering or modifying the computer may void the warranties given at time of purchase.

CMOS

TABLE OF CONTENTS

GENERAL DESCRIPTION	5
FEATURES	5
EQUIPMENT REQUIRED	5
LOADING CMOS	5
OPERATING CMOS	5
DISPLAY DESCRIPTION	6
COMMANDS	8
Configuration Screen Commands	8
Test Screen Commands	9
TEST DESCRIPTIONS	10
APPENDIX	11
Error Messages	11
Diagnostic Status Byte	12

GENERAL DESCRIPTION

The CMOS test is a diagnostic designed for the Tandy 3000, 4000, and 5000MC and their GRiD and Panasonic counterparts. In addition to a complete test of the CMOS RAM and status of the flags set on boot-up contained in the diagnostic status byte, the test also permits reconfiguration of the CMOS RAM.

FEATURES

The CMOS test is a menu driven program which permits complete testing of the CMOS RAM regardless of its size. Testing of the CMOS RAM can be done through a selection of four tests in either single or continuous mode. On the Model 5000MC type machines, in addition to the standard CMOS RAM, the extended CMOS RAM can also be tested. An error log is kept containing any errors which occur during the testing process. This error log may be cleared at any time. The CMOS test also allows for the reconfiguration of the CMOS RAM. This configuration may be saved or restored to and from the CMOS RAM.

EQUIPMENT REQUIRED

The CMOS test may be executed on the Tandy 3000, 4000, or 5000MC and their GRiD and Panasonic counterparts. The only other requirement is the appropriate diagnostic disk containing the CMOS program.

LOADING CMOS

There are two ways to access the CMOS diagnostic. The first is through the main menu of the diagnostic disk. The key corresponding to the CMOS test is pressed to load the CMOS program. The second method to access the CMOS diagnostic is directly from MS-DOS. The name of the CMOS diagnostic is typed in at the MS-DOS prompt:

A>CMOS<ENTER>

The machine selection screen will then appear on the screen, unless the test is being executed on one of the 5000MC type machines, in which case the first screen displayed is the CMOS configuration screen.

OPERATING CMOS

After the selection of the machine type, except on the 5000MC family where the configuration screen is shown initially, the configuration screen will be displayed. The configuration screen allows new configurations to be selected, saved, and restored from CMOS. The CMOS test screen can also be accessed from the configuration screen. The test screen displays the status of various items which are contained in the status byte in CMOS. It also contains commands for running the tests and an option to display the error log. Exiting the test screen returns the user to the configuration screen, from which point he can exit the program.

DISPLAY DESCRIPTION

The initial screen displayed upon execution of the CMOS test contains a list of machine types. The number which corresponds to the target machine should be pressed for proper functionality of the CMOS test. After this selection the following screen will appear. This configuration screen is the initial screen when the CMOS test is being run on the 5000MC family.

Tandy CMOS Setup and Test		
XXXXXX XX, XXXX	Version X.XX	
Copyright (c) XXXX, XXXX Tandy Corp. All rights reserved.		
L/R Arrow to Select		Size of CMOS Ram
Bytes of CMOS	128
CPU/BUS Speed	N/A
Diskette Drive A:	1.44M 3½" Floppy
Diskette Drive B:	360K 5¼" Floppy
Diskette Swap Flag	No
Fixed Disk Drive C:	06- 615 4 -1 615 17
Fixed Disk Drive D:	40- 1024 8 1024 1024 17
Prime Video Adapter	EGA/VGA
Math Co-Processor	None
System Base Memory	640K
Expansion Memory	None
Date	August 23,1989
Day of the Week	Wednesday
Time	10:05:47 am
F1: Save Setup to CMOS		F2 : CMOS Tests
F3: Restore Last Setup Saved		ESC: Exit Setup
		↑ : Up
		↓ : Down

The help line is located between the copyright section and the configuration section. This line will change when the highlight bar is moved up and down highlighting different fields. The information on the left indicates which key should be pressed to change the highlighted item. The information on the right describes the current field and its options.

Under the help line is the current configuration of the CMOS RAM. The commands available on this screen are listed at the bottom of the screen. If the command for CMOS tests is selected the following screen will appear.

TANDY COMPUTER PRODUCTS

Tandy CMOS Setup and Test
 XXXXXX XX, XXXX Version X.XX
 Copyright (c) XXXX, XXXX Tandy Corp. All rights reserved.

	Standard	Extended
Checker Board Pattern ...	Not Tested	N/A
Rotating Bit Pattern ...	Not Tested	N/A
Modified Address Pattern ...	Not Tested	N/A
On/Off Bit Pattern ...	Not Tested	N/A
Clock Power Ok ...	Yes	Flags Set on Boot-up
Checksum Status Byte Ok ...	Yes	
Equipment Status ...	Good	
Memory Size Valid ...	Yes	
Hard Drive Status ...	Good	
Time Valid 10:29:06 am ...	Yes	
Installed Adapters OK ...	N/A	
Read Adapter ID ...	N/A	
F1 : Single Test	F3 : Display Error Log	ESC : Exit
F2 : Continuous Test		

This screen displays the possible tests to be run and their status. The extended column is used in the testing of the extended CMOS RAM which is present in the 5000MC family only. After the tests have been run, a passed or failed message will appear.

Under the testing information the status of the flags set in the diagnostic status byte in CMOS RAM are displayed. These flags are set on boot-up; therefore changes in the CMOS configuration will not be reflected in this section until the computer is rebooted. The last two items in the status list pertain to the 5000MC family only.

The commands for the test screen are displayed at the bottom of the screen. In addition to these commands, a command to test extended CMOS (executed by pressing the <F4> key) will be listed when the test is executed on a 5000MC family machine.

COMMANDSConfiguration Screen Commands

<F1> - Save Setup to CMOS

This option saves the current displayed configuration to the CMOS RAM. Any changes made without the execution of this command will not be changed in the CMOS RAM when the program is exited.

<F2> - CMOS Tests

This command displays the CMOS test screen.

<F3> - Restore Last Setup Saved

This command retrieves the current configuration located in CMOS RAM. If changes are made to the displayed configuration after a save has been executed the latest setup that was saved can be restored.

<ESC> - Exit Setup

Pressing the <ESC> key allows the user to exit the program. If the configuration has not been saved a message confirming the exit is displayed. By pressing the <Y> or <y> key the test is exited. If the <N> or <n> key is pressed the exit is aborted.

<↑> - Up

By pressing the <↑> key the highlight bar is moved to the preceding field.

<↓> - Down

By pressing the <↓> key the highlight bar is moved down to the next field.

Test Screen Commands

<F1> - Single Test

This command executes one test. The tests are executed in a sequential order. Each time the <F1> key is pressed the current test in the sequence will be executed. The test being executed is pointed to by an arrow.

<F2> - Continuous Test

This command sequentially executes the tests without input from the user. While in the continuous mode the testing may be paused or stopped. By pressing the <F2> key the testing is paused. To resume continuous testing after the pause has been initiated, any key may be pressed. To abort continuous testing the <F1> key is pressed.

<F3> - Display Error Log

This option displays the errors found by the CMOS tests. The errors will be displayed one at a time from smallest to largest offset at the bottom of the screen. After the last error is shown a message will be displayed inquiring whether or not the error log should be cleared. If the <Y> or <y> key is pressed the log will be cleared. If the <N> or <n> key is pressed the log will not be cleared.

<ESC> - Exit

By pressing the <ESC> key the configuration screen is again displayed.

Model 5000

<F4> - Test Extended CMOS

This command tests the extended CMOS. This option will appear only when the test is being executed on a 5000MC family machine. The errors will be listed in the error log with the standard CMOS errors. When the <F4> key is pressed another set of commands will appear at the bottom of the screen. These commands include single testing which is activated by pressing the <F1> key, continuous testing activated by the <F2> key and exiting the extended CMOS test by pressing the <ESC> key.

TEST DESCRIPTION

Checker Board Test

The checker board test uses the patterns 55h and AAh. First, a 55h is written to each CMOS offset, read back and verified. If any pattern read back does not match the pattern written, a message that the test failed is displayed, and the offset, pattern written, and pattern read is added to the error log. Next the pattern AAh is written to each CMOS offset, read back and verified. It too displays a failed message and is added to the error log if any offset read back does not match the pattern written.

Rotating Bit Test

The rotating bit test begins by writing an 80h to the first offset in CMOS. The offset is then read, and verified. The high bit is then shifted one bit to the right making the new pattern 40h which is written to the same offset, read back, and verified. This process is continued with the bit being shifted right by one and the new pattern being written, read and verified from the same offset until the pattern 00h is reached. If any errors are found a failed message is displayed and the offset, pattern read, and pattern written are added to the error log. The same patterns are written to each offset throughout the CMOS RAM with all errors being recorded.

Modified Address Test

The modified address test writes the result of the offset address exclusive OR'ed with the data located at that offset. This result is then read back and verified. This process is done for each CMOS offset. For example, if the CMOS offset is 30h, and the data located at that offset is 45h, the result written to the address would be 75h (30h XOR 45h). Again, as with the other tests, if the pattern read back from the offset does not match the pattern written to that offset a failed message is displayed and the error is recorded in the error log.

On/Off Bit Test

The on/off bit test writes the pattern 00h to each offset in CMOS, reads the pattern back and verifies it. Next, the test writes the pattern FFh to each offset, reads the pattern back, and verifies it. If the pattern read back does not match the pattern written then a failed message is displayed and the offset, pattern written and pattern read are recorded in the error log.

APPENDIXError Messages

When an error occurs during testing a failed test message will appear to the right of the test that failed. In addition to this message an error log is also kept of each offset where an error occurred. Only one error is kept per offset, therefore the most recent error at one particular offset will be the error stored in the error log. To view this error log the <F3> key is pressed. The error at the smallest offset will appear first at the bottom of the screen. The offset where the error occurred is displayed along with the data written and the data read to and from that offset. To view the next error the <F1> key is pressed and the next error is displayed at the bottom of the screen. The user may exit the display of the error log at any time by pressing the <ESC> key. When all the errors have been displayed a message stating that there are no more errors and inquiring whether or not the user wishes to clear the user log is displayed. If the error log is to be cleared either <Y> or <y> is pressed. Otherwise either <N> or <n> is pressed. The following screen shows the messages present when the error log is being displayed.

Tandy CMOS Setup and Test
 XXXXXX XX, XXXX Version X.XX
 Copyright (c) XXXX, XXXX Tandy Corp. All rights reserved.

F1 : Display Next Error

ESC : Exit

	Standard	Extended
Checker Board Pattern ...	Failed Test +	N/A
Rotating Bit Pattern ...	Not Tested	N/A
Modified Address Pattern ...	Not Tested	N/A
On/Off Bit Pattern ...	Not Tested	N/A
Clock Power Ok ...	Yes	Flags Set on Boot-up
Checksum Status Byte Ok ...	Yes	
Equipment Status ...	Good	
Memory Size Valid ...	Yes	
Hard Drive Status ...	Good	
Time Valid 12:19:47 pm ...	Yes	
Installed Adapters OK ...	N/A	
Read Adapter ID ...	N/A	

CMOS Offset : 017 Data Written : 55 Data Read : DD

Diagnostic Status Byte

The status of the diagnostic status bits are displayed on the test screen. These flags are set on boot-up, therefore any corrections to these areas after boot-up will not be reflected in this display until the computer has been rebooted.

Clock Power Ok :

- YES - indicates that the Real Time Clock has not lost power.
- NO - indicates that the Real Time Clock has lost power.

Checksum Status Byte Ok :

- YES - indicates that the configuration checksum is good.
- NO - indicates that the configuration checksum is bad.

Equipment Status:

- GOOD - indicates that the configuration information is correct.
- BAD - indicates that the configuration information is incorrect.

Memory Size Valid:

- YES - indicates that the power on check has determined the memory size to be the same as that stored in the configuration.
- NO - indicates that the memory size is different than that stored in the configuration.

Hard Drive Status:

- GOOD - indicates that the fixed disk and adapter are operating properly, and the system can attempt to boot up.
- BAD - indicates that either the fixed disk or the adapter has failed initialization.

Time Valid:

- YES - indicates that the time is valid.
- NO - indicates that the time is invalid.

Model 5000**Installed Adapters Ok:**

- YES - indicates that the installed adapters match the configuration.
- NO - indicates that the installed adapters do not match the configuration.

Read Adapter ID:

- YES - indicates that no time out occurred while reading the adapter ID.
- NO - indicates that a time out occurred while reading the adapter ID.

SERVICE POLICY

Radio Shack's nationwide network of service facilities provides quick, convenient, and reliable repair services for all of its computer products, in most instances. Warranty service will be performed in accordance with Radio Shack's Limited Warranty. Non-warranty service will be provided at reasonable parts and labor costs.

CUSTOM MANUFACTURED FOR RADIO SHACK A Division of Tandy Corporation

U.S.A.: FORT WORTH, TEXAS 76102

CANADA: BARRIE, ONTARIO L4M 4W5

TANDY CORPORATION

AUSTRALIA

91 Kurralong Avenue
Mount Druitt, N.S.W. 2770

BELGIUM

Rue des Pieds d'Alouette, 39
5140 Naninne (Namur)

FRANCE

Centre Commercial des 3 Fontaines
B.P. 147
95022 Cergy Pontoise Cedex

U. K.

Bilston Road Wednesbury
West Midlands WS10 7JN