

**TANDY®**

**Technician Series  
Diagnostics Software**

**EM**

**Extended Memory  
Diagnostic**

**01-0220 Computer Technical Services**

**IMPORTANT**  
**READ THIS BEFORE USING THIS PRODUCT**

This is a legal agreement between you, the end user, and Tandy Corporation. BY OPENING THIS SEALED PRODUCT, YOU ARE AGREEING TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNOPENED SEALED PRODUCT AND THE ACCOMPANYING ITEMS (including written materials and blisters or other containers) TO THE PLACE YOU OBTAINED THEM FOR A FULL REFUND.

**TANDY SOFTWARE LICENSE**

1. **GRANT OF LICENSE.** Tandy grants to you the right to use one copy of the enclosed Tandy software program (the "SOFTWARE") on a single terminal connected to a single computer (i.e. with a single CPU). You may not network the SOFTWARE or otherwise use it on more than one computer or computer terminal at the same time.
2. **COPYRIGHT.** The SOFTWARE is owned by Tandy or its suppliers and is protected by United States copyright laws and international treaty provisions. Therefore, you must treat the SOFTWARE like any other copyrighted material (e.g. a book or musical recording) except that you may either (a) make one copy of the SOFTWARE solely for backup or archival purposes, or (b) transfer the SOFTWARE to a single hard disk provided you keep the original solely for backup or archival purposes. You may not copy the written materials accompanying the SOFTWARE.
3. **OTHER RESTRICTIONS.** You may not rent or lease the SOFTWARE, but you may transfer the SOFTWARE and accompanying written materials on a permanent basis provided you retain no copies and the recipient agrees to the terms of this Agreement. You may not reverse engineer, decompile or disassemble the SOFTWARE.
4. **DUAL MEDIA SOFTWARE.** If the SOFTWARE package contains both 3-1/2" and 5-1/4" disks, then you may use only the disks appropriate for your single-user computer. You may not use the other disks on another computer or loan, rent, lease, or transfer them to another user except as part of the permanent transfer (as provided above) of all SOFTWARE and written materials.

**LIMITED WARRANTY**

**LIMITED WARRANTY.** Tandy warrants that (a) the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt; and (b) any hardware accompanying the SOFTWARE will be free from defects in materials and workmanship under normal use and service for a period of one (1) year from the date of receipt. Any implied warranties on the SOFTWARE and hardware are limited to ninety (90) days and one (1) year, respectively. Some states do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

**CUSTOMER REMEDIES.** Tandy's entire liability and your exclusive remedy shall be, at Tandy's option, either (a) return of the price paid or (b) repair or replacement of the SOFTWARE or hardware that does not meet Tandy's Limited Warranty and which is returned to Tandy with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE or hardware has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

**NO OTHER WARRANTIES.** TANDY DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO THE SOFTWARE, THE ACCOMPANYING WRITTEN MATERIALS, AND ANY ACCOMPANYING HARDWARE. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE TO STATE.

**NO LIABILITY FOR CONSEQUENTIAL DAMAGES.** IN NO EVENT SHALL TANDY OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THIS TANDY PRODUCT, EVEN IF TANDY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

**U.S. GOVERNMENT RESTRICTED RIGHTS**

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013. Contractor/manufacturer is Tandy Corporation, Fort Worth, Texas 76102, U.S.A.

This Agreement is governed by the laws of the State of Texas.

Should you have any questions concerning this Agreement, or if you desire to contact Tandy for any reason, please write: Tandy Customer Sales and Service, One Tandy Center, Fort Worth, Texas 76102.

91-256WP

04-161k

EM

© 1990, Tandy Corporation  
All Rights Reserved.

Reproduction or use, without express written permission from Tandy Corporation, of any portion of this manual is prohibited. While reasonable efforts have been taken in the preparation of this manual to assure its accuracy, Tandy Corporation assumes no liability resulting from any errors or omissions in this manual, or from the use of the information obtained herein.

Please refer to the Software License on the first page of this manual for limitations on use and reproduction of this Software package.

Important Notice:

This diagnostic software and manual are written for Tandy™ computer owners who have a thorough understanding of electronics and computer circuitry. It is not written at a comprehension level for the beginner.

Radio Shack® will not be liable for any damage caused, or alleged to be caused, by the customer or any other person using this diagnostic software or manual to repair, modify, or alter any Tandy™ computer in any manner.

Many parts of the computer electronics are very sensitive and can be easily damaged by improper servicing. We strongly suggest that for proper servicing, the computer be returned to Radio Shack®.

While this diagnostic software and manual have been carefully prepared, Radio Shack® will not be responsible for any errors or omissions and will not be liable for damages resulting therefrom.

Opening the Tandy™ computer housing, breaking the housing seal, or altering or modifying the computer may void the warranties given at time of purchase.

## EM

## TABLE OF CONTENTS

GENERAL DESCRIPTION .....	5
FEATURES .....	5
EQUIPMENT REQUIRED .....	5
LOADING EM .....	5
DISPLAY DESCRIPTION .....	6
COMMANDS .....	9
APPENDIX .....	13
Memory Error Decoding .....	13
Error Messages .....	14

### GENERAL DESCRIPTION

The Extended Memory (EM) diagnostic allows the testing of memory above the 1 Megabyte address space.

### FEATURES

Capable of testing 15 Megabytes of Extended Memory.

Selectable test range allows user to concentrate testing on a particular memory section.

Multiple test patterns selectable from pop-up windows.

Supports single pass or continuous testing modes.

Variable verify delay allows checking for proper memory refreshing.

Graphic display of test range as well as passed and failed memory blocks.

### EQUIPMENT REQUIRED

MS-DOS computer system with memory above 1 Megabyte.

### LOADING EM

The EM program can be loaded either by selecting the appropriate menu selection on a Diagnostic Diskette or at the DOS prompt by typing:

em<ENTER>

DISPLAY DESCRIPTION

Once loaded, the main screen is displayed:

EXTENDED MEMORY TEST Ver. 1.00 March 30, 1990 Copyright (C) 1990, Tandy Corp. All rights reserved.									
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <b>MAIN TEST OPTIONS</b>            Test Extended Memory            Configure Test Parameters         </div> <div style="border: 1px solid black; padding: 5px;"> <b>TEST CONFIGURATION</b>            System Size: 1024k, 16 64K Blocks            Test Size: 1024k, 16 64K Blocks              Pattern: Group Fixed            Mode: Single            Verify Delay: 07 0 <span style="display: inline-block; width: 100px; height: 1em; background: repeating-linear-gradient(45deg, transparent, transparent 2px, black 2px, black 4px);"></span> 100         </div>	<div style="border: 1px solid black; padding: 5px;"> <b>ERROR LOG</b>  <table style="width: 100%; border-collapse: collapse;"> <tr> <th style="text-align: left;">ADDRESS</th> <th style="text-align: left;">BLK WRITTEN</th> <th style="text-align: left;">READ</th> <th style="text-align: left;">PASS</th> </tr> <tr> <td colspan="4" style="height: 150px;"></td> </tr> </table> </div>	ADDRESS	BLK WRITTEN	READ	PASS				
ADDRESS	BLK WRITTEN	READ	PASS						
<div style="display: flex; justify-content: space-between;"> <div> <b>TEST STATUS</b>            Current 64K Block: Pass:            Current Pattern: Errors:            Current Function: WRITE / DELAY / READ              Scale=1/4 MEG <span style="display: inline-block; width: 400px; height: 1em; background: repeating-linear-gradient(45deg, transparent, transparent 2px, black 2px, black 4px);"></span> </div> <div> <b>MEMORY GRAPH LEGEND</b>            =N/A    =System    =Passed                  =Test        =Failed         </div> </div>									

Main Option Selection:  <ESC> To Exit

NOTE: Memory values displayed may vary depending on amount of memory installed in the test machine.

The Main screen can be divided into five (5) sections:

- |  |  |                           |
|--|--|---------------------------|
| <b>Main Test Options</b><br><b>Test Status</b> | <b>Error Log</b><br><b>Option Prompt Bar</b> | <b>Test Configuration</b> |
|--|--|---------------------------|
- Main Test Options:** Displays the primary options of the test. Refer to the Command Section of this manual for further details on the available options.
- Error Log:** Displays any errors that may occur in the following format:
- ADDRESS:** Displays the memory address of the error in Segment:Offset format.
- BLOCK:** Displays the 64K block number in which the error occurred.

---

TANDY COMPUTER PRODUCTS

---

WRITTEN: Displays the pattern written.

READ: Displays the pattern read back.

PASS: Displays the pass number in which the error occurred.

NOTE: If the error was something other than a data miscompare one of the following messages may appear in place of the Written & Read values:

ADDRESS LINE (Major Address line failed)  
ADR LN xxxxh (Address Line at chip failed)  
PARITY ERROR (Memory Parity error occurred)  
EXCEPT. INT. (Exception Interrupt occurred)  
GATE LINE 20 (Address Gate Line 20 Failed)

See the Memory Error Decoding section of this manual for more information on errors.

Test Configuration: Displays the current test parameters:

System Size: Displays the amount of system memory, as seen by BIOS during boot-up, in both kilobytes and the number of 64K blocks.

Test Size: Displays the amount of memory currently defined as the test range in both kilobytes and the number of 64K blocks. Default size is the same as the System size.

Pattern: Displays the currently selected test pattern. Default test pattern is Fixed & Rotating.

Mode: Displays the currently selected test mode. Default mode is Single Pass.

Verify Delay: Displays the amount of delay between write and read as a percentage of total delay available in both decimal form and as a graph. Default Verify Delay is 0%, or no delay implemented.

Test Status: Displays the progress of the current memory test. When the test is completed it displays the final results both as error counts and graphically.

Current 64K Block: Displays the current block being tested.



---

TANDY COMPUTER PRODUCTS

---

Current Pattern: Displays the current pattern being written to the block under test.

Current Function: Displays the current test operation.

Pass: Displays the current pass number.

Errors: Displays the current error count.

Graph: Displays the test progress graphically

**NOTE:** If an error occurs the address, block number, pattern written, pattern read and pass count are displayed under the Error Log and the Error count is incremented by one. The testing of the current block is then aborted and testing proceeds onto the next block. Therefore the Error count does not represent all of the bad memory locations but instead it represents how many 64K blocks had an error occur.

Each graph location represents 256K or 4-64K blocks. Therefore if one, or more, of the 4 blocks within that 256K of memory had an error the graph will indicate that 256K as failed.

Option Prompt Bar: Displays additional information on the current input requested from the user.

COMMANDS

The Main Option menu contains just two selections, Test Extended Memory and Configure Test Parameters.

**Test Extended Memory:** Selecting this option starts the testing of the Extended Memory within the currently selected Test Range using the selected Pattern(s) and Verify Delay parameters.

**NOTE:** Testing may be aborted at any time by pressing the <ESC> key.

**Configure Test Parameters:** This option permits the selection of the parameters used during testing. Once selected the Parameter Option menu window will be displayed:

**PARAMETER OPTIONS**

Range Select  
Mode Select  
Pattern Select  
Increase Delay  
Decrease Delay

**Range Select:** This option provides the selection of the Test Range. This is accomplished by using the memory graph in the Test Status section to select the beginning and ending block of memory. The smallest amount of memory selectable is 256K or 4 - 64K blocks.

Once this option is selected, the memory graph is redisplayed showing only the System Memory locations. A blinking arrow is then positioned over the first block. You are then requested to mark the beginning of the test range by using the left and right arrow keys to position the blinking arrow over the desired starting point and then pressing <ENTER>. With the beginning 256K block of memory selected the Test Configuration section of the main screen will show the Test Size in kilobytes as well as the number of 64K blocks. By using the left and right arrow keys again, you position the blinking arrow over the ending 256K block and press <ENTER>. Once the ending 256K block of memory has been defined the memory graph is redisplayed with the new Test Range values.

**NOTES:** The Test Range selection may be aborted at any time before the ending 256K block has been defined by pressing <ESC>. This will return the original Test Range values.

---

TANDY COMPUTER PRODUCTS

---

If at any time the Test Range Selection goes beyond the System memory location a message will appear within the Test Configuration area of the screen as follows:

TEST RANGE BEYOND SYSTEM MEMORY

This informs you that memory has been selected to be tested which is beyond the address area in which the computer system believes the installed memory resides.

**Mode Select:** This option provides the selection of Single Pass or Continuous mode.

**Single:** The memory is tested within the selected test range with the current pattern(s) once and then control is returned to the Main Options menu.

**Continuous:** The memory is tested within the selected test range with the current pattern(s) after which the Pass number is incremented and testing is restarted at the beginning of the test range. This cycle will repeat until the <ESC> key is pressed to abort the testing and return control to the Main Options menu.

**Pattern Select:** This option provides the selection of the test Pattern or group of patterns. When selected the Pattern Selection menu appears with the following patterns available:

**Single Fixed:** This option causes the memory within the test range to be tested with the same single word pattern. The single word pattern is selected from the pop-up window and may be either 0000h, 5555h, AAAAh or FFFFh. With this pattern selected each 64K block within the test range is tested once.

**Group Fixed:** This options causes the memory within the test range to be tested with each of the available Single Fixed patterns (0000h, 5555h, AAAAh and FFFFh). With this pattern selected each 64K block within the test range is tested four times, once with each fixed pattern, before the test proceeds to the next 64K block.

---

TANDY COMPUTER PRODUCTS

---

**Rotating Bit:** This option causes the memory within the test range to be tested multiple times by rotating a single bit through each bit location of the word. The starting test pattern is 0001h with each successive pattern having the bit rotated one position to the left. With this pattern selected each 64K block within the test range is tested sixteen times, once for each bit location of the word, before the test proceeds to the next 64K block.

**Fixed & Rotating:** This option causes the memory within the test range to be tested first with the patterns used in the Fixed Group test and then with the patterns of the Rotating Bit group. With this pattern selected each 64K block is tested twenty times, four for the Group Fixed and sixteen for the Rotating Bit, before the test proceeds to the next 64K block.

**Quick Modified Address:** A Modified Address test fills each byte within the 64K block with the XOR of the address and the current test pattern. In this way every byte within the 64K block contains a different value. The XOR test pattern is then decremented by one and the process is repeated. With this pattern selected the starting pattern for the XOR is 00FFh which means each 64K block is tested 256 times before the test proceeds to the next 64K block.

**Long Modified Address:** This option performs the same modified address test as the Quick Modified Address except the starting pattern for the XOR is FFFFh which means each 64K block is tested 65,536 times before the test proceeds to the next 64K block.

**Increase Delay:** Selecting this option will increase the Verify Delay by 10% of its full delay time until the maximum delay is reached at which time this option will no longer have an effect.

**Decrease Delay:** Selecting this option will decrease the Verify Delay by 10% of its full delay time until the delay value reaches zero at which time this option will no longer have an effect.

**NOTE:** The delay option provides a simple method of checking memory refresh. Normally a pattern is written into memory and then very quickly read back. Even if the refresh circuitry is not working properly this quick write/read may function correctly. By inserting a delay between the write/read we can insure a refresh must take place before the memory is read back.

#### **Address Line Testing:**

At the completion of testing a block with the selected test patterns, before proceeding onto the next block, a special test is performed. This test combines a rotating bit and modified address pattern designed to detect address line problems. It writes these special patterns to the current memory block and then checks all 64K blocks within the test range for these patterns. If the machine is functioning correctly the only block containing the patterns should be the one written to. If the test pattern is detected in a 64K block other than the current block, an ADDRESS LINE error message is displayed within the Error Log. If the test pattern read back within the current block is different than the written pattern, an ADR LN xxxxxh error message is displayed.

APPENDIX**MEMORY ERROR DECODING**

Following are examples of the possible memory error messages displayed by EM and how they are decoded:

	ERROR LOG			
	ADDRESS	BLK	WRITTEN READ	PASS
Error Number 1 --->	20000:0000	17	FFFFh FFFEh	1
Error Number 2 --->	21000:0000	18	ADR LN FDFCh	1
Error Number 3 --->	20000:0000	19	ADDRESS LINE	1
Error Number 4 --->	23000:0000	20	PARITY ERROR	1
Error Number 5 --->	24000:0000	21	GATE LINE 20	1
Error Number 6 --->	25000:0000	22	EXCEPT. INT.	1

**ERROR NUMBER 1:**

A data error has occurred at address 20000:0000, which is the 17th 64K block of memory, during pass 1 of the test. The binary difference between FFFFh and FFFEh indicates bit 0 is being held low.

**ERROR NUMBER 2:**

An address line error has occurred at address 21000:0000, which is the 18th 64K block of memory, during pass 1 of the test. The binary difference between FDh (value written) and FCh (value read) indicates the RAM chip responsible for bit 0 has an addressing problem.

**ERROR NUMBER 3:**

When checking for possible address line problems the test pattern was detected in the 64K block of memory at address 20000:0000 (block 17) while testing memory block 19. This indicates a major address line problem which caused the test data to be written and read correctly but at the wrong memory address. This error occurred during pass 1 of the test.

**ERROR NUMBER 4:**

A parity error occurred at address 23000:0000, which is the 20th 64K block of memory, during pass 1 of the test.

**NOTE:**

EM is not capable of detecting Parity errors on computers that do not have an on-board port 80h, such as the 3000HL and 3000NL. With these computers the following message will appear within the error log section:

Warning: EM Can Not Detect A Parity  
Error On This Computer!

**ERROR NUMBER 5:**

The enabling, or disabling, of Address Line 20 when entering, or exiting, protected mode failed while testing address 24000:0000, which is in the 21st 64K block of memory, during pass 1 of the test.

**ERROR NUMBER 6:**

While in protected mode testing address 25000:0000, which is in the 22nd 64K block of memory, an exception interrupt error (instruction could not be completed normally) occurred.

**ERROR MESSAGES****EM ERROR: Insufficient Memory To Allocate 64K Transfer Buffer!**

EM must have a 64K block of Standard memory (below 640K) in order to transfer information to the Extended memory (above 1 MEG). This error indicates it was unable to acquire the 64K of Standard memory required.

Remove any TSR (Terminate but Stay Resident) programs which may be holding this memory or install more Standard memory.

**EM ERROR: This Machine Does Not Support Extended Memory!**

This error indicates the machine does not support the use of Extended memory in which case the EM test is not required.

## **SERVICE POLICY**

Radio Shack's nationwide network of service facilities provides quick, convenient, and reliable repair services for all of its computer products, in most instances. Warranty service will be performed in accordance with Radio Shack's Limited Warranty. Non-warranty service will be provided at reasonable parts and labor costs.

### **CUSTOM MANUFACTURED FOR RADIO SHACK A Division of Tandy Corporation**

**U.S.A.: FORT WORTH, TEXAS 76102  
CANADA: BARRIE, ONTARIO L4M 4W5**

---

#### **TANDY CORPORATION**

---

<b>AUSTRALIA</b>	<b>BELGIUM</b>	<b>FRANCE</b>	<b>U. K.</b>
91 Kurrajong Avenue Mount Druitt, N.S.W. 2770	Rue des Pieds d'Alouette. 39 5140 Naninne (Namur)	Centre Commercial des 3 Fontaines B.P. 147 95022 Cergy Pontoise Cedex	Bilston Road Wednesbury West Midlands WS10 7JN