




Adafruit HMC5883L Breakout - Triple-Axis Magnetometer/Compass Sensor

Created by Ladyada




Last updated on 2014-03-05 07:15:07 PM EST

Guide Contents


Guide Contents	2
Overview	3
Pinouts	5
Assembly	7
Prepare the header strip:	7
Add the breakout board:	7
And Solder!	8
Wiring and Test	9
Download & Install Libraries	9
Download Adafruit_Sensor	9
Download Adafruit_HMC5883	10
Load Demo	10
Downloads	13
Datasheet	13
Breakout board design	13

Overview



He told you "Go West, young maker!" - but you don't know which way is West! Ah, if only you had this triple-axis magnetometer compass module. A magnetometer can sense where the strongest magnetic force is coming from, generally used to detect magnetic north.

We based this breakout on a popular and well loved magnetometer, the HMC5883L. This compact sensor uses I2C to communicate and its very easy to use. Since it's a 3.3V max chip, we added circuitry to make it 5V-safe logic and power, for easy use with either 3 or 5V microcomtrollers. Simply connect VCC to +3-5V and ground to ground. Then read data from the I2C clock and data pins. There's also a Data Ready pin you can use to speed up reads (check the [datasheet](http://adafru.it/daB) (<http://adafru.it/daB>) for details)





This is the same magnetometer sensor that is *inside* the LSM303. So if you want an [accelerometer as well as a magnetometer, check out the LSM303 \(http://adafruit.it/1120\)](http://adafruit.it/1120) - it has basically this sensor + a nice digital 3-axis accelerometer!

Specs:

- I2C interface
- 1-2 degree heading accuracy
- Integrated 12-bit ADC
- 160Hz max data rate
- Range of -8 to +8 Gauss

Pinouts




This is a fairly simple breakout. The sensor itself is super tiny and in the middle of the PCB. We have all the useful pins broken out in to a 0.1" spaced header at the bottom

- **VIN** - this is the power in pin, give it 3-5VDC. It is reverse-polarity protected. Use the same voltage as you do for the controlling microcontroller's logic. For an Arduino, 5V is best.
- **GND** - this is the common power and data ground pin
- **3vo** - This is the 3.3V output from the onboard regulator. It will be at 3.3V and you can grab

up to 100mA from this to power other items


- **SDA** and **SCL** - these are the I2C data and clock pins used to send and receive data from the module to your microcontroller. There are 10K pullups on these pins to the **VIN** pin. You can connect these pins to 5V I2C lines, there are level shifters on board to safely bring the pins down to 3V
- **RDY** - this is the 'data ready' pin output. If you want to stream data at high speed (higher than 100 times a second) you may want to listen to this pin for when data is ready to be read. Check the datasheet for more details about using the RDY pin, we don't use it because we don't read that fast!

Assembly




Assembly is really easy, you can use straight or 'right-angle' style headers to attach to the PCB. We'll be using the plain straight headers included

The board comes with all surface-mount components pre-soldered. The included header strip can be soldered on for convenient use on a breadboard or with 0.1" connectors. You can also skip this step and solder on wires.




Prepare the header strip:

Cut the strip to length if necessary. It will be easier to solder if you insert it into a breadboard - **long pins down**



Add the breakout board:



Place the breakout board over the pins so that the short pins poke through the breakout pads



And Solder!


Be sure to solder all 5 pins for reliable electrical contact.

(For tips on soldering, be sure to check out our [Guide to Excellent Soldering](http://adafruit.it/aTk) (<http://adafruit.it/aTk>)).



You're done! Check your solder joints visually and continue onto the next steps

Wiring and Test



This 3-axis magnetometer breakout is thankfully very easy to use. It only requires 2 power pins and 2 data pins.

We'll be demoing it with an Arduino but any other microcontroller can be used if you are willing to port the I2C code. We suggest using an Arduino to start since its guaranteed to work

- Connect **VIN** to 5V pin on the Arduino. If you have a 3V logic Arduino, connect **VIN** to 3V instead
- Connect **GND** to the ground pin on the Arduino
- Connect the **SDA** pin on the breakout to the I2C data **SDA** pin on your Arduino. On an UNO & '328 based Arduino, this is also known as **A4**, on a Mega it is also known as **digital 20** and on a Leonardo/Micro, **digital 2**
- Connect the **SCL** pin on the breakout to the I2C clock **SCL** pin on your Arduino. On an UNO & '328 based Arduino, this is also known as **A5**, on a Mega it is also known as **digital 21** and on a Leonardo/Micro, **digital 3**

The HMC5883L has a fixed I2C address, you can only connect *one* sensor per microcontroller!

Download & Install Libraries

Lucky for you we have written a very nice sensor library for the HMC5883L, which is based off of our Adafruit_Sensor framework library.

Download Adafruit_Sensor

To begin, you will need to [download Adafruit_Sensor from our github](#)

repository (<http://adafru.it/aZm>). You can do that by visiting the github repo and manually downloading or, easier, just click this button to download the zip

Download
Adafruit_Sensor
Library

<http://adafru.it/cMO>

Rename the uncompressed folder **Adafruit_Sensor** and check that the **Adafruit_Sensor** folder contains **Adafruit_Sensor.cpp** and **Adafruit_Sensor.h**

Place the **Adafruit_Sensor** library folder your **arduinofolder/libraries/** folder. You may need to create the **libraries** subfolder if its your first library. Restart the IDE.

We also have a great tutorial on Arduino library installation at:

<http://learn.adafruit.com/adafruit-all-about-arduino-libraries-install-use> (<http://adafru.it/aYM>)

Download Adafruit_HMC5883

Next you can download the Adafruit HMC5883 "Unified" library. The "Unified" means that it is based on Adafruit_Sensor and will give you normalized values back in microTeslas instead of arbitrary numbers from 0 to 1023 or whatever is used internally. Again, [either visit the github repo \(http://adafru.it/daC\)](http://adafru.it/daC) or, better, download by clicking below

Download
Adafruit_HMC5883_U
library

<http://adafru.it/daD>


Rename the uncompressed folder **Adafruit_HMC5883_U** and check that the **Adafruit_HMC5883_U** folder contains **Adafruit_HMC5883_U.cpp** and **Adafruit_HMC5883_U.h**

Place the **Adafruit_HMC5883_U** library folder your **arduinofolder/libraries/** folder as you did with **Adafruit_Sensor**


Finally, restart the IDE!

Load Demo

Open up **File->Examples->Adafruit_HMC5883_U->magsensor** and upload to your Arduino wired up to the sensor



And open up the serial console. You will see some quick spec's about the HMC5883 and then a stream of data with X Y Z magnetometer data in uTeslas and then a calculated heading. If you hold the module so that it is parallel with the ground then it will point you in the direction of North!



If you have to mount the module so that some other axis is parallel with the ground (X or Y) you will have to modify the heading code to take the arcTan of X&Z or Y&Z instead of X&Y


Downloads

Datasheet

- Grab the [HMC5883L datasheet here \(http://adafru.it/daB\)](http://adafru.it/daB), it has a lot more specifications available!
- This [handy app note from Honeywell talks about how to calculate heading from a magnetometer's raw data \(http://adafru.it/daE\)](http://adafru.it/daE)

Breakout board design

Layout diagram in inches:



Schematic, [click to enlarge](#)

