


● PIN code settings

"Setting"->"PIN" menu is used to enable/disable, change, modify and unlock locked PIN code via PUK. When inserting a PIN-enabled SIM card, modem will be prompt for PIN code before using it. If the PIN codes were modified, please unplug/replug modem. The modem utility will prompt for the new PIN code.


< NOTE >

After three failed attempts to enter the PIN code, the SIM card will be locked. To unlock the SIM card, you will be required to enter the correct PUK to retrieve the default PIN code. Please contact your service provider to obtain the PUK code information. With incorrect PIN code input, the modem is unable to register on the network; **All network service will be unavailable.**



● Reset modem

"Settings"->"Reset" menu is used to restore the device to factory default settings and reboot the device.



Additional Information


This product is suitable for indoor network access applications, not applicable for outdoor usage. For up-to-date product information, descriptions, documentation, application updates, and support information, please visit www.alfa.com.tw

HARDWARE INSTALLATION

Insert SIM Card Before Using Onyx4G

Slide off the cover on the back of the device.

Insert SIM card as shown in the diagram below.




< Optional > microSD card installation:

Onyx4G provides a microSD slot for file sharing feature. To install a microSD card, please upturn the card and insert it into the card slot as shown in the diagram. A "click" sound indicates the card is installed properly. (Push the microSD card again, it will be ejected from the memory card slot.)

Install Onyx4G to Your Computer

Onyx4G is powered by USB host port, and designed to work with USB 2.0/3.0 port on your computer. To start using Onyx4G, insert Onyx4G into an available USB port on your computer.



< NOTE >

If the computer does not have Onyx4G drivers installed, Onyx4G will prepare the utility program installation.
If the utility program is already installed, Onyx4G will be detected, and utility program will start automatically.

SOFTWARE INSTALLATION

Install Onyx4G Utility Program

Onyx4G contains the necessary drivers for Windows 7/8/10 computer ; an installation CD is not required. The first time connecting Onyx4G to a Windows computer, Onyx4G utility program will start the utility program installation automatically. Please permit the program installation if there is a prompt window during the installation. Follow the on-screen instructions to complete the setup of the Onyx4G utility program.




< NOTE >

- If the installation does not start automatically, please turn on the CD Auto Run feature in your computer or manually browse the new CD-ROM drive added by Onyx4G in "My Computer", the setup.exe file of Onyx4G program can be found in the CD-ROM drive.
- Manual installation: Double-click the "Setup.exe" file and follow the on-screen instructions to complete the Installation. (Please permit the program installation if there is any prompt message during the installation process.)

Make sure Onyx4G is


ALFA ALFA ROMEO



When using Onyx4G with a PIN-enabled SIM card, each time at program launch, it will be required to input proper PIN code to use Onyx4G. If the PIN-code is incorrectly input three times, SIM will be locked. To unlock a locked SIM card, a PUK code is required. The PUK code can be obtained from the service provider. (When asking for PUK code, please contact your service provider to verify you are the owner of the SIM card.)



Statistics





Download data is shown in red, and upload data is shown in yellow.



Records

Record Record

**USSD**

Unstructured Supplementary Service Data (USSD), is a protocol used by GSM cellular devices to communicate with the service provider's equipment. USSD service is carrier-specific and often can be used by prepaid GSM cellular customers to query their available balance, etc. Before using the USSD feature, please consult your carrier to make sure USSD service is available, and information of the supported USSD codes.



SETTINGS


The screenshot shows the 'Settings' dialog box with the 'Network' tab selected. The fields are as follows:

Network	File	Language	Mode	Reset
Name			Churchina	New
MacAddr			A68D2	Edit
Number			793.8	Delete
Username				
Password				
Aps			ipconfig	
Priority list			Auto	

Buttons: OK, Cancel

The default connection profile is Chunghwa Telecom (located in Taiwan). Various network operation modes can be selected. The default is Auto, but GPRS only, or LTE only can be selected. After selecting the operation mode, the modem will register to chosen network according to the selected mode.

100%



Setting	
Name	TEST
ModId	
Number	*99#
Username	test
Password	****
Apn	internet

OK Cancel