

Release key / Authorising Windmill Software

You have to send us the Request key code that is issued by your computer.

You will find it in the installing *Windmill section, Configuring your system.*

Find the main *ConfIML window and press the software button.*

You will see the **Request key** code (7 characters)

Email this code to us and then we can send you the Release key code to enter on to the same screen.

This will then authorise your software.