

WINDMILL SOFTWARE INSTALLATION NOTES

The Windmill installer does not automatically install the USB drivers for the ML75x, ML770 and ML3304 devices

The correct procedure is:

- 1) Run the Windmill installer to install the software
- 2) At the end of the installation after confIML has run, connect the hardware (ML75x, ML770 or ML3000)

Windows should say Unkown device

Go to the Windows start menu and select: Control Panel.

WINDOWS 7

- View devices and printers
- Click on Unknown device

WINDOWS XP

- Select System. Hardware. Device Manager. Microlinks and then USB device

- Select Properties
 - Select Change Settings
 - Select Driver
 - Update driver
 - Browse My Computer

For Windows 64-bit systems:

- Select c:\windmill\drivers64\ and click Next

For Windows 32-bit systems:

- Select c:\windmill\drivers\ and click Next

Windows should say Installing driver software, then select Install Anyway

Then the green light should come on on your hardware device, indicating the device has been installed and is ready for use.

WINDOWS 8

If using Windows 8 please contact us for another PDF (USB Driver Installations Windows 8 file).

In Windows 8, Microsoft have enforced a block on all drivers without signatures. To get around this please uninstall the driver from your machine and remove device (from device manager) then follow the PDF file instructions from STEP #3. This should disable signatures checking allowing you to install the driver successfully.