

Note that there was an error on the previous setup.  
You can't use A0

Note that there was an error on the previous setup.  
You can't use A0

The 1/8" jack can be placed anywhere on the breadboard

