

IPA robot and ipa-apartment manual

**Manual for  
working in the IPA environments**

Autors: Florian Weisshardt  
Nadia Hammoudeh Garcia

Fraunhofer IPA

Institute for Manufacturing Engineering and Automation  
Stuttgart, Germany

Last modified on Wednesday 11<sup>th</sup> April, 2012



# Contents

|          |  |          |
|----------|--|----------|
| <b>1</b> | <b>IPA apartment rules</b>                 | <b>1</b> |
| 1.1      | robot side . . . . .                       | 1        |
| 1.1.1    | Working on pool pcs . . . . .              | 1        |
| 1.1.2    | connect your own pc . . . . .              | 1        |
| 1.1.3    | Leaving the room . . . . .                 | 2        |
| 1.1.3.1  | Move furniture back . . . . .              | 2        |
| 1.1.3.2  | Tidy up working places . . . . .           | 2        |
| 1.1.3.3  | dasfa . . . . .                            | 2        |
| 1.2      | student side . . . . .                     | 2        |
| 1.2.1    | Leaving the room . . . . .                 | 2        |
| 1.3      | Floor plan . . . . .                       | 2        |
| <b>2</b> | <b>IPA robot rules</b>                     | <b>3</b> |
| 2.1      | cob3-3 and cob3-5 . . . . .                | 3        |
| 2.1.1    | Leaving the robot . . . . .                | 3        |
| 2.1.1.1  | Mount all casings . . . . .                | 3        |
| 2.1.1.2  | Move components in home position . . . . . | 3        |
| 2.1.1.3  | Move robot to charging station . . . . .   | 3        |
| 2.1.1.4  | Disconnect power . . . . .                 | 4        |

|       |                           |   |
|-------|---------------------------|---|
| 2.2   | raw3-1 . . . . .          | 4 |
| 2.2.1 | leave the robot . . . . . | 4 |

# Chapter 1

## IPA apartment rules

You can always get the latest version of this manual at <sup>1</sup>.

If you have comments, suggestions or would like to add something to the manual, please contact [fmw@ipa.fhg.de](mailto:fmw@ipa.fhg.de).

### 1.1 robot side

#### 1.1.1 Working on pool pcs

don't remove any cable

#### 1.1.2 connect your own pc

use plugs for network and power on the tables (never plug or unplug something under the tables)

you can find cables in cabinet nr 3 (see floor plan ADD REFERENCE)

---

<sup>1</sup>[https://github.com/ipa320/setup/blob/master/manual/IPA\\_manual.pdf](https://github.com/ipa320/setup/blob/master/manual/IPA_manual.pdf)

### **1.1.3 Leaving the room**

#### **1.1.3.1 Move furniture back**

Table, chairs, cupboards

ADD MAP for standard apartment layout

#### **1.1.3.2 Tidy up working places**

remove everything from tables of cob-stud-6 to cob-stud-9 Unplug additional network and power cables and put back to cabinet

#### **1.1.3.3 dasfa**

## **1.2 student side**

### **1.2.1 Leaving the room**

## **1.3 Floor plan**

ADD FLOOR PLAN for robot side and student side

# Chapter 2

## IPA robot rules

You can always get the latest version of this manual at <sup>1</sup>.

If you have comments, suggestions or would like to add something to the manual, please contact [fmw@ipa.fhg.de](mailto:fmw@ipa.fhg.de).

### 2.1 cob3-3 and cob3-5

#### 2.1.1 Leaving the robot

##### 2.1.1.1 Mount all casings

Mont all casings: green and grey parts from base, head casing

##### 2.1.1.2 Move components in home position

always leave the robot components in home position. ADD IMAGE

##### 2.1.1.3 Move robot to charging station

leave next to charging station/coffee machine ADD IMAGE

---

<sup>1</sup>[https://github.com/ipa320/setup/blob/master/manual/IPA\\_manual.pdf](https://github.com/ipa320/setup/blob/master/manual/IPA_manual.pdf)

#### **2.1.1.4 Disconnect power**

unplug the power cable and shut down the power supply

## **2.2 raw3-1**

### **2.2.1 leave the robot**

disconnect power