


Contributed by **Mahmoud, Mohamed** <mmahmoud@ntech.edu>

(1) Download compiler 5 from here

[https://www.cae.ntech.edu/~mmahmoud/teaching\\_files/undergrad/ECE3130-ARM/ARMCompiler\\_506\\_Windows\\_x86\\_b960.zip](https://www.cae.ntech.edu/~mmahmoud/teaching_files/undergrad/ECE3130-ARM/ARMCompiler_506_Windows_x86_b960.zip)


(2) Unzip the file and click on setup

Make sure the compiler is installed under ARM/ARM\_Compiler\_5.06u7







(3) In uVision 5



Click file extensions, books and environment




Click Folders/Extensions









Select version 5 from here

