

Tizen/Artik IoT Lecture Chapter 12. IoTivity Resource Container


Sungkyunkwan University

Use Case

2

10

- Acts as a bridge between OIC & non-OIC ecosystems
- Enables Iotivity system to see non-OIC servers




https://wiki.iotivity.org/resource_container_-_programming_guide

Architecture

3

10




https://wiki.iotivity.org/resource_container_-_programming_guide

Control Flow of startContainer()

4

10



https://wiki.iotivity.org/resource_container_-_programming_guide

Embedded Software Lab. @ SKKU

XML Configuration File

5

10

- **XML file defines the interface and configuration of resource with resource container**
 - Id, path, activator, resource info ...
- **When adding bundles, Resource Container parses configuration file and create object (RCSResourceObject) and resource**

```
<?xml version="1.0" encoding="UTF-8" standalone="no"?>
<container>
  <bundle>
    <id>oic.bundle.discomfortIndexSensor</id>
    <path>libDISensorBundle.so</path>
    <activator>disensor</activator>
    <version>1.0.0</version>
    <resources>
      <resourceInfo>
        <name>DiscomfortIndexSensor1</name>
        <resourceType>oic.r.sensor</resourceType>
        <outputs>
          <output>
            <name>discomfortIndex</name>
            <type>int</type>
          </output>
          <output>
            <name>humidity</name>
            <type>double</type>
          </output>
          <output>
            <name>temperature</name>
            <type>double</type>
          </output>
        </outputs>
        <inputs>
          <input>
            <name>humidity</name>
            <type>double</type>
            <resourceType>oic.r.humidity</resourceType>
          </input>
          <input>
            <name>temperature</name>
            <type>double</type>
            <resourceType>oic.r.temperature</resourceType>
          </input>
        </inputs>
      </resourceInfo>
    </resources>
  </bundle>
```

bundle

output

input

Bundle API accessing resource container

ResourceConatinerBundleAPI

RCSResourceContainer

contains

ResourceContainerImpl

Configuration

RCSBundleInfo

BundleInfoInternal

Xml file
- Bundles
- Resources

Bundle Info

ResourceContainerAPI

Parent class

Inheritance

Child class

Dynamic
configuration

Return	Interface	Parameter
void	startContainer	string configFile
void	stopContainer	void
list<BundleInfo*>	listBundles	void
void	startBundle	BundleInfo *bInfo
void	stopBundle	BundleInfo *bInfo
void	addBundle	string bundleId, string bundleUri, string bundlePath, map<string,string> params
void	removeBundle	string bundleId
void	addResourceConfig	string bundleId, string resourceUri, map<string,string> params
void	removeResourceConfig	string bundleId, string resourceUri
list<BundleResource*>	listBundleResources	string bundleId

Test Program: ContainerSample (1/2)

7

10

1 – start resource container
Read config and .so files

3 - Add bundles

4 – start bundles (activate)

Test Program: ContainerSample (2/2)

8

10

```
=====
IoTivity Resource Container Test Application
=====
1. Start Resource Container
2. Stop Resource Container
3. Add Sample Bundle
4. Start Sample Bundle
5. Stop Sample Bundle
6. Remove Sample Bundle
7. Add Sample Resource
8. Remove Sample Resource
9. List Bundles
10. List Resources
11. Exit

Please Enter the NO: 7
53:56.407 INFO: RESOURCE_CONTAINER: list bundles (3)
53:56.407 INFO: RESOURCE_CONTAINER: set attribute (on-off', with false)'
53:56.407 INFO: RESOURCE_CONTAINER: set attribute (dim', with 0)'
53:56.407 INFO: RESOURCE_CONTAINER: set attribute (color', with 0)'
53:56.407 INFO: RESOURCE_CONTAINER: Registration of resource (/hue/light/sample, oic.r.light,oic.bundle.hueSample)
53:56.407 INFO: RESOURCE_CONTAINER: Registration finished (/hue/light/sample, oic.r.light)
53:56.407 INFO: RESOURCE_CONTAINER: isHasInput out of range oic.bundle.hueSample.
53:56.407 INFO: RESOURCE_CONTAINER: Resource has no input (/hue/light/sample, oic.r.light)
53:56.407 INFO: RESOURCE_CONTAINER: Registration finished (/hue/light/sample, oic.r.light)
```

7 – add resources

```
=====
IoTivity Resource Container Test Application
=====
1. Start Resource Container
2. Stop Resource Container
3. Add Sample Bundle
4. Start Sample Bundle
5. Stop Sample Bundle
6. Remove Sample Bundle
7. Add Sample Resource
8. Remove Sample Resource
9. List Bundles
10. List Resources
11. Exit

Please Enter the NO: 9
55:05.276 INFO: RESOURCE_CONTAINER: list bundles (3)
-- oic.bundle.BMISensor
-- oic.bundle.discomfortIndexSensor
-- oic.bundle.hueSample
```

9 – list bundles

```
=====
IoTivity Resource Container Test Application
=====
1. Start Resource Container
2. Stop Resource Container
3. Add Sample Bundle
4. Start Sample Bundle
5. Stop Sample Bundle
6. Remove Sample Bundle
7. Add Sample Resource
8. Remove Sample Resource
9. List Bundles
10. List Resources
11. Exit

Please Enter the NO: 10
Type Bundle Id to get Resource List (Press '0' to get example resource list): 0
56:02.599 INFO: RESOURCE_CONTAINER: list bundles (3)
56:02.599 INFO: RESOURCE_CONTAINER: listBundleResources oic.bundle.hueSample
-- /hue/light/sample
```

10 – list resources

Oic.bundle.hueSample

```
=====
IoTivity Resource Container Test Application
=====
1. Start Resource Container
2. Stop Resource Container
3. Add Sample Bundle
4. Start Sample Bundle
5. Stop Sample Bundle
6. Remove Sample Bundle
7. Add Sample Resource
8. Remove Sample Resource
9. List Bundles
10. List Resources
11. Exit

Please Enter the NO: 10
Type Bundle Id to get Resource List (Press '0' to get example resource list): oic.bundle.discomfortIndexSensor
56:15.394 INFO: RESOURCE_CONTAINER: list bundles (3)
56:15.394 INFO: RESOURCE_CONTAINER: listBundleResources oic.bundle.discomfortIndexSensor
-- /softsensor/discomfortIndex/1
```

Oic.bundle.discomfortIndexSensor

Resource Example

9

10

With Bridge – Hue Sample

BundleResource

ProtocolBridgeResource

HueLight

Resource within bridge

ProtocolBridgeConnector

HueConnector

Role of connecting and data transfer

Common Part

BundleActivator

HueSampleBundleActivator

Role of activating and
creating resources

Functions

activateBundle()

deactivateBundle()

Without Bridge – Discomfort Index Sensor

BundleResource

SoftSensorResource

DiscomfortIndexSensorResource

Resource representing sensor

Source Directory

10

10

