



Pushing during power-up causes  
internal boot loader to run from  
system memory.

MH1 MH2

Mounting holes

TITLE: Freeflow flow sensor PCB

FILE: REVISION: 3

PAGE OF DRAWN BY: Steve Glow