

Wall Function Definition

This node gives the user the ability to specify the use of a turbulence model wall function.

Parents: Base_t/Zone_t/TurbulenceModel_t
Name: WallFunction
Label: DataArray_t
Dimensions: 1
Dimension Values: 1
Data: Integer: 1: Wall function type flag
0 – None
1 – White-Christoph

Notes:

- We probably need to add more wall function types...
- The current definition is only valid by zone, we may want to specify this capability by surface, or even point.