


New prototype switcher (FY23) manual


2024/07/27 ABC/NAOJ Takayuki Kotani



Fiber microscopes,
fiber attachment,
USB memory for
GUI software in the
Lightel case

1. Please clean the inside and outside of the switcher. I did only very simple cleaning
2. Connect the switcher and the power supply
3. Attach the fiber microscopes (be careful about the orientation and the inner and external microscopes)
4. Connect the air tubes to the fittings
5. Set the IP address of your PC
6. (optional) Connect 2x 25V power supplies to control 2x solenoid valves
7. Please initialize the switcher when turning on the power


Fibers, microscopes, air blow port



Attach microscopes to the fiber ports

- Please use the fiber microscope labeled “inside” for the inner fiber port. It cannot be attached to the outer fiber port.
- For the internal microscope, please put it to the fiber port so that the focus knob is facing downwards. For the external microscope, put it so that the focus knob is facing upwards.


Internal microscope




external microscope

Remove this parts
and 2 screws




Focus knob



USB port for the
internal microscope




Attach air tubes to the switcher




- If you use the 6mm OD tube (green one), remove the 10mm OD tube adapter, then connect the 6mm OD tube to the fitting 1. This 6mm OD tube should be connected to your compressor or regulator
- Air pressure should be > 0.4 MPa to drive pneumatic actuators.
- Connect the tube 2 to the fitting 2
- Fitting 3 is for a tube which will be connected to a particle counter


Fiber adapter orientation




- Please note that the cutout of the fiber adapter is oriented, as shown here. It is 180 degrees different from the previous switcher.



Power supplies for the solenoid valves



2x cable pairs for 2x solenoid valves.



air intake and outlet
(I do not remember
which one is intake)

- There are 2 cable pairs for the 2 solenoid valves, each for sending air to the switcher for pressurization and sending air inside the switcher to a particle counter.
- Please connect these cables to 25V power supplies to open/close the valves.

IP setting of your control PC

インターネット プロトコル バージョン 4 (TCP/IPv4) のプロパティ

全般

ネットワークでこの機能がサポートされている場合は、IP 設定を自動的に取得することができます。サポートされていない場合は、ネットワーク管理者に適切な IP 設定を問い合わせてください。

☐ IP アドレスを自動的に取得する(O)

☒ 次の IP アドレスを使う(S):

IP アドレス(I): 192 . 168 . 0 . 184

サブネット マスク(U): 255 . 255 . 255 . 0

デフォルト ゲートウェイ(D): . . .

☐ DNS サーバーのアドレスを自動的に取得する(B)

☒ 次の DNS サーバーのアドレスを使う(E):

優先 DNS サーバー(P): . . .

代替 DNS サーバー(A): . . .

☐ 終了時に設定を検証する(L)


詳細設定(V)...

OK キャンセル

IP address: 192.168.0.184

GUI software

Run GT SoftGOT2000, then open the file “IT240408ファイバー交換器2024_240614a.GTX”



Please insert this USB memory stick into your PC to prevent the software from being forcibly closed after a few hours. This USB memory is in the Lightel's case.

MSG02) Operatable

MSG29) Reached the number of times [Airblow1]

Warning message if the number of times it is used exceeds the set value

ポートA (上下)

Port A (vertical move, outside fiber port)

	x	1	2	3	4	5	6	7	8	9
y	A	SpO	SpO	SpO	So	CAL	Bak	Sci	Spe	
	B	—	—	—	Cam	—	PL	PL	PL	
	C	Air	Air	Air	Air	Air	Cleaner	—	—	

Select the fiber ports A and B you want to connect, then click “Connecting”. If you want to move the stage to the position immediately before inserting the fiber, click “Connect Position”.

sent address

connect

32000 [pls]

connect

disconnect


start connect

passing

ポートB (左右)

Port B (horizontal, inside fiber port, seen from the outside port)

	x	1	2	3	4	5	6
y	a	Air	Air	Air	Cleaner	—	Cam
	b	Slit	Slit	Slit	—	Splt	—



Address of the selected fiber ports

スティッククリーニング

enabled

disabled

Stick cleaner

エアブロー

enabled

disabled

Air blow

Intializing

Back to passing pos.

connect position

connecting

stop

Y X

PortA.308

PortB.206

MSG02) Operatable
MSG29) Reached the number of times [Airblow1]

Port A (vertical move, outside fiber port)

y	x	1	2	3	4	5	6	7	8	9	10
A		SpO	SpO	SpO	So	CAL	Bak	Sci	Spe		
B		—	—	—	Cam	—	PL	PL	PL		
C		Air	Air	Air	Air	Air	Cleaner	—	—		


Microscope

Stick cleaner

Port B (horizontal, inside fiber port), seen from the outside port

y	x	1	2	3	4	5	6
a		Air	Air	Air	Cleaner	—	Cam
b		Slit	Slit	Slit	—	Splt	—

Air blow port, usable only these 2 ports



Stick cleaner

Microscope

Present address connect 32000 [pls]

③ connect

④ disconnect

② start connect

① passing

- SpO: Splitter Out
So: Solar
CAL: Calibration
Bak: Background
Sci: Science
Spe: Speckle
PL: Photonic lantern
Splt: Splitter in

スティッククリーニング

enabled

disabled

エアブロー

enabled

disabled

Intializing

Back to passing pos.

connect position

Y X
PortA.308
PortB.206

connecting

stop

Fiber port address

Some combinations of fiber ports cannot be executed.

Port A (vertical move, outside fiber port)										
	1	2	3	4	5	6	7	8	9	10
A	101	102	103	104	105	106	107	108		
B				204		206	207	208		
C	301	302	303	304	305	306				

Port B (horizontal, inside fiber port)										
	1	2	3	4	5	6				
a	101	102	103	104		106				
b	201	202	203		205					

y \ x	1	2	3	4	b	8	/	8	9	10
A	SpO	SpO	SpO	So	CAL	Bak	Sci	Spe		
B	—	—	—	Cam	—	PL	PL	PL		
C	Air	Air	Air	Air	Air	Cleaner	—	—		

y \ x	1	2	3	4	5	6
a	Air	Air	Air	Cleaner	—	Cam
b	Slit	Slit	Slit	—	Splt	—

SpO: Splitter Out
 So: Solar
 CAL: Calibration
 Bak: Background
 Sci: Science
 Spe: Speckle
 PL: Photonic lantern
 Splt: Splitter in

		101	102	103	104	105	106	107	108	204	206	207	208	305	306
		A1	A2	A3	A4	A5	A6	A7	A8	B4	B6	B7	B8	C5	C6
103	a3	0	0	1	1	1	1	1	1	1	1	1	1	0	0
104	a4	0	0	1	1	1	1	1	1	1	1	1	1	0	0
106	a6	0	0	0	0	0	1	1	1	0	1	1	1	0	0
201	b1	1	1	1	1	1	1	0	0	1	1	0	0	1	1
202	b2	0	1	1	1	1	1	1	0	1	1	1	0	1	1
203	b3	0	0	1	1	1	1	1	0	1	1	1	1	1	1
205	b5	0	0	0	0	1	1	1	1	0	1	1	1	1	1

1 = Connection OK
 2 = connection not possible

[back](#)

	explanation
M01/M03 setting (taravese)	Setting M01 M03 axis.
M02 setting (connecting)	Setting M02 axis.
timer setting	
maintenance data	check runnning data
PLC IP address setting	settting of animation position
言語	日本語に切り替え Language setting

M01,M03 setting (taravese)

Present address 15000 30000 [pls]
Present speed 0 0 [pls/sec]

reset

back

	address[pls]		speed	Acc.time	Dec.time		
	X	Y	[pls/sec]	[sec]	[sec]		
Initial	Initial address						
	500	-350	2000	1.000	1.000		
JOG +	CW limit						
	78500	62500	100	1.000	1.000		
JOG -	CCW limit						
	-4800	-4000	100	1.000	1.000		
Setting address							
	30000	0	6000	1.000	1.000		

		Pos.1	Pos.2	Pos.3	Pos.4	Pos.5	Pos.6
		0	15000	30000	45000	60000	75000
Pos.1	0	00	01	02	03	04	05
Pos.2	30000	10	11	12	13	14	15
Pos.3	60000	20	21	22	23	24	25

X Y
☐ ☐ Axis error
error code
0 0
maximum speed
6000 [pls/sec]
initial creep speed
500 [pls/sec]
acc. time
1.000 [sec]
dec. time
1.000 [sec]

X Y
☒ ☒ cw limit
☐ ☐ org sensor
☐ ☐ zero tim
☒ ☒ ccw limit
☒ ☒ drv. alarm








stop

Present address 32000 [pls]

Present speed 0 [pls/sec]

reset

back

	address[pls]	speed [pls/sec]	Acc.time [sec]	Dec.time [sec]	
Initial	Initial address -40	4000	1.000	1.000	
JOG +	CW limit 32300	2000	1.000	1.000	
JOG -	CCW limit -2000	2000	1.000	1.000	
passing	0	8000	3.000	0.100	
start connect	14000	8000	3.000	0.100	
connect	32000	3000	1.000	1.000	
dis- connect	12500	4000	1.000	1.000	

☒ Axis error
error code
0
maximum speed
40000[pls/sec]
initial creep speed
200[pls/sec]
acc. time
1.000[sec]
dec. time
1.000[sec]

- ☒ cw limit
- ☐ org sensor
- ☐ zero tim
- ☒ ccw limit
- ☒ drv. alarm

停止

[illegible]

back

Air blow A repetition

Air blow B time setting

Air blow B repetition

Stick cleaner time setting

Total number of uses of stick cleaners, air blowers, and fiber connections

maintenance data

	PV	/	SV		remark
スティック A	14	/	100	RESET	電磁弁動作回数
スティック B	9	/	100	RESET	電磁弁動作回数
エアブロー A	104	/	100	RESET	電磁弁動作回数
エアブロー B	162	/	100	RESET	電磁弁動作回数
嵌合回数	143	/	100	RESET	挿入位置到達回数

back

Stick cleaner A

Stick cleaner B

Air blow A

Air blow B

Fiber connection

IP address setting for the switcher

If you want to change the switcher's IP address, you also need special software. **So please let us know before changing the address.**

PLC IP address setting

現在のPLC内のIPアドレス設定	変更用のPLC内のIPアドレス設定 *白地黒文字のところに設定値を書き込んでください
IPアドレス 192.168. 0.183	IPアドレス 192.168. 0.183
サブネットマスクパターン 255.255.255. 0	サブネットマスクパターン 255.255.255. 0
ゲートウェイIPアドレス 192.168. 0. 2	ゲートウェイIPアドレス 192.168. 0. 2

*Soft-GOT内の設定変更も必要です。通信アドレスを変更した画面データを再読み込みしてください。

*書き込み後は、PLCの電源を一度切り、再投入で有効になります。

back

設定書込

Command line operation

Most commands are the same as the past switcher, except select fibers and switch status.

Select fiber port A and B

```
> 500000FF03FF000024000014010000W*0000140003010501020001
```

0105: Port A address

0102: Port B address

Last 4 letters: 0001= Cleaning On, 0000 = Cleaning off

Get switch status (I will send you the details of the alert and GUI messages later)

```
> 500000FF03FF000018000004010000W*000000000E
```

```
< D00000FF03FF00003C00000104010200010001AFC8000003E80000753000000000000000040010
```

[23 : 26] # Port A target position

[27 : 30] # Port B target position

[31 : 34] # M01, M03 flag for current and target position match, 0001 == OK

[35 : 38] # M02 insert-disconnect axis current position, 0=during move, 0003=insert, 0001=disconnect

[39 : 46] # Horizontal axis current position

[47 : 54] # insertion axis current position

[55 : 62] # vertical axis current position

[63 : 66] # Alert number 1

[67 : 70] # Alert number 2

[71 : 74] # GUI message 1

[75 : 78] # GUI message 2

Move the stages to the position immediately before inserting the fiber

```
> 500000FF03FF00001C0000140200000100W*0000120010
```