


# Importing GIS Network Data from VISUM, Cube, TransCAD Files with Examples

Version 2: Prepared by Dana Alsader (dana.alsader@asu.edu)  
Last Revised: April, 2016



Flow Chart for Importing, Analyzing and Exporting Data

Reference: Data Flow for Performing Dynamic Traffic Analysis

## Goal:

The following sections describe techniques and processes for importing and exporting network data using NeXTA's new network conversion tools. Specifically, these tools provide the capabilities of preparing and importing shape and demand files from VISUM, Cube, TransCAD and other shape files. To demonstrate this functionality, and assist the user throughout the conversion process,

## Examples:

1. [West Valley City, UT 3500 S sub-network \(VISUM\)](#)
2. [South Jordan, UT sub-network \(Cube\)](#)

**\*NeXTA:** The NeXTA used in this assignment is NeXTA GIS Tool

## **Content:**

### Lesson 1.1: Importing GIS Network Data from VISUM and Cube with Examples

#### Introduction

#### Methodology for Importing VISUM Networks

#### Example 1: West Valley City Sub-Network

##### Step 1: Export network and demand data from VISUM

- 1) Load the network in VISUM
- 2) Export network as shapefiles
- 3) Export demand tables/matrices

##### Step 2: Update input link type and input node data

##### Step 3: Import network from VISUM

- 1) Prepare the configuration file for conversion
- 2) Use NeXTA's import network tool to convert the network
- 3) Save the new network as a new project file

#### Methodology for Importing Cube Networks

#### Example 2: South Jordan Sub-Network

##### Step 1: Export network and demand data from Cube

##### Step 2: Import network from Cube

- 1) Prepare the configuration file for conversion
- 2) Use NeXTA's import network tool to convert the network

##### Import demand data from regional travel demand model (VISUM)

## Introduction

NeXTA's network conversion tool specifically imports network data from shapefiles, which are geospatial vector data files used with Geographic Information System (GIS) software and commonly supported by many transportation modeling software packages. Shapefiles contain spatial information about points, lines, and polygons in the transportation network, with separate files for different shapes. Road networks are represented as a graph of links (lines) and nodes (points), where links may represent road segments or transit lines and nodes may represent intersections or connections between individual links, and trips are often made between zones (polygons) on the network.

Network attribute data is stored in database (DBF) files for each shapefile, which must be read by NeXTA during the conversion process. Network data formatting is very flexible between network modeling software packages, with many applications allowing users to define custom formats and data fields for use within a software package. To support these applications, NeXTA uses a configuration CSV file for importing GIS settings, to identify and connect the fields in the input DBF files to their corresponding fields in the NeXTA/DTALite data format (`import_GIS_settings.csv`).

The user must be very careful when preparing the input data for conversion in NeXTA, specifically when selecting the map projection used to create the input shapefiles. A map projection identifies how 3-dimensional data is displayed on a 2-dimensional surface, and different shapefiles may have different map projections. The same shapefile, displayed with different map projections, can appear in completely separate locations, or show slightly different spatial alignments. To resolve this issue, it is important that the user makes sure that all input shapefiles have the same map projection before using the conversion tool. NeXTA currently supports arbitrary coordinate system but have a preferred map projection – WGS84, the default projection for Google Earth and the KML data standard. Map projection data is stored in a projection (PRJ) file within the shapefile standard. Therefore, it is the user's responsibility to make sure that shapefiles used for conversion in NeXTA all have WGS84 projection.

## Methodology for Importing VISUM Networks

The conversion tools offer the ability to convert networks for modeling at different spatial and temporal resolutions. However, this type of conversion often results in problems in network representation and data inconsistencies. The examples in this section follow a specific methodology for maintaining network and input data integrity between network models to support analysis at mesoscopic and microscopic modeling resolutions. This methodology is detailed below.

**Step 1:** Export network and demand data from VISUM

**Step 2:** Prepare input link type and input node and GIS importing setting data

**Step 3:** Import network into NeXTA

**Step 4:** Import demand data

**Step 5:** Run assignment with DTALite to equilibrium

**Step 6:** Export to Synchro/VISSIM for signal optimization and/or microscopic analysis

## **Example 1: [West Valley City Sub-Network](#)**

This example provides a step-by-step process to guide the user through converting the West Valley City sub-network for use in NeXTA/DTALite. This sub-network includes the busiest corridor of the 3500 South arterial in West Valley City, UT. The sub-network was obtained from the regional planning model and customized in VISUM.


### **Step 1: Export network and demand data from VISUM**

The first step in the network conversion process is to create a set of shapefiles describing the network to be imported into NeXTA. This is normally accomplished using export functions in the software used to prepare the selected network, and can be divided into three internal steps:

1. Load the network in originating software application
2. Export network as shapefiles
3. Export demand tables/matrices


#### **1) Load the network in VISUM**

In this example, the West Valley City sub-network was coded in VISUM and must be exported as a set of shapefiles. First, the network is loaded in VISUM.



**Figure 1: West Valley City sub-network loaded in VISUM**

Once the network is loaded in VISUM, it is recommended to check the map projections system and set it to WGS84 if some other system is used. In VISUM, this can be done by setting Network Parameters. In the Menu toolbar, go to Network -> Network Parameters..., select the Scale tab and check the Spatial reference system. Make sure that the From file option is checked, and that the reference system is set to GCS\_WGS\_1984. This procedure is shown in Figure 2. If the projection system is not changed in this step, the user must manipulate the shapefiles exported from VISUM in third-party software.




**Figure 2: Setting map projection system in VISUM**


## 2) Export network as shapefiles

By using VISUM's export function (File -> Export -> Shapefile), the network is split into its components, and saved as multiple separate shapefiles. First the user selects the destination folder for the network, gives the base name of the exported files under the File name (e.g. 35\_S\_export), and VISUM automatically adds suffix names for each layer. After pressing the Save button, VISUM opens another window where the user can choose which layers to export. The user should at least select the node, link, zone, zone centroid, and connector layers to ensure that the conversion process can successfully create a new network. While it is recommended that the user changes the export options to save the links as directed links to minimize any potential problems in the conversion process, the appropriate setting will depend on the network coding format. NeXTA can import networks with both directed and non-directed links. The user can also identify which columns will be exported with the shapefiles, which may be helpful to minimize confusion when working with shapefiles with large database files, or when working with multiple scenarios in the same network files. VISUM will export the shapefiles in the previously defined projection system. Once finished selecting export options, select "OK" at the bottom of the dialog box. This procedure is given in Figure 3.


## 3) Export demand tables/matrices

Click on the Matrices tab in the Overview toolbar to display the demand matrices. The zone matrices are compatible with the demand definition in NeXTA, so they are the main focus of this effort. Right click on the desired matrix, select Save to File..., navigate to the destination folder, give the name to the matrix, select Save, and in the next window select Format O from the Format dropdown list. . Format O is a common 3-column format that can be easily read by NeXTA. NeXTA also supports the standard VISUM "Format V" demand matrix format, which takes the form of a table with size Origin x Destination. The user should reference the VISUM User Manual for more information regarding different demand matrix formatting types. This matrix exporting procedure is shown in Figure 4.





**Figure 3: Exporting shapefiles from VISUM**



**Figure 4: Exporting matrices from VISUM**

The shapefiles and the matrix are now placed in the destination folder. If you open the folder, you should see the following files:

Organize ▾ Include in library ▾ Share with ▾ Burn New folder			
	Name	Date modified	Type
★ Favorites			
	Desktop		
	Downloads		
	Dropbox		
	Recent Places		
Libraries			
	Documents		
	Music		
	Pictures		
	Videos		
Computer			
	Local Disk (C:)		
zlatkovi (\\earth.coe			
	roadsafety (\\earth.c		
Network			
	MCE-1650-03		
	SAMUEL		
	35_S_export_connector.CTF	2/22/2013 10:37 AM	CTF File
	35_S_export_connector.DBF	2/22/2013 10:37 AM	DBF File
	35_S_export_connector.PRJ	2/22/2013 10:37 AM	PRJ File
	35_S_export_connector.SHP	2/22/2013 10:37 AM	SHP File
	35_S_export_connector.SHX	2/22/2013 10:37 AM	SHX File
	35_S_export_link.CTF	2/22/2013 10:37 AM	CTF File
	35_S_export_link.DBF	2/22/2013 10:37 AM	DBF File
	35_S_export_link.PRJ	2/22/2013 10:37 AM	PRJ File
	35_S_export_link.SHP	2/22/2013 10:37 AM	SHP File
	35_S_export_link.SHX	2/22/2013 10:37 AM	SHX File
	35_S_export_node.CTF	2/22/2013 10:37 AM	CTF File
	35_S_export_node.DBF	2/22/2013 10:37 AM	DBF File
	35_S_export_node.PRJ	2/22/2013 10:37 AM	PRJ File
	35_S_export_node.SHP	2/22/2013 10:37 AM	SHP File
	35_S_export_node.SHX	2/22/2013 10:37 AM	SHX File
	35_S_export_zone.CTF	2/22/2013 10:37 AM	CTF File
	35_S_export_zone.DBF	2/22/2013 10:37 AM	DBF File
	35_S_export_zone.PRJ	2/22/2013 10:37 AM	PRJ File
	35_S_export_zone.SHP	2/22/2013 10:37 AM	SHP File
	35_S_export_zone.SHX	2/22/2013 10:37 AM	SHX File
	35_S_export_zone_centroid.CTF	2/22/2013 10:37 AM	CTF File
	35_S_export_zone_centroid.DBF	2/22/2013 10:37 AM	DBF File
	35_S_export_zone_centroid.PRJ	2/22/2013 10:37 AM	PRJ File
	35_S_export_zone_centroid.SHP	2/22/2013 10:37 AM	SHP File
	35_S_export_zone_centroid.SHX	2/22/2013 10:37 AM	SHX File
	35_S_matrix.mtx	2/22/2013 10:45 AM	MTX File

**Figure 5: Exported files in destination folder**

## **Step 2: Update input link type and input node data**

The link type list in VISUM shows all link types used in the current network, as shown in Figure 6. It can be seen that there are a lot more link types than the default NeXTA values given in the input\_link\_type.csv file. For that reason, this CSV file needs to be updated with the current link types.



Count	No	Name	Rank	TsynSet	NumLanes	CapPVT	VOPVT	VMaxPVT	VMax_PTSynC	VDef_PuTSynB	VDef_PuTSynF
12	11	Major freeway	1	C	1	6000	65	0	200	25	2
13	12	Major freeway	1	C	1	4000	65	0	200	25	2
14	13	Major freeway	1	C	1	2000	55	0	200	25	2
15	14	Major freeway	1	C	1	5700	65	0	200	25	2
16	15	Major freeway	1	C	1	3800	65	0	200	25	2
17	16	Major freeway	1	C	1	5600	60	0	200	25	2
18	17	Major freeway	3	C	1	5400	60	0	200	25	2
19	18	Major freeway	3	C	1	3600	60	0	200	25	2
20	19	Major freeway	2	C	1	99999	31	0	124	25	2
21	20	Major freeway	2	C	1	99999	31	0	124	25	2
22	21	Freeway	7	C	1	5800	60	0	200	25	2
23	22	Freeway	7	C	1	3600	60	0	200	25	2
24	23	Freeway	9	C	1	1800	55	0	200	25	2
25	24	Freeway	9	C	1	5800	55	0	200	25	2
26	25	Freeway	9	C	1	3600	55	0	200	25	2
27	26	Freeway	9	C	1	1800	55	0	200	25	2
28	27	Freeway	3	C	1	99999	31	0	124	25	2
29	28	Freeway	3	C	1	99999	31	0	124	25	2
30	29	Freeway	9	C	1	3000	55	0	200	25	2
31	30	Freeway	4	C	1	99999	31	0	124	25	2
32	31	Junction ramp	51	C	1	4500	55	0	200	25	2
33	32	Junction ramp	51	C	1	3000	55	0	200	25	2
34	33	Ramp	55	C	1	4500	45	0	200	25	2
35	34	Ramp	55	C	1	3000	40	0	200	25	2
36	35	Ramp	55	C	1	1500	35	0	200	25	2
37	36	Ramp	55	C	1	4500	45	0	200	25	2
38	37	Ramp	55	C	1	3000	40	0	200	25	2
39	38	Ramp	55	C	1	1500	35	0	200	25	2
40	39	Rest area	89	C	1	0	5	0	200	25	2
41	40	Rest area	5	C	1	99999	31	0	124	25	2
42	41	Principal arterial	11	C	1	5100	50	0	200	25	2
43	42	Principal arterial	12	C	1	3200	50	0	200	25	2
44	43	Principal arterial	13	C	1	1600	50	0	200	25	2
45	44	Principal arterial	14	C	1	5100	45	0	200	25	2
46	45	Principal arterial	15	C	1	3200	45	0	200	25	2
47	46	Principal arterial	16	C	1	1600	45	0	200	25	2
48	47	Principal arterial	17	C	1	5100	40	0	200	25	2
49	48	Principal arterial	18	C	1	3200	40	0	200	25	2
50	49	Principal arterial	19	C	1	1600	40	0	200	25	2
51	50	Principal arterial	6	C	1	99999	31	0	124	25	2
52	51	Major arterial	21	C	1	4800	50	0	200	25	2
53	52	Major arterial	22	C	1	3000	50	0	200	25	2
54	53	Major arterial	23	C	1	1500	50	0	200	25	2
55	54	Major arterial	24	C	1	4800	45	0	200	25	2
56	55	Major arterial	25	B.C	1	3000	45	0	200	25	2
57	56	Major arterial	26	B.C	1	1500	45	0	200	25	2
58	57	Major arterial	27	C	1	4800	40	0	200	25	2
59	58	Major arterial	28	C	1	3000	40	0	200	25	2
60	59	Major arterial	29	C	1	1500	40	0	200	25	2

Figure 6: Link types in VISUM for current network

For the given example of the West Valley City VISUM network, the updated link type table should look like as follows:

link_type	link_type_name	type_code	default_lane_capacity	default_speed_limit	default_number_of_lanes
11	Freeway	f	1800	65	3
12	Freeway	f	1800	65	3
13	Freeway	f	1800	65	3
14	Freeway	f	1800	65	3
15	Freeway	f	1800	65	3
16	Freeway	f	1800	65	3

17	Freeway	f	1800	65	3
18	Freeway	f	1800	65	3
21	Freeway	f	1800	65	3
22	Freeway	f	1800	65	3
23	Freeway	f	1800	65	3
24	Freeway	f	1800	65	3
25	Freeway	f	1800	65	3
26	Freeway	f	1800	65	3
29	Freeway	f	1800	65	3
2	Highway/Expressway	h	1450	50	3
41	Principal arterial	a	1000	40	3
42	Principal arterial	a	1000	40	3
43	Principal arterial	a	1000	40	3
44	Principal arterial	a	1000	40	3
45	Principal arterial	a	1000	40	3
46	Principal arterial	a	1000	40	3
47	Principal arterial	a	1000	40	3
48	Principal arterial	a	1000	40	3
49	Principal arterial	a	1000	40	3
51	Major arterial	a	900	35	3

52	Major arterial	a	900	35	3
53	Major arterial	a	900	35	3
54	Major arterial	a	900	35	3
55	Major arterial	a	900	35	3
56	Major arterial	a	900	35	3
57	Major arterial	a	900	35	3
58	Major arterial	a	900	35	3
59	Major arterial	a	900	35	3
61	Minor arterial	a	850	30	2
62	Minor arterial	a	850	30	2
63	Minor arterial	a	850	30	2
64	Minor arterial	a	850	30	2
65	Minor arterial	a	850	30	2
66	Minor arterial	a	850	30	2
67	Minor arterial	a	850	30	2
68	Minor arterial	a	850	30	2
69	Minor arterial	a	850	30	2
71	Collector	a	650	25	1
72	Collector	a	650	25	1
73	Collector	a	650	25	1
74	Collector	a	650	25	1
75	Collector	a	650	25	1
76	Collector	a	650	25	1
77	Collector	a	650	25	1
78	Collector	a	650	25	1

79	Collector	a	650	25	1
81	Local	a	600	20	1
82	Local	a	600	20	1
85	Local	a	600	20	1
86	Local	a	600	20	1
99	Local	a	600	20	1
8	Frontage road	a	1000	45	2
31	Ramp	r	1300	30	2
32	Ramp	r	1300	30	2
33	Ramp	r	1300	30	2
34	Ramp	r	1300	30	2
35	Ramp	r	1300	30	2
36	Ramp	r	1300	30	2
37	Ramp	r	1300	30	2
38	Ramp	r	1300	30	2
10	Zonal connector	c	2000	100	2
100	Transit link	t	1000	40	1
200	Walking link	w	1000	5	1

The input node table should also be updated with the current control type, especially for signalized intersections. For a given VISUM network, this can be done by matching the node number in VISUM and the input\_node.csv file, and setting the correct control type in the CSV file. The easiest way is to open the node list in VISUM, and sort the nodes by control type. Figure 7 shows an example of the sorted nodes in VISUM for the given network. There are 13 signalized nodes, and for other the control type is unknown.

Count	No	Name	XCoord	YCoord	ControlType
1	132682591		-112.0057	40.6966	Signalized
2	132727839		-112.0248	40.6965	Signalized
3	132727841		-112.0153	40.6966	Signalized
4	132738639		-111.9962	40.6966	Signalized
5	132738640		-111.9903	40.6966	Signalized
6	132738644		-111.9866	40.6966	Signalized
7	132738645		-111.9809	40.6966	Signalized
8	132738649		-111.9771	40.6966	Signalized
9	132738651		-111.9675	40.6966	Signalized
10	132738657	3500	-111.9580	40.6967	Signalized
11	132738658		-111.9602	40.6966	Signalized
12	132738677		-111.9735	40.6966	Signalized
13	132738809		-111.9579	40.6929	Signalized
14	132673469		-111.9800	40.7039	Unknown
15	132676365		-112.0153	40.6929	Unknown
16	132677590		-112.0249	40.7038	Unknown
17	132682589		-112.0057	40.6949	Unknown
18	132682590		-112.0057	40.6954	Unknown
19	132682592		-112.0051	40.6954	Unknown

**Figure 7: Node control types in VISUM for current network**

When the project network is opened in NeXTA, it should reflect the new changes made in the input CSV files. The user is encouraged to compare the network between NeXTA and VISUM to make sure the network is coded correctly.

### **Step 3: Import network from VISUM**

The third step in the network conversion process is to use NeXTA's network import tool to convert the shapefiles (created in the previous step) into a network which can be used with NeXTA and DTALite. This process reads the spatial data stored in each specified shapefile, along with the corresponding data stored in the database (DBF) file, to create the input CSV files used by NeXTA and DTALite. In order to interpret the database (DBF) files for conversion, a GIS configuration CSV file is used to map field names between the shapefiles and the standard data format used by NeXTA (import\_GIS\_settings.csv).

The network import process is divided into three internal steps:

1. Prepare the configuration file for conversion
2. Use NeXTA's import network tool to convert the network
3. Save the new network as a new project file

#### **1) Prepare the configuration file for conversion**

First, create a configuration file in the folder containing the exported shapefiles (import\_GIS\_settings.csv). This file is located in the NeXTA's folder, under

importing\_sample\_data\_sets\GIS\_data\_set. The user should copy this CSV file to the destination folder, and make the changes needed for successful input process.

The configuration file consists of several sections, as defined in Column A. There are several sections of information in column “value” to be prepared by users, namely, file, configuration, node, link, zone, and optional centroid and connector layers.

The “key” settings given in Column B are used by NeXTA to successfully match and convert the shapefiles from the DBF files.

“Value” in Column C is the matching name between NeXTA’s “key” values, and those given in the shapefiles. When used with VISUM, these values are read from the corresponding lists accesses in VISUM through Menu -> Lists, or the converted shapefiles can be opened in any GIS software and accessed through attribute tables. “Allowed\_values” in Column D show which definitions are related to “value” for binary values (such as km vs. mile, lane vs. link, etc). Column E (“required\_or\_optional”) shows which values must be defined for a successful import.

**Remark: Although this configuration contains many data fields, users only need to prepare or change the data in column “value”.**

A sample file can be always found under

Internal\_release\importing\_sample\_data\_sets\GIS\_files\West\_Jordan\_from\_CUB

The first section defines the shape file names for nodes, links, zones, centroids, and connectors. In this example, the file name table looks like this:

section	key	value	allowed_values	required
file_name	node	35_S_export_nod e.shp		x
file_name	link	35_S_export_link. shp		x
file_name	zone	35_S_export_zon e.shp		
file_name	centroid	35_S_export_zon e_centroid.shp		
file_name	connector	35_S_export_con nector.shp		

The reference file names should correspond to the layers exported from VISUM. In this case, the file names have the format '35\_S\_export\_(layer).shp'. Node and link are the required layers for a successful GIS network import.

The next configuration section defines configuration settings to accommodate different network field

and format coding conventions. These settings include the latitude/longitude coordinate system definition, length units, one way vs. two way links, and whether the capacity is given per lane, or per link. In the given example, the configuration settings are as follows:

section	key	value	allowed_values	required
configuration	with_decimal_longitude_lat	yes	yes;no	
configuration	length_unit	mile	km;mile	
configuration	number_of_lanes_one-way_vs_two-way	oneway	oneway;two-way	
configuration	lane_capacity_vs_link_capacity	lane	lane;link	

configuration	direction_0_as_one-way_vs_two-way	oneway	oneway;two-way	
configuration	node_number_threshold_as_centroid	0	default 0	
configuration	use_default_speed_limit_from_link_type	no	yes;no	
configuration	use_default_lane_capacity_from_link_type	no	yes;no	
configuration	use_default_number_of_lanes_from_link_type	no	yes;no	
configuration	identify_signal_intersection	yes		yes;no
configuration	minimum_speed_limit_for_signals	28		
configuration	maximum_speed_limit_for_signals	60		
configuration	default_cycle_length	110		

	gth_in_second			
configuration	minimum_length_for_importing_links	0.00001		

The next section defines node attributes. The import values are node ID, node name, the zone (TAZ) to which a certain node belongs to, and node control type. In the given example, the node table is as follows:

section	key	value	allowed_values	required
node	node_id	NO		
node	name	NAME		
node	TAZ			
node	control_type	CONTROLT~1		


To see the correct definition node attributes, in VISUM go to Menu -> Lists -> Nodes and read the definitions from the corresponding columns. An example of the node list for this sub-network is given in Figure 6. For example, the node ID is the numerical value given in the column "No". The node ID, TAZ, name and control type should correspond to the attributes defined in VISUM.

Count: 388	No	Code	Name	TypeNo	ControlType	XCoord	YCoord	t0PrT	VolPrT	SCType
1	132673469			0	Unknown	-111.9800	40.7039	0s	0	
2	132676365			0	Unknown	-112.0153	40.6929	0s	399	
3	132677590			0	Unknown	-112.0249	40.7038	0s	1159	
4	132682589			0	Unknown	-112.0057	40.6949	0s	1419	
5	132682590			0	Unknown	-112.0057	40.6954	0s	1389	
6	132682591			0	Signalized	-112.0057	40.6966	0s	4357	Stage-based
7	132682592			0	Unknown	-112.0051	40.6954	0s	0	
8	132682595			0	Unknown	-112.0051	40.6949	0s	0	
9	132684259			0	Unknown	-111.9962	40.6934	0s	737	
10	132684260			0	Unknown	-111.9962	40.6939	0s	737	

**Figure 8: Node list in VISUM**

The user needs to be careful with attribute names that have more than 10 characters (such as ControlType in this case). The exported SHP/DBF file will convert the file name to the 10-character length (Controlt~1). To see the correct attribute name definitions, the user can use any GIS software to open the corresponding shapefile and read the name from the attribute table. Figure 9 shows an example for the node layer attribute table accessed through Quantum GIS. Note the adjusted name for control type:





**Figure 9: Node list in Q GIS**

The second section defines the link shapefile attributes. In order to code the corresponding attributes correctly, the user needs to open the link list in VISUM (Menu -> Lists -> Links), or access the link shapefile through GIS software, and read the link attributes. The available link attributes are from and to node, name, link ID, link type, transportation modes that link is open for, direction definition, length, number of lanes, hourly capacity, speed limit, and number of lanes, capacity, speed limit and link type for reversible lanes, if links are defined as two way links. For this example, the link table is as follows:

section	key	value	allowed_values	required
link	from_node_id	FROMNODENO		
link	to_node_id	TONODENO		
link	name	NAME		
link	link_id	NO		
link	link_type	TYPENO		
link	mode_code	TSYSSET		
link	direction			
link	length	LENGTH		
link	number_of_lanes	NUMLANES		
link	hourly_capacity	CAPPRT		
link	speed_limit	VOPRT		
link	r_number_of_lan			


	es			
link	r_hourly_capacity			
link	r_speed_limit			
link	r_link_type			

Note that there is a separate CSV file for link types (input\_link\_type.csv) that needs to be updated with the correct link types exported from VISUM.

The attributes can be read from the link list in VISUM or through GIS. Example for this network are given in Figures 10 and 11. The attributes denoted with r\_ refer to the reverse links, if the oneway\_vs\_twoway is set to twoway.

Count: 848	No	FromNodeNo	ToNodeNo	TypeNo	TSysSet	Length	NumLanes	CapPrT	VOPrT
1	31362734	132682589	132682590	66	C,F	0.035	1	1500	40
2	31362734	132682590	132682589	66	C,F	0.035	1	1500	40
3	31362735	132682590	132682591	66	C,F	0.080	1	1500	40
4	31362735	132682591	132682590	66	C,F	0.080	1	1500	40
5	31362736	132682590	132682592	86	C,F	0.034	1	800	15
6	31362736	132682592	132682590	86	C,F	0.034	1	800	15
7	31362740	132682589	132682595	86	C,F	0.034	1	800	15
8	31362740	132682595	132682589	86	C,F	0.034	1	800	15
9	31362741	132682592	132682595	86	C,F	0.030	1	800	15
10	31362741	132682595	132682592	86	C,F	0.030	1	800	15

**Figure 10: Link list in VISUM**



**Figure 11: Link list in Q GIS**

The next section is the zone table. The settings for the zone attributes are similar as for nodes and links, with the only important attribute being zone ID. The correct ID name is read from the zone link list in VISUM, or through the attribute table in GIS software:

section	key	value	allowed_values	required
zone	zone_id	NO		

The sections for the zone centroid and connector conversions are optional, and they need to be defined only if these layers are exported to shapefiles. In this example, the connector and zone centroid layers are exported from VISUM, so we need to define the importing configuration. The corresponding codes are read from the connector and zone lists in VISUM, or through the attribute table in GIS software. The definitions for centroids are name, node ID, and zone (TAZ). The definitions for connectors are zone end, link end, node end, length, number of lanes, hourly capacity, default speed limit, default link type, and direction.


section	key	value	allowed_values	required
centroid	name	NAME		
centroid	node_id	NO		
centroid	TAZ	NO		

section	key	value	allowed_values	required
connector	zone_end	ZONENO		
connector	link_end			
connector	node_end	NODENO		
connector	length	LENGTH		
connector	number_of_lanes			
connector	hourly_capacity			
connector	default_speed_limit	60		
connector	default_link_type	10		
connector	direction	DIRECTION		

The next sections define the final output, control type, and minimum and maximum values for speed limits for signals. These sections can be left as they are in the default file. The control type is defined in a separate CSV configuration file. Once the configuration file is populated and placed in the destination folder, the exported files are ready to be imported in NeXTA.



## 2) Use NeXTA's import network tool to convert the network

Starting with a new, empty network project in NeXTA, the conversion process is initiated by selecting the appropriate tool in the Import Menu. Go to File -> Import -> GIS Planning Data Set. A pop-up dialog box will inform the user about the importing configuration and required CSV files. The user can copy the sample CSV files to the destination folder before import. The user also has the option to access the online help document. This step is shown in Figure 12.




**Figure 12: GIS Network Import Menu location in NeXTA**

Press NEXT, navigate to the destination folder, select the import\_GIS\_settings.csv configuration file created in the previous step, and click Open, as shown in Figure 13. In the next step, NeXTA will display an import window, where the user can review the GIS import settings and make any changes if necessary. The importing window has three tabs, namely Input Node Type, Input Link Type, and GIS Import Settings. These settings should correspond to the defined CSV files. The Edit File in Excel option opens the corresponding CSV file in Excel. There is also an option to fetch the corresponding GIS field names in the case when user cannot find their definition. Selecting Import GIS Data will load the network into NeXTA. The importing window is shown in Figure 14.




Before importing the network, NeXTA will check the validity of the importing configuration. If there are any mismatches, it will provide a warning about the missing attributes, such as for example the following message:



**Figure 15: GIS importing error message**


This message refers to certain links which in VISUM are of Type 0 (unused). This error can be fixed later in the input\_link\_type.csv, and input\_link.csv files. The input\_link\_type.csv file should be updated with the current link types that exist in VISUM.

After the conversion process is complete, a File Loading Status window opens to display the results of the conversion process. Make sure to note the number of links, nodes, and zones (if any were selected for import) against the number of records in the shapefiles to make sure the process was completed successfully (no missing records). The file loading status for the current example is shown in Figure 16.



**Figure 16: File loading status window displays import results after completion**


The imported network should look similar to Figure 15 below.




**Figure 16: West Valley City (35 S) sub-network imported into NeXTA/DTALite**

### 3) Save the new network as a new project file

Finally, save the network as a new Transportation Network Project (\*.tnp) file to write the input tables in the project. In NeXTA, go to Menu File Save Project As, navigate to the destination folder, give the name to the project, and press Save. NeXTA will provide information on the main attributes of the new project network. This procedure is given in Figures 16 and 17.



**Figure 16: Saving new NeXTA/DTALite project file**



**Figure 17: New project status window**

## **Methodology for Importing Cube Networks**

Cube is another macroscopic simulation tool widely used by transportation agencies for their regional planning models. A network from Cube can be exported to shapefiles, so the same network can be imported into NeXTA. The exporting process from Cube is similar to VISUM. Please refer to the Cube User's manual for details on exporting to shapefiles. Also, the importing process into NeXTA is the same as for VISUM. The only adjustments need to be made to the import\_GIS\_settings.csv file. Here we provide an example for the [South Jordan, UT sub-network](#).

### **Example 2: [South Jordan Sub-Network](#)**

This example provides a guide for importing South Jordan sub-network, originated from Cube, for use in NeXTA/DTALite. The sub-network was obtained from the regional planning model and customized in Cube.

#### **Step 1: Export network and demand data from Cube**

The first step is to create a set of shapefiles describing the network to be imported into NeXTA. This is accomplished using export functions in Cube. At the minimum, layers for nodes and links must be exported. The demand data can be exported from Cube, or demand data available in some other format can be used. In this example, the following layers are exported:

- Node layer: SJ\_Node.shp
- Link layer: SJ\_Link.shp
- Zone layer: SJ\_Zone.shp

#### **Step 2: Import network from Cube**

The second step in the network conversion process is to use NeXTA's network import tool to convert the shapefiles (created in the previous step) into a network which can be used with NeXTA and DTALite. In order to interpret the database (DBF) files for conversion, a GIS configuration CSV file is used to map field names between the shapefiles and the standard data format used by NeXTA (import\_GIS\_settings.csv).

The network import process is divided into three steps, same as for importing VISUM networks:



1. Prepare the configuration file for conversion
2. Use NeXTA's import network tool to convert the network
3. Save the new network as a new project file


#### 1) Prepare the configuration file for conversion

The importing configuration file (import\_GIS\_settings.csv) is the only step that will be different from importing a VISUM network, due to different attribute definitions. In order to read the attributes correctly, the user is encouraged to use any available GIS software to access layer attribute tables.

In this example, we first define the layer file names and configuration in the configuration file:

section	key	value	allowed_values	required
file_name	node	SJ_Node.shp		x
file_name	link	SJ_Link.shp		x
file_name	zone	SJ_Zone.shp		
file_name	centroid			
file_name	connector			
configuration	with_decimal_longitude_lat	yes	yes;no	
configuration	length_unit	mile	km;mile	
configuration	number_of_lanes_oneway_vs_two_way	oneway	oneway;two-way	
configuration	lane_capacity_vs_link_capacity	lane	lane;link	

The next step is to define the node attributes. Opening the node layer shapefile in Quantum GIS provides an easy access to the node attribute table, which we need to read the node attributes correctly. Figure 22 shows node attribute table in Q GIS:




**Figure 22: Node layer attributes exported from Cube for South Jordan sub-network**

Based on these attributes, we update the node table in the configuration file:

section	key	value	allowed_values	required
node	node_id	N		
node	name	NODENAME		
node	TAZ	TAZID		
node	control_type			

The next step is defining the link attributes. They can be accessed by opening the layer shapefile in Q GIS as given in Figure 23:




**Figure 23: Link layer attributes exported from Cube for South Jordan sub-network**

We populate the link table in the configuration file according to the given attributes:

section	key	value	allowed_values	required
link	from_node_id	A		
link	to_node_id	B		
link	name	STREET		
link	link_id	LINKID		
link	link_type			
link	mode_code			
link	direction			
link	length	DISTANCE		
link	number_of_lanes	LANES		
link	hourly_capacity	CAP1HR1LN		
link	speed_limit	SFF		
link	r_number_of_lanes			
link	r_hourly_capacity			
link	r_speed_limit			
link	r_link_type			

The last exported layer is the zone layer. We again open it with Q GIS to access its attributes, as shown in Figure 24:



**Figure 24: Zone layer attributes exported from Cube for South Jordan sub-network**


The zone table will have the zone ID field as:

section	key	value	allowed_values	required
zone	zone_id	Id		


The centroid and connector fields will be empty in the configuration table, since we do not have those layers exported from Cube. The “offset\_link” can be kept to the default value as “yes”, as well as the values for minimum and maximum speed for signals.

## 2) Use NeXTA’s import network tool to convert the network

As for the VISUM network, the Cube network can be imported into NeXTA through Menu File GIS Network Data Set. We navigate to the South Jordan sub-network folder and select import\_GIS\_settings.csv file. This network will now be imported into NeXTA, as shown in Figures 25 and 26:



**Figure 25: NeXTA file loading status for South Jordan sub-network**



**Figure 26: South Jordan sub-network loaded into NeXTA**

The last step is to save the network as a new network project (File -> Save Project As), and the new network can now be manipulated through NeXTA.


**Extra Steps: Run assignment with DTLite to equilibrium**

### Import demand data from regional travel demand model

The demand matrix from VISUM is exported in Format O, which is a typical 3-column format for zone-to-zone demand. The demand data settings are defined in the input\_demand\_meta\_data.csv file in the project folder. In this CSV file, among other settings, the user defines the scenario to which the demand is applied, the file sequence if there are more than one demand data table/matrix, the format type, number of lines to be skipped, loading multiplier, simulation start and end times, and different demand types. Note that these settings can be accessed and changed directly within NeXTA, through Menu -> Project -> 2. Demand Meta Database. The main settings for the given network are as follows:

scenario_no	file_sequence_no	file_name	format type	number_of_lines_to_be_skipped	loading_multiplier
0	1	35_S_matrix.mtx	multi_column	8	1

The demand matrix exported from VISUM has the format as shown in Figure 20.



```
35_S_matrix.mtx - Notepad
File Edit Format View Help
$O;D3
* From to
0.00 24.00
* Factor
1.00
*
* U of Utah salt Lake city
* 02/22/13
1      40  6.000
1      57 10.000
3       1  3.000
3      37  3.000
3      39 15.000
3      56 28.000
3      57 15.000
4       1  3.000
4      37  3.000
4      39 15.000
4      56 20.000
4      57 15.000
5      39  6.000
6      53 25.000
7      38 25.000
7      39 29.000
7      53 20.000
```

**Figure 27: Demand matrix format**

After all network and demand data are imported, the network is ready for running DTA. Note that any changes can be made in NeXTA through Menu -> Projects. The simulation is run by pressing the Start simulation button located in the toolbar menu. The popup window that appears shows the defined settings, and allows a selection of the traffic flow model, traffic assignment method, the number of iterations, and the demand loading multiplier, as shown in Figure 21. When the selections are made, pressing OK starts the DTA simulation.

Review Simulation/Assignment Settings

Network Data:	Demand Data:
447 nodes 988 links 447 zones 447 activity locations 69 link types	Demand Loading Time Period: 14:00->15:00 (02:00 PM->03:00 PM) Demand files: 35_S_matrix.mtx

Traffic Flow Model:	Traffic Assignment Method:	# of Iterations:
BPR Function Point Queue Model Spatial Queue Model Newell's N-Curve Model	Method of Successive Average Day-to-Day Learning Gap function-based Assignment Gap function-based MSA Accessibility (Distance) Accessibility (Travel Time)	20

☐ Emission Data Output

Demand Loading Multiplier: 1

OK Cancel

Figure 28: Simulation/Assignment settings window