

[Home](#)

CLASSES

rcb

endScript  
getBoardId  
getBoardVersion  
getFirmwareVersion  
onKeyPress  
setDebugMode  
wait

console

append  
clear  
error  
overwrite  
print  
remove  
setVerbose  
warning

files

appendTextFile  
newLogEntry  
newLogFile  
newTextFile

output

ramp  
set  
steps  
steps2

sensors

averageResultsArray  
read  
readOhm  
setMotorPoles  
setSafetyLimit  
tareCurrent  
tareLoadCells

udp

ab2str  
init  
onReceive  
send  
str2ab

GLOBAL

# console

## rcb.console

new console()

Console interface functions

Source: [rcbApi.js, line 153](#)

## Methods

(static) append(message, id<sub>opt</sub>)

Adds to the last printed line (does not create a new line).

### Parameters:

Name	Type	Attributes	Description
message	string		The string to print on the console. Can have html markup.
id	integer	<optional>	If specified, will append to this line instead.

Source: [rcbApi.js, line 245](#)

## Example

```
rcb.console.print('Doing...');  
rcb.console.append('<strong>done</strong>');
```

(static) clear()

[Home](#)

CLASSES

rcb

- endScript
- getBoardId
- getBoardVersion
- getFirmwareVersion
- onKeyPress
- setDebugMode
- wait

console

- append
- clear
- error
- overwrite
- print
- remove
- setVerbose
- warning

files

- appendTextFile
- newLogEntry
- newLogFile
- newTextFile

output

- ramp
- set
- steps
- steps2

sensors

- averageResultsArray
- read
- readOhm
- setMotorPoles
- setSafetyLimit
- tareCurrent
- tareLoadCells

udp

- ab2str
- init
- onReceive
- send
- str2ab

GLOBAL

Clears the script console. Needed for performance reasons if console log has too much text.

Source: [rcbApi.js, line 301](#)

Example

```
rcb.console.clear();
```

(static) error(message)

Prints an error on the user console. The script will be stopped.

Parameters:

Name	Type	Description
message	string	The string to print on the console. Can have html markup.

Source: [rcbApi.js, line 291](#)

Example

```
rcb.console.print("A basic message");  
rcb.console.warning("About to throw error");  
rcb.console.error("Bazinga!");
```

(static) overwrite(message, id<sub>opt</sub>)

Reprints over the last line of the user console. Useful to display progress updates.

Parameters:

Name	Type	Attributes	Description
message	string		The string to print on the console. Can have html markup.

[Home](#)

CLASSES

- rcb
- endScript
  - getBoardId
  - getBoardVersion
  - getFirmwareVersion
  - onKeyPress
  - setDebugMode
  - wait

- console
- append
  - clear
  - error
  - overwrite
  - print
  - remove
  - setVerbose
  - warning

- files
- appendTextFile
  - newLogEntry
  - newLogFile
  - newTextFile

- output
- ramp
  - set
  - steps
  - steps2

- sensors
- averageResultsArray
  - read
  - readOhm
  - setMotorPoles
  - setSafetyLimit
  - tareCurrent
  - tareLoadCells

- udp
- ab2str
  - init
  - onReceive
  - send
  - str2ab

GLOBAL

Name	Type	Attributes	Description
id	integer	<optional>	If specified, will overwrite this line instead.

Source: [rcbApi.js, line 257](#)

(static) print(message) → {integer}

Prints a new line to the user console.

Parameters:

Name	Type	Description
message	string	The string to print on the console. Can have html markup.

Source: [rcbApi.js, line 231](#)

Returns:

A unique id, to reference this printed line later.

Type      integer

Examples

```
rcb.console.print('Normal text');
rcb.console.print('<strong>Bold font</strong>');
rcb.console.print('<span style=\"color: green\">
```

```
//Simple examples
rcb.console.print("I will always be there!");
rcb.console.print("I will be gone");
rcb.console.remove();
rcb.console.append(" Still here!");
rcb.console.print("I will be overwritten");
rcb.console.overwrite("Fruits:");
```

[Home](#)**CLASSES****rcb**

endScript  
getBoardId  
getBoardVersion  
getFirmwareVersion  
onKeyPress  
setDebugMode  
wait

**console**

append  
clear  
error  
overwrite  
print  
remove  
setVerbose  
warning

**files**

appendTextFile  
newLogEntry  
newLogFile  
newTextFile

**output**

ramp  
set  
steps  
steps2

**sensors**

averageResultsArray  
read  
readOhm  
setMotorPoles  
setSafetyLimit  
tareCurrent  
tareLoadCells

**udp**

ab2str  
init  
onReceive  
send  
str2ab

**GLOBAL**

```
//Working with ids
var id1 = rcb.console.print("I WILL BE REMOVED")
var id2 = rcb.console.print("2");
var id3 = rcb.console.print("I WILL BE OVERWRITTEN")
rcb.console.print("3");
rcb.console.append(" apples");
rcb.console.append(" oranges", id2);
rcb.console.remove(id1);
rcb.console.overwrite("Doesn't compare with:", id3);
rcb.endScript();
```

```
//Animation example
rcb.console.setVerbose(false);
var lineQty = 12;
var colQty = 25;
var lines = [];

//Create the Lines
for(var i=0; i<lineQty; i++) lines[i] = rcb.console.print(i);
```

```
//Starting coordinates
var line = 0;
var col = 0;
var dirL = true;
var dirC = true;
//Travel Loop until user stops script
move();
function move(){
    //Update coordinates
    if(dirL){
        line++;
        if (line === lineQty-1) dirL = false;
    }else{
        line--;
        if (line === 0) dirL = true;
    }
    if(dirC){
        col++;
        if (col === colQty-1) dirC = false;
    }else{
        col--;
        if (col === 0) dirC = true;
    }
}
```

```
//Draw
for(var i=0; i<lineQty; i++){
    if(i===line){
        var text = "";
        for(var j=0; j<colQty-1; j++) text+="&#9208;";
    }
}
```

[Home](#)

CLASSES

rcb

- endScript
- getBoardId
- getBoardVersion
- getFirmwareVersion
- onKeyPress
- setDebugMode
- wait

console

- append
- clear
- error
- overwrite
- print
- remove
- setVerbose
- warning

files

- appendTextFile
- newLogEntry
- newLogFile
- newTextFile

output

- ramp
- set
- steps
- steps2

sensors

- averageResultsArray
- read
- readOhm
- setMotorPoles
- setSafetyLimit
- tareCurrent
- tareLoadCells

udp

- ab2str
- init
- onReceive
- send
- str2ab

GLOBAL

console - Documentation

```
        text+="0";
        rcb.console.overwrite(text,lines[i])
    }else
        rcb.console.overwrite("",lines[i]);
    }

    //iterate
    rcb.wait(move,0.05);
}
```

(static) remove(id<sub>opt</sub>)

Removes the last line of the user console.

Parameters:

Name	Type	Attributes	Description
id	integer	<optional>	If specified, will remove this line instead.

Source: [rcbApi.js, line 268](#)

(static) setVerbose(value)

Sets the verbose mode for the rcb API. If activated (default), some API functions will print some text (in grey color). It may be useful to deactivate verbose mode in loops to avoid excessive text in the console.

Parameters:

Name	Type	Description
value	boolean	If true, verbose mode is activated.

Source: [rcbApi.js, line 371](#)

Example

```
//Example showing the effect of changing verbose
rcb.console.print("Verbose activated...");
```

[Home](#)

CLASSES

rcb

endScript  
getBoardId  
getBoardVersion  
getFirmwareVersion  
onKeyPress  
setDebugMode  
wait

console

append  
clear  
error  
overwrite  
print  
remove  
setVerbose  
warning

files

appendTextFile  
newLogEntry  
newLogFile  
newTextFile

output

ramp  
set  
steps  
steps2

sensors

averageResultsArray  
read  
readOhm  
setMotorPoles  
setSafetyLimit  
tareCurrent  
tareLoadCells

udp

ab2str  
init  
onReceive  
send  
str2ab

GLOBAL

console - Documentation

```
rcb.setDebugMode(true);  
rcb.setDebugMode(false);  
rcb.console.setVerbose(false);  
rcb.console.print("Verbose deactivated...");  
rcb.setDebugMode(true);  
rcb.setDebugMode(false);  
rcb.endScript();
```

(static) warning(message) → {integer}

Prints a message in orange. Does not interrupt script.

Parameters:

Name	Type	Description
message	string	The string to print on the console. Can have html markup.

Source: [rcbApi.js, line 279](#)

Returns:

A unique id, to reference this printed line later.

Type      integer

Example

```
rcb.console.warning('<strong>Warning:</strong> w
```

Documentation generated by [JSDoc 3.6.3](#) on Wed Aug 21 2019  
09:49:26 GMT-0400 (Eastern Daylight Time) using the *Minami*  
theme.