

# Maintenance Schedule

SERVICE AT THE INTERVAL OF LISTED KM (MILES) OR MONTHS, WHICHEVER OCCURS FIRST.						
ITEMS	x 1,000 km	20	40	60	80	100
	x 1,000 miles	12	24	36	48	60
	months	12	24	36	48	60
IDLE SPEED AND IDLE CO		I	I	I	I	I
VALVE CLEARANCE		I	I	I	I	I
ALTERNATOR DRIVE BELT			I		I	
■ ENGINE OIL AND OIL FILTER		Replace every 10,000 km (6,000 miles) or 6 months				
■ TRANSMISSION OIL			R		R	
■ RADIATOR COOLANT					R <sup>*1</sup>	
COOLING SYSTEM, HOSES AND CONNECTIONS			I		I	
E.G.R. SYSTEM (For cars using unleaded gasoline) <sup>*2</sup>						I
SECONDARY AIR SUPPLY SYSTEM (For carburetor type) <sup>*3</sup>						I
AIR CLEANER ELEMENT (Dry type) <sup>*4</sup>	R	R	R	R	R	R
AIR CLEANER ELEMENT (Viscous type) <sup>*6</sup>			R		R	
FUEL FILTER (Including aux. filter for carburetor type)			R		R	
INTAKE AIR TEMP. CONTROL SYSTEM (For carburetor type)						I
TANK, FUEL LINE AND CONNECTION			I		I	
THROTTLE CONTROL SYSTEM (For carburetor type)			I		I	
CHOKE MECHANISM (For carburetor type)			I		I	
CHOKE OPENER OPERATION (For carburetor type)						I
EVAPORATIVE EMISSION CONTROL SYSTEM <sup>*5</sup>						I
IGNITION TIMING AND CONTROL SYSTEM			I		I	
SPARK PLUGS (For cars using leaded gasoline)	R	R	R	R	R	R
SPARK PLUGS (For cars using unleaded gasoline)			R		R	
DISTRIBUTOR CAP AND ROTOR			I		I	
IGNITION WIRING			I		I	
CRANKCASE EMISSION CONTROL SYSTEM			I		I	
BRAKE HOSES AND LINES (Including ALB hoses and pipes for ALB models)	I	I	I	I	I	I
BRAKE FLUID (Including ALB fluid for ALB models)			R		R	
FRONT BRAKE DISCS AND CALIPERS	I	I	I	I	I	I
FRONT BRAKE PADS		Inspect every 10,000 km (6,000 miles) or 6 months				
REAR BRAKE DISCS CALIPERS AND PADS		I		I		
PARKING BRAKES	I	I		I		
EXHAUST PIPE AND MUFFLER	I	I	I	I	I	I
SUSPENSION MOUNTING BOLTS	I	I	I	I	I	I
FRONT WHEEL ALIGNMENT	I	I	I	I	I	I
REAR WHEEL ALIGNMENT (For 4WS model)		I	I	I	I	I
STEERING OPERATION, TIE ROD ENDS, STEERING GEAR BOX BOOTS, AND CENTER SHAFT FOR 4WS MODEL	Except for 4WS model	I	I	I	I	
	For 4WS model	I	I	I	I	I
ALB HIGH PRESSURE HOSES					R	
ALB OPERATION		I	I		I	
POWER STEERING SYSTEM	I	I	I	I	I	I
POWER STEERING PUMP BELT			I		I	
CATALYTIC CONVERTER HEAT SHIELD (Car equipped with catalytic converter)						I

R—Replace I—Inspect. After inspection, clean, adjust, repair or replace if necessary <sup>\*1</sup> Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

■ REMARK: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

<sup>\*2</sup> Except for KQ type  
<sup>\*3</sup> Except for cars using leaded gasoline  
<sup>\*4</sup> Except for European and KQ types  
<sup>\*5</sup> Except for fuel injection type using leaded gasoline  
<sup>\*6</sup> For European and KQ types

**CAUTION:** The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

"Severe driving conditions" include:  
A: Repeated short distance driving  
B: Driving in dusty conditions  
C: Driving in severe, cold weather  
D: Driving in areas using road salt or other corrosive materials  
E: Driving on rough and/or muddy roads  
F: Towing a trailer

R—Replace  
I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A, B, F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
F	Transmission oil	R	Every 20,000 Km (12,000 miles) or 12 months
A, B, D, E, F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A, B, D, E, F	Rear brakes	I	Every 20,000 km (12,000 miles) or 12 months
B, C, E	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months