

1.3 For transmitter modules (XJT as an example), choose D16 mode first, and turn on External RF on the transmitter while holding the F/S button on the module, release the

How to Switch FS mode/HS mode

1. The factory default setting is FS mode.

Note: The SBUS output is 9ms, no matter HS/FS mode.

How to Disable/Enable Variometer function

- a) The factory default setting is “enabled”.

How to select output 1 ~ 6CH / 9 ~ 14CH

For both Taranis and Horus series transmitters, choose 1-8CH / 9~16CH after selecting

Selections on the Transmitter	
CH1 – 8 Telemetry ON	