

# How to Use Your *Skillsville* Tablet

- **Turning the Tablet On and Off**
  - Press and hold the small grey power button located on the upper-right side of the tablet.
- **Unlocking the Tablet**
  - Swipe up from the bottom of the screen.
- **Waking up the Tablet**
  - Double tap or press the power button once.
- **Three Button Navigation**
  - There are three buttons at the bottom of the screen that help you navigate. The left arrow allows you to go back, the middle circle takes you to the home screen, and the right square shows all of the tabs that are open.
- **Accessing Settings**
  - Swipe down from the top of your screen. Swipe down again on the black portion then select Settings.
- **Joining the Internet**
  - Swipe down from the top of your screen to see the settings. Select Internet and then join your local WIFI.
- **Camera**
  - The camera is located on the backside of the tablet in the upper-right corner.
- **Headphones**
  - You can plug in your headphones at the top of the tablet on the left side.
- **Adjusting Volume**
  - Press the volume buttons on the upper-right side of the tablet above the power button.
- **Charging the Tablet**
  - Plug in the charging cord at the bottom of the tablet. You will know it is charging when the red light appears. The light will turn green when it is done charging.
- **Opening the *Skillsville* Platform**
  - Select the Chrome icon at the bottom of the screen to open the platform.