

PIEZAS Y MANO DE OBRA

Partes	PIEZA OEM #	PRECIO	CANTIDAD	
Suspensión delantera				
Paréntesis				
14 - Parte de la barra estabilizadora.		0.00	1	Agregar
Bujes				
13 - Parte de la barra estabilizadora.		0.00	1	Agregar
Suspensión delantera				
16 - Travesaño	3C0199313BB	975.14	1	Agregar
Buje de travesaño				
17 - Inferior	1K0199867Q	93.53	1	Agregar
17 - Superior	1K0199868Q	93.53	1	Agregar
Brazo de control inferior				
9 - Izquierda	5N0407151	404.60	1	Agregar
9 - Derecha	5N0407152	404.60	1	Agregar
Paréntesis	3C0199231E	115.79	1	Agregar
Bujes				
10 - Frente	1K0407182F	48.63	1	Agregar
Trasero				
10 - Parte del soporte.		0.00	1	Agregar
Barra estabilizadora				
12 - Barra estabilizadora	3C0411303T	267.56	1	Agregar
Incluye: Casquillos y soportes.				
15 - Enlace	5Q0411315D	88.78	1	Agregar

Componentes de suspensión

1 - Buje delantero y rodamiento	5K0498621	338.62	1	Agregar
<i>Incluye rodamiento de rueda.</i>				
3 - Puntal	5N0413031AK	170.50	1	Agregar
<i>Ordenar por aplicación de vehículo.</i>				
4 - Cojinete de puntal	6N0412249E	58.36	1	Agregar
5 - Montaje de puntal	1K0412331C	114.18	1	Agregar
6 - Muelle helicoidal	5N0411105S	150.86	1	Agregar
<i>Ordenar por marcas de color.</i>				
7 - Escudo contra el polvo	6N0413175A	59.29	1	Agregar
8 - Parachoques de puntal	1K0412303M	58.94	1	Agregar
Nudillo				
2 - Left	1K0407255AA	441.18	1	Add
2 - Right	1K0407256AA	441.18	1	Add
Lower Ball Joint				
11 - Left	1K0407365C	100.36	1	Add
11 - Right	1K0407366C	100.36	1	Add

Rear Suspension

Lower Control Arm

13 - Lower Control Arm	1K0505311AB	312.80	1	Add
------------------------	-------------	--------	---	-----

Rear Suspension





18 - Crossmember	5N0505315S	1077.39	1	Add
------------------	------------	---------	---	-----

19 - Crossmember Bushing	NOT LISTED	0.00	1	Add
--------------------------	------------	------	---	-----

Stabilizer Bar

14 - Stabilizer Bar	1K0511409CA	165.36	1	Add
---------------------	-------------	--------	---	-----

15 - Bushings	1K0511327AR	20.50	<input type="text" value="1"/>	Add
16 - Bracket	1K0511439E	49.15	<input type="text" value="1"/>	Add
17 - Link	1K0505465AA	77.20	<input type="text" value="1"/>	Add
Suspension Components				
1 - Shock Absorber	5N0513049AP	176.82	<input type="text" value="1"/>	Add
<i>Order By VIN.</i>				
2 - Coil Spring	3C0511115AD	159.80	<input type="text" value="1"/>	Add
<i>Order By Paint Code.</i>				
4 - Dust Shield	3C0513425	18.23	<input type="text" value="1"/>	Add
5 - Bumper	3C0511359	38.99	<input type="text" value="1"/>	Add
6 - Shock Mount	3C0513353C	100.40	<input type="text" value="1"/>	Add
8 - Bushings	1K0505553A	35.00	<input type="text" value="1"/>	Add
9 - Rear Hub & Bearing	5QF598611	223.33	<input type="text" value="1"/>	Add
Knuckle				
7 - Left	3C0505433L	607.58	<input type="text" value="1"/>	Add
7 - Right	3C0505434L	607.58	<input type="text" value="1"/>	Add
Spring Seat				
3 - Lower	1K0512297D	34.88	<input type="text" value="1"/>	Add
3 - Upper	1K0512149B	33.49	<input type="text" value="1"/>	Add
Tie Rod				
See Axle Assembly	NOT SERVICED	0.00	<input type="text" value="1"/>	Add
Trailing Arm				
11 - Left	3C0505223F	246.50	<input type="text" value="1"/>	Add
11 - Right	3C0505224F	246.50	<input type="text" value="1"/>	Add

Upper Link					
10 - Left	1K0501529F	131.23		1	Add
10 - Right	1K0501530C	131.23		1	Add
Upper Control Arm					
12 - Upper Control Arm	5Q0505323C	294.10		1	Add
Labor	SKILL	WARRANTY	STANDARD	HOURS	^
Overhaul					
Front Suspension					
Suspension Service					
Suspension, Overhaul					
One Side	B	0.0	4.2 	4.2	Add
Both Sides	B	0.0	8.2 	8.2	Add
Rear Suspension					
Suspension Service					
Suspension, Overhaul					
One Side	B	0.0	3.6 	3.6	Add
Both Sides	B	0.0	7.0 	7	Add
Remove & Replace					
Front Suspension					
Crossmember Bushing, R&R					
All	B	0.0	2.6 	2.6	Add
One	B	0.0	2.0 	2	Add
Crossmember, R&R	B	0.0	4.0 	4	Add
Lower Control Arm					
Bushings, R&R					
One	B	0.0	1.8 	1.8	Add

Does Not Include: Wheel Alignment.

Each Additional

B

0.0

0.1 

0.1

Add

Does Not Include: Wheel Alignment.

Lower Control Arm, R&R

One Side

B

0.0

1.6 

1.6

Add

Does Not Include: Wheel Alignment.

One Side

NOTE *(Optional Labor)*

To R&R Bushings, Add

One

0.2 

0.2

Add

Each Additional

0.1 

0.1

Add

Both Sides

B

0.0

3.0 

3

Add

Does Not Include: Wheel Alignment.

Both Sides

NOTE *(Optional Labor)*

To R&R Bushings, Add

One

0.2 

0.2

Add

Each Additional

0.1 

0.1

Add

Stabilizer Bar

Bushings, R&R

One Or Both

C

0.0

1.5 

1.5

Add

Link, R&R

One Side

C

0.0

0.4 

0.4

Add

Both Sides

C

0.0

0.7 

0.7

Add

Stabilizer Bar, R&R

C

0.0

2.3 

2.3

Add

Suspension Components

Coil Spring, R&R

Left Side

B

0.0

3.8 

3.8

Add

Does Not Include: Wheel Alignment.

Right Side

B	0.0	2.0		2	Add
---	-----	-----	---	---	-----

Does Not Include: Wheel Alignment.

Front Hub & Bearing, R&R

One Side

B	0.0	1.3		1.3	Add
---	-----	-----	---	-----	-----

Both Sides

B	0.0	2.3		2.3	Add
---	-----	-----	---	-----	-----

Knuckle, R&R

One Side

B	0.0	1.6		1.6	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Both Sides

B	0.0	3.1		3.1	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Lower Ball Joint, R&R

One Side

B	0.0	0.8		0.8	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Both Sides

B	0.0	1.5		1.5	Add
---	-----	-----	--	-----	-----

Does Not Include: Wheel Alignment.

Strut Assembly, R&R

One Side

B	0.0	1.8		1.8	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment, Or Disassembly Of Strut And Spring Assembly.

Both Sides

B	0.0	3.4		3.4	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment, Or Disassembly Of Strut And Spring Assembly.

Strut Bearing, R&R

One Side

B	0.0	2.0		2	Add
---	-----	-----	---	---	-----

Does Not Include: Wheel Alignment.

Both Sides

B	0.0	3.8		3.8	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Strut Mount, R&R

One Side

B	0.0	2.0		2	Add
---	-----	-----	---	---	-----

Does Not Include: Wheel Alignment.

Both Sides

B	0.0	3.8		3.8	Add
---	-----	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Strut, R&R

One Side	B	0.0	2.0 	2	Add
----------	---	-----	---	---	-----

Does Not Include: Wheel Alignment.

Both Sides	B	0.0	3.8 	3.8	Add
------------	---	-----	---	-----	-----

Does Not Include: Wheel Alignment.

Rear Suspension

Crossmember Bushing, R&R	B	0.0	5.7 	5.7	Add
--------------------------	---	-----	---	-----	-----

Crossmember, R&R	B	0.0	5.5 	5.5	Add
------------------	---	-----	---	-----	-----

Lower Control Arm

Lower Control Arm, R&R

One Side	B	0.0	1.5 	1.5	Add
----------	---	-----	---	-----	-----

One Side

NOTE (Optional Labor)

To R&R Bushings, Add

One			0.2 	0.2	Add
-----	--	--	---	-----	-----


Each Additional			0.1 	0.1	Add
-----------------	--	--	---	-----	-----

Both Sides	B	0.0	2.8 	2.8	Add
------------	---	-----	---	-----	-----

Both Sides

NOTE (Optional Labor)

To R&R Bushings, Add

One			0.2 	0.2	Add
-----	--	--	---	-----	-----

Each Additional			0.1 	0.1	Add
-----------------	--	--	---	-----	-----















Stabilizer Bar

Bushings, R&R



One Or Both	C	0.0	1.2 	1.2	Add
-------------	---	-----	---	-----	-----

Link, R&R



One Side	C	0.0	0.5 	0.5	Add
----------	---	-----	---	-----	-----

Both Sides	C	0.0	0.8 	0.8	Add
Stabilizer Bar, R&R	C	0.0	1.2 	1.2	Add
Suspension Components					
Coil Spring, R&R					
One Side	B	0.0	0.6 	0.6	Add
Both Sides	B	0.0	1.0 	1	Add
Knuckle, R&R					
One Side	B	0.0	1.6 	1.6	Add
One Side					
NOTE (Optional Labor)					
To R&R Lower Control Arm Bushings, Add					
One Side			0.2 	0.2	Add
Both Sides			0.4 	0.4	Add
Both Sides	B	0.0	3.0 	3	Add
Both Sides					
NOTE (Optional Labor)					
To R&R Lower Control Arm Bushings, Add					
One Side			0.2 	0.2	Add
Both Sides			0.4 	0.4	Add
Rear Hub & Bearing, R&R					
One Side	B	0.0	1.3 	1.3	Add
Both Sides	B	0.0	2.4 	2.4	Add
Shock Absorber, R&R					
One Side	B	0.0	1.0 	1	Add
Both Sides	B	0.0	1.8 	1.8	Add

Shock Mount, R&R

One Side	B	0.0	1.0 	<input type="text" value="1"/>	Add
Both Sides	B	0.0	1.8 	<input type="text" value="1.8"/>	Add

Tie Rod, R&R

One Side	B	0.0	1.2 	<input type="text" value="1.2"/>	Add
Both Sides	B	0.0	2.0 	<input type="text" value="2"/>	Add




Trailing Arm, R&R

One Side	B	0.0	1.3 	<input type="text" value="1.3"/>	Add
----------	---	-----	---	----------------------------------	-----

One Side

NOTE *(Optional Labor)*

To R&R Bushings, Add

One Side			0.2 	<input type="text" value="0.2"/>	Add
Both Sides			0.4 	<input type="text" value="0.4"/>	Add
Both Sides	B	0.0	1.8 	<input type="text" value="1.8"/>	Add



Both Sides

NOTE *(Optional Labor)*

To R&R Bushings, Add

One Side			0.2 	<input type="text" value="0.2"/>	Add
Both Sides			0.4 	<input type="text" value="0.4"/>	Add

Upper Link, R&R

One Side	B	0.0	2.1 	<input type="text" value="2.1"/>	Add
Both Sides	B	0.0	4.0 	<input type="text" value="4"/>	Add

Upper Control Arm

Upper Control Arm, R&R

One Side	B	0.0	1.0 	<input type="text" value="1"/>	Add
----------	---	-----	---	--------------------------------	-----

One Side

NOTE (Optional Labor)

To R&R Bushings, Add

One Side

0.2 

0.2

Add

Both Sides

0.4 

0.4

Add

Both Sides

B

0.0

1.8 

1.8

Add

Both Sides

NOTE (Optional Labor)

To R&R Bushings, Add

One Side

0.2 

0.2

Add

Both Sides

0.4 

0.4

Add

Lubricate

Chassis & Wheels

Chassis, Lubricate

See Lube & Filter, Service

0.0



0

Add