














2012 Audi A6 Quattro Sedan (4G2) V6-3.0L SC (CGXB)

Vehicle > Transmission and Drivetrain > Automatic Transmission/Transaxle

PIEZAS Y MANO DE OBRA

Partes	PIEZA OEM #		PRECIO	CANTIDAD	^
Transeje automático					
Placa de accionamiento	Modelo 06E105323T		345.44	<div>1</div>	Agregar
Filtro	0BK398009A		433.33	<div>1</div>	Agregar
Junta de la bandeja					
Parte de Trans Filter.			0.00	<div>1</div>	Agregar
Transeje					
Código Trans Nxt	0BK300039D002		14044.00	<div>1</div>	Agregar
Trans Code Neu					
A partir del 30/05/11	0BK300039D002		14044.00	<div>1</div>	Agregar
Hasta el 30/05/11	0BK300039D001		14044.00	<div>1</div>	Agregar
Control de cambio de marchas					
Conjunto de cambio de marchas	8K1713105AG		828.33	<div>1</div>	Agregar
Cable de control de cambios	4G0713265E		255.00	<div>1</div>	Agregar
Trabajo	HABILIDAD		ESTÁNDAR	HORAS	^
Quitar y reemplazar					
Transeje automático					
Filtro, R&R	B	0.0	3.2	<div>3.2</div>	Agregar
Incluye: Drene & Refill Trans y R&I Trans Oil Pan.					
Transaxle, R&R	B	0.0	11.4	<div>11.4</div>	Agregar
Transaxle, R&R					
NOTA (mano de obra opcional)					

Para enjuagar las líneas del enfriador, agregue			0.6		0.6	Agregar
A la placa de transmisión R&R, agregue			0.2		0.2	Agregar
Al convertidor de par R&R,						
Agregar			0.2		0.2	Agregar
Caja y piezas relacionadas						
Junta de cárter de aceite, R&R						
Quattro	B	0.0	3.0		3	Agregar
Cárter de aceite, R&R						
Quattro	B	0.0	3.0		3	Agregar
Control de cambio de marchas						
Conjunto de cambio de marchas, R&R						
Quattro	B	0.0	0.9		0.9	Agregar
Shift Control Cable, R&R						
Quattro	B	0.0	2.1		2.1	Add
Mounts						
Trans Mount, R&R	B	0.0	0.9		0.9	Add
Oil Cooler						
Oil Cooler, R&R						
Quattro	B	0.0	0.7		0.7	Add
Powertrain Control						
Input Sensor, R&R	B	0.0	3.9		3.9	Add
Output Sensor, R&R	B	0.0	3.9		3.9	Add
Vehicle Speed Sensor, R&R	B	0.0	3.9		3.9	Add
Switches						
Range Sensor, R&R	B	0.0	0.5		0.5	Add

Valve Body

Valve Body, R&R

Quattro	B	0.0	4.2 	4.2	Add
---------	---	-----	---	-----	-----

Change

Automatic Transaxle

Trans Fluid, Change	B	0.0	0.6 	0.6	Add
---------------------	---	-----	---	-----	-----

Diagnosis

Automatic Transaxle

Oil Leak, Diagnosis	B	0.0	0.5 	0.5	Add
---------------------	---	-----	---	-----	-----

Includes: Clean And Dry Outside Of Case And Operate Unit To Determine Point Of Leakage.

Transaxle, Diagnosis	A	0.0	1.8 	1.8	Add
----------------------	---	-----	---	-----	-----

Includes: Time To Hook-Up And Disconnect Test Equipment. Checking System For Fault Codes, Road Test And Hydraulic Pressure Test As Required.

Remove & Install

Automatic Transaxle

Transaxle, R&I	B	0.0	10.8 	10.8	Add
----------------	---	-----	--	------	-----

Transaxle, R&I

NOTE (Optional Labor)

To R&R Driveplate, Add			0.2 	0.2	Add
------------------------	--	--	---	-----	-----

To R&R Torque Converter,

Add			0.2 	0.2	Add
-----	--	--	---	-----	-----

Overhaul

Automatic Transaxle

Transaxle, Overhaul	A	0.0	17.3 	17.3	Add
---------------------	---	-----	--	------	-----

Includes: R&I Transaxle.

Transaxle, Overhaul

NOTE (Optional Labor)

To Flush Cooler Lines, Add

0.6 

Add

To Overhaul Differential,

Add

1.5 

Add

To Overhaul Valve Body, Add

1.5 

Add