




Table of Contents

1 Introduction

2 Configurations

2.1 Configuration of SoftAP Mode



2.2 Configuration of Web Server

ATWE

platform_opts.h



3.1 Page of OPEN

The screenshot shows the "Realtek SoftAP Configuration" interface. It has three main configuration rows:

- SoftAP SSID:** The input field contains 38 asterisks (*).
- Security Type:** A dropdown menu is set to "OPEN".
- Channel:** A dropdown menu is set to "6".

A JavaScript alert dialog box is overlaid on top of the configuration form. It displays the IP address "<192.168.1.1>" and the error message "SoftAP SSID is too long!(1-32)". At the bottom of the dialog, there is a checkbox labeled "Stop executing scripts on this page" which is currently unchecked, and an "OK" button.

3.2 Page of WPA2

Realtek SoftAP Configuration

SoftAP SSID:	wlan_ap_wpa2
Security Type:	WPA2-AES
Password:	12345678
Channel:	6

Submit

Copyright ©realtek.com

Realtek SoftAP Configuration

SoftAP SSID:	wlan_ap_wpa2
Security Type:	WPA2-AES
Password:	
Channel:	

JavaScript <192.168.1.1>
Password length is between 8 to 32
☐ Stop executing scripts on this page OK

Realtek SoftAP Configuration

SoftAP SSID:	wlan_ap_wpa2
Security Type:	WPA2-AES
Password:	123
Channel:	


JavaScript <192.168.1.1>
Password length is between 8 to 32
☐ Stop executing scripts on this page OK

Realtek SoftAP Configuration

SoftAP SSID:	wlan_ap_wpa2
Security Type:	WPA2-AES
Password:	33333333333333333333333333333333
Channel:	

JavaScript <192.168.1.1>
Password length is between 8 to 32
☐ Stop executing scripts on this page OK

3.3 Page of Wait



SoftAP is now restarting!

Please wait a moment and reconnect!