



---

**Table of Contents**


# **1 Introduction**


## **2 Solution 1: Device AP mode + Smart Phone App**

## **3 Solution 2: Vendor Customize Simple Config**

### **3.1 STA mode + Promiscuous mode**

p





```
# ATWM=3[with_len]
#ATWM match ATWM, search cnt 1
[ATWM]: _AT_WLAN_PROMISC_
```

```
Switch to channel<1>
DA: c4 6e 1f 58 42 bc, SA: 00 e0 4c 87 00 00, len=6
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=56
DA: ff ff ff ff ff ff, SA: 00 1f 3b 81 48 89, len=47

Switch to channel<2>
DA: ff ff ff ff ff ff, SA: 00 1f 3b 81 48 89, len=154

Switch to channel<3>

Switch to channel<4>
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=56

Switch to channel<5>
DA: 34 bd c8 ac 14 20, SA: d0 22 be 22 00 a9, len=6
DA: 34 bd c8 ac 14 20, SA: d0 22 be 22 00 a9, len=6
```

```
# ATWM=3
#M match ATWM, search cnt 1
[ATWM]: _AT_WLAN_PROMISC_
```


```
Switch to channel<1>
DA: 01 00 5e 00 00 fb, SA: c4 6e 1f 58 42 bc, len=0
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=0
DA: 01 00 5e 00 00 fb, SA: c4 6e 1f 58 42 bc, len=0
DA: 01 00 5e 00 00 fb, SA: c4 6e 1f 58 42 bc, len=0
DA: ff ff ff ff ff ff, SA: ac cf 5c 61 eb 27, len=0
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=0

Switch to channel<2>

Switch to channel<3>
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=0
DA: 01 00 0c cc cc cd, SA: 24 e9 b3 23 f0 92, len=0

Switch to channel<4>
DA: 20 10 7a 7c bb 34, SA: 5c f3 fc 3e a9 b8, len=0
```

## 4 Solution 3: Realtek Simple Config



## 4.1 Simple Config Usage

### Install Android APP

---

## Simple Config APK description

### Config Progress



## Configuration without PIN code

*entered via "ATWQ" command*

- 
- 

## Configuration with PIN Code

P

- 
- 

## 4.2 Simple Config Testing

K	K	K
---	---	---



---

P

K

K

P

```
# ATWQ=12345678
# Command ATWQ
  ATWQ match ATWQ, search cnt 1
[ATWQ]: _AT_WLAN_SIMPLE_CONFIG_

ioctl[SIIOCGIWESSID] ssid = NULL, not connected
ioctl[SIIOCGIWESSID] ssid = NULL, not connected
ioctl[SIIOCGIWESSID] ssid = NULL, not connected
===== Connection Information =====

wifi->security_type = RTW_SECURITY_OPEN
wifi.password =
wifi.password_len = 0
wifi.ssid = rtk
wifi.ssid_len = 3

===== start to connect target AP =====
RTL8195A[Driver]: set ssid [rtk]
RTL8195A[Driver]: start auth
RTL8195A[Driver]: auth success, start assoc
RTL8195A[Driver]: association success(res=1)

IP address : 192.168.1.100

WIFI wlan0 Setting:
=====
  MODE => STATION
  SSID => rtk
  CHANNEL => 1
  SECURITY => OPEN
  PASSWORD =>

[MEM] After do cmd, available heap 52936

# ATWI=192.168.1.254
# Command ATWI
  ATWI match ATWI, search cnt 1
[ATWI]: _AT_WLAN_PING_TEST_
[ATWI]Target address: 192.168.1.254
[ATWI]Repeat Count: 5

[ping_test] PING 192.168.1.254 120(148) bytes of data
[ping_test] 128 bytes from 192.168.1.254: icmp_seq=1 time=2 ms
[ping_test] 128 bytes from 192.168.1.254: icmp_seq=2 time=2 ms
[ping_test] 128 bytes from 192.168.1.254: icmp_seq=3 time=2 ms
[ping_test] 128 bytes from 192.168.1.254: icmp_seq=4 time=3 ms
[ping_test] 128 bytes from 192.168.1.254: icmp_seq=5 time=2 ms
[MEM] After do cmd, available heap 52936
```


## 4.3 Simple Config Resources

---

## 5 Solution 3: Realtek WPS Config

### 5.1 WPS Config Usage

#### Config Progress



device pin code    75798024

#### Configuration with PBC

## Configuration with PIN

### 5.2 WPS Config Testing

K
---

K

```
# ATWW=pin
# Command ATWW
ATWW match ATWW, search cnt 2
[ATWW]: _AT_WLAN_WPS_

ioctl[ISIOCGIWESSID] ssid = NULL, not connected
[pin]device pin code = 75798024

[pin]find out first trigger wps AP = rtk

Start WPS PIN

[pin]target ssid = rtk
RTL8195A[Driver]: set ssid [rtk]
RTL8195A[Driver]: start auth
RTL8195A[Driver]: auth success, start assoc
RTL8195A[Driver]: association success(res=3)
RTL8195A[Driver]: WPS: Building Message M1
RTL8195A[Driver]: Receive WPS_M2
RTL8195A[Driver]: WPS: Building Message M3
RTL8195A[Driver]: Receive WPS_M4
RTL8195A[Driver]: WPS: Building Message M5
RTL8195A[Driver]: Receive WPS_M6
RTL8195A[Driver]: WPS: Building Message M7
RTL8195A[Driver]: Receive WPS_M8
RTL8195A[Driver]: WPS: Received M8
RTL8195A[Driver]: WPS: Building Message WSC_Done

[pin]get credential from queue

[pin]dev_cred.ssid = rtk
[pin]dev_cred.key =
[pin]dev_cred.auth_type = u
[pin]dev_cred.encr_type = u

wps_config_wifi_setting

wps_wifi.ssid = rtk
wps_wifi.ssid_len = 3
security_type = RTW_SECURITY_OPEN
wps_wifi.security_type = 0
wps_wifi.password =
wps_wifi.password_len = 0
===== wifi_certificate_info =====
```

```
===== wifi_certificate_info =====
```

```
wps_wifi.ssid = rtk
security_type = 0
wps_wifi.password =
ssid_len = 3
password_len = 0
RTL8195A[Driver]: set ssid [rtk]
RTL8195A[Driver]: start auth
RTL8195A[Driver]: auth success, start assoc
RTL8195A[Driver]: association success(res=3)
```

```
IP address : 192.168.1.100
```

```
WIFI wlan0 Setting:
```

```
=====
MODE => STATION
SSID => rtk
CHANNEL => 2
SECURITY => OPEN
PASSWORD =>
```

```
[MEM] After do cmd, available heap 52912
```