


Brake Lights



Test

NOTE: Refer to page 16-92 for wiring description of the brake light circuit.

1. If the brake lights do not go on, check the No. 32 (15 A) fuse in the under-hood relay box, and the brake light bulbs in the taillight assembly and the high mount brake light.
2. If the fuse and bulbs are OK, disconnect the 2-P or 4-P connector from the brake light switch.



3. Check for continuity between the A and B terminals.
There should be continuity with the brake pedal pushed.
- If no continuity, replace the switch or adjust pedal height (see section 13).
 - If there is continuity, but the brake lights do not go on:
 - Poor ground (G501).
 - An open in the WHT/GRN or GRN/WHT wire.
 - Faulty brake light failure sensors (see page 16-97).