


Gearshift Mechanism



Cable Adjustment

Select Cable


1. Remove the console.
2. With the transmission in neutral, check that the groove in the lever bracket is aligned with the index mark on the selector cable.



3. If the index mark is not aligned with the groove in the cable, loosen the lock nuts and turn the adjuster as necessary.

NOTE:


- After adjustment, check operation of the gearshift lever.
- Also check that the threads ③ of the cables do not extend out of the cable adjuster by more than 10 mm (0.4 in.).



③: 10 mm or less

Gearshift Cable


1. Remove the console.
2. Place the transmission in 4th gear.
3. Measure the clearance between the gearshift lever bracket and stopper while pushing the lever forward.



4. If the clearance is outside specifications, loosen the lock nuts and turn the adjuster in or out until the correct clearance is obtained.

NOTE:

- After adjustment, check operation of the gearshift lever.
- Also check that the threads ③ of the cables do not extend out of the cable adjuster by more than 10 mm (0.4 in.).



③: 10 mm or less

Gearshift Mechanism

Gearshift Mechanism Overhaul

NOTE: Inspect rubber parts for wear or damage when disassembling.

