

Cylinder Head/Valve Train

Illustrated Index

CAUTION: To avoid damaging the cylinder head, wait until the coolant temperature drops below 38°C (100°F) before removing it.

NOTE: Use new O-rings and gaskets whenever reassembling.



