




Test

Recirculation Control Switch

1. Disconnect the 16P connector from the heater control.
2. Check for continuity between the terminals according to the table.

Terminal	12	11	6
Position			
	○	○	○
		○	○



Function Control Motor

1. Connect the battery positive terminal to the 5 terminal of the function control motor and negative to the 1 terminal.
 2. Using a jumper wire short the 6 terminal to the 8, 7, 2, 3 and 4 terminals to follow the order.
- The motor should run each time the short circuit is made.

