

# Console

## Replacement

Disassemble in numbered sequence:

**NOTE:**

- Remove the rear console first, before front console removal.
- Lift up the parking brake lever.
- After removing the front console, disconnect the wire harness inside the console.
- For manual transmission models, remove the shift lever knob.

