



Opener and Latch Replacement

1. Remove the left kick panel. (page 14-36).
2. Remove the bolts, then remove the hood opener and disconnect the opener cable.
3. Remove the 3 mounting bolts, then remove the hood latch and disconnect the opener cable.
4. Remove the inner fender, then pull out the opener cable.

NOTE: Before pulling out the opener cable, tie a string to the cable so you can pull it back in later.

