


Clutch

Illustrated Index



NOTE: Whenever the transmission is removed, release bearing sliding surface should be cleaned and greased.

