





























# Troubleshooting

## Symptom-to-System Chart

PROBLEM CODE		PROBLEMATIC COMPONENT/ SYSTEM	AFFECTED				See page	OTHER COMPONENT	See page
MAIN CODE	SUB CODE		FRONT RIGHT	FRONT LEFT	REAR RIGHT	REAR LEFT			
	—	Hydraulic Controlled Component	—	—	—	—	13-50	-ALB fuse -Motor relay -Pressure Switch -Accumulator -Modulator	13-84
	—	Parking brake switch-related problem	—	—	—	—	13-53	Brake fluid level switch <b>BRAKE</b> light	
		Front fail safe relay	—	—	—	—	13-84 (Function Test)		
		Rear fail safe relay	—	—	—	—			
		Pulser (s)	○				—		
				○					
					○	○			
		Speed sensor(s)			○		13-54	Modulator	
						○			
					○	○			
 or  or 		Speed sensor	○				13-55		
				○					
					○				
						○			
		Front solenoid related problem (Open)	IN				13-56		
			OUT					Front R speed sensor	13-55
			BOTH						
				IN					
				OUT				Front L speed sensor	13-55
				BOTH					
		Front fail safe relay	BOTH	BOTH			13-57	Solenoids misconnected	

PROBLEM CODE		PROBLEMATIC COMPONENT/ SYSTEM	AFFECTED			See page	OTHER COMPONENT	See page	
MAIN CODE	SUB CODE		FRONT RIGHT	FRONT LEFT	REAR				
<div>9</div>	—	Solenoid related problem (Open)			IN	13-59			
<div>10</div>	—				OUT		Rear speed sensors	13-55	
<div>11</div>	—				BOTH	13-60	Rear fail safe relay	13-86	
<div>11</div>	<div>3</div>		BOTH		BOTH	—			Front or rear fail safe relay
	<div>12</div>			BOTH	BOTH				
	<div>15</div>			BOTH	BOTH		BOTH		
<div>12</div>	<div>1</div>	Solenoid related problem (Short)	IN			13-62			
	<div>2</div>		OUT						
	<div>3</div>		BOTH			13-63	No.28 fuse		
	<div>4</div>	Power supply problem		IN		13-62			
	<div>8</div>			OUT					
	<div>12</div>			BOTH		13-64	No.26 fuse		
	<div>15</div>		BOTH	BOTH		—	No.28 and/or No.26 fuse		
<div>13</div>	—	Solenoid related problem (Short)			IN	13-65			
<div>14</div>	—				OUT				
<div>15</div>	—				BOTH	—			
<div>15</div>	<div>3</div>		BOTH		BOTH		No.28 fuse		
	<div>12</div>			BOTH	BOTH		No.26 fuse		
			LED stays ON:		BOTH		BOTH	BOTH	No.28 and/or No.26 fuse

NOTE: The control unit can display a number of sub-codes other than those listed. Such sub-codes indicate unlikely combinations of multiple component failures, or more likely, a problem in a wire or connector common to a group of components. To troubleshoot, refer to the procedures for other sub-codes with the same main code.