

Evaporator

Overhaul

1. Pull out the evaporator sensor from the evaporator fins.
2. Remove the tapping screws and clips from the housing.
3. Carefully separate the housings and remove the evaporator covers.
4. Remove the expansion valve if necessary.

Assemble the evaporator in the reverse order of disassembly, and:
Install the expansion valve capillary tube against the suction line, and wrap it with tape.
Reinstall the evaporator sensor in its original location.

TAPE

Repalce

Make sure there is no foreign matter stuck between the capillary tube and outlet line.

