



Overhaul

NOTE:

- Before reassembly, make sure that the air door and linkage moves smoothly without binding.
- When re-attaching the actuator, make sure its positioning will not allow the air door to be pulled too far. Attach the actuator and all linkage, then apply battery voltage and watch the door movement. If necessary, loosen the holding screw and move the actuator up or down.

To adjust the control rod:

Connect the recircu. control motor connector to the main wire harness, push the "FRESH" and open the air doors. Then connect the control rod to the arm while holding the air doors open.

NOTE: LH Drive shown, RH Drive is similar.

